

AD4212L-R50
AD4212L-R100
Weigh Module



INSTRUCTION MANUAL



A&D Company, Ltd.

The manual and Marks

All safety messages are identified by the following, "WARNING" or "CAUTION", of ANSI Z535.4 (American National Standard Institute: Product Safety Signs and Labels). The meanings are as follows:

 WARNING	A potentially hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	A potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



This is a hazard alert mark.

- This manual is subject to change without notice, at any time, to improve the product.
- The contents of the product specifications and this manual are subject to change without any obligation on the part of the manufacturer.
- Under the copyright laws, the software (program) described in this manual is copyrighted, with all rights reserved.
The software may be installed into one computer and may not be installed into other computers without the prior written consent of A&D Company, Limited. Copying includes translation into another language, reproduction, conversion, photocopying and offer or loan to another person.

Teflon is a registered trademark of DuPont.

© 2019 **A&D Company, Limited** All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, or translated into any language in any form by any means without the written permission of A&D Company, Limited.

Contents

1.	Introduction.....	4
1.1.	Features.....	4
2.	Product Structure, Installation and Precautions.....	6
2.1.	Assembling and Adjusting	8
2.2.	Precaution Before Use	13
2.3.	Precaution on Building Into a System	14
2.4.	During Use.....	16
2.5.	After Use.....	16
3.	Basic Operation.....	17
3.1.	Changing the Weighing Speed and Stability Detection	17
3.2.	Calibrating the Display Unit	20
3.2.1.	Calibration Using a Weight ([-5Et]).....	20
3.2.2.	Error Codes for Calibration ([Er]).....	21
3.3.	Changing the Baud Rate and Slave Address	22
3.3.1.	Initializing Parameters.....	22
3.3.1.1.	Initializing Mode for RAM and Function Parameters.....	22
3.3.1.2.	Initializing All Data	23
4.	Communication Specification.....	24
5.	Troubleshooting.....	26
5.1.	Check Mode.....	26
5.1.1.	Entering Check Mode	26
5.1.2.	Verifying the Switch Operation.....	27
5.1.3.	Checking the Control I/O	27
5.1.4.	Checking the Standard Serial Output	27
5.1.5.	Checking the RS-485 Output.....	27
5.1.6.	Monitoring the A/D Converter (for Load Cell Output)	27
5.1.7.	Monitoring the Internal Value	27
5.1.8.	Monitoring the Program Version	28
5.1.9.	Monitoring the Serial Number.....	28
5.1.10.	Monitoring the Checksum of the Program.....	28
5.1.11.	Monitoring the Checksum of an Internal FRAM.....	28
5.1.12.	Displaying Function Parameters for the Calibration ([-F01 ~ 28]).....	28
5.2.	Verifying Weighing Unit Connections (DIAGNOS)	29
5.2.1.	Guideline to Verify Weighing Unit Connections.....	29
5.2.2.	Verifying Weighing Unit Connections with Switch Operation.....	29
5.2.3.	Verifying Using the RS-485.....	30
5.2.4.	Verifying Using Control I/O	30
5.2.5.	Display and Output of Verification	30
5.3.	Verifying Weighing Unit Connections Using Multimeter	32
5.3.1.	Check List for Weighing Unit Connections	32
6.	Display Unit Detailed Descriptions.....	34
6.1.	Specifications.....	34
6.1.1.	Digital Parts (Display and Keys)	34
6.1.2.	General.....	34
6.1.2.1.	Interface.....	34

6.1.2.2.	Weighing Functions.....	35
6.2.	Operations	36
6.2.1.	General Functions.....	36
6.2.1.1.	Zero Operation	36
6.2.1.2.	Zero Tracking	36
6.2.1.3.	Tare Function.....	36
6.2.1.4.	Clearing the Tare Value and Zero Operation	37
6.2.1.5.	Customizing the Functions of the F Key	37
6.2.1.6.	Customizing the Function of the x Display	38
6.2.1.7.	Memory Backup	38
6.2.1.8.	Near-Zero Detection.....	38
6.2.1.9.	Upper or Lower Limit Detection Function	39
6.2.1.10.	Full Value Detection Function	39
6.2.1.11.	Digital Filter 1 and 2 (F_{nc05} and F_{nc06})	39
6.2.1.12.	Hold Functions	40
6.2.2.	Flow Rate	43
6.2.3.	Batch Weighing.....	44
6.2.3.1.	Sequential Weighing	45
6.2.3.2.	Weighing Sequence Error (Output)	47
6.2.3.3.	Error Reset (Input).....	47
6.2.3.4.	One Shot Small Flow (Input).....	47
6.2.3.5.	Full Open (Output)	47
6.2.3.6.	Actual Free Fall Input.....	47
6.2.3.7.	Automatic Free Fall Compensation	48
6.2.3.8.	Active Free Fall Compensation.....	48
6.2.3.9.	Sequence Numbers	49
6.2.4.	Remote I/O.....	50
6.2.5.	State Diagram and Operation Switches	51
6.2.5.1.	State Diagram.....	51
6.2.6.	Calibration	52
6.2.6.1.	Calibrating with a Weight ($L-5Et$).....	52
6.2.6.2.	Calibration Using a Weight with the RS-485 Modbus RTU.....	53
6.2.6.3.	Gravity Acceleration Correction	53
6.2.6.4.	Digital Linearization	55
6.2.6.5.	Actual Load Linearization Function ($L-5Et$)	56
6.2.6.6.	Calibration Function ($L-F_{nc}$).....	57
6.2.6.7.	Linearization Functions ($L-F_{nc}$)	61
6.2.7.	List of General Functions.....	62
6.2.7.1.	Procedure to Store New Parameters.....	62
6.2.7.2.	Basic Functions ($F_{nc} F$)	63
6.2.7.3.	Hold Functions ($Hld F$).....	64
6.2.7.4.	Weighing Sequence Functions ($Sq F$).....	65
6.2.7.5.	Flow Rate Functions ($F_r F$).....	66
6.2.7.6.	Control I/O Functions ($IO F$).....	67
6.2.7.7.	Standard Serial Output Functions ($SL F$).....	68
6.2.7.8.	RS-485 Functions ($r5 F$).....	68
6.3.	Interface	69
6.3.1.	RS-485	69

6.3.1.1.	Modbus RTU	69
6.3.1.2.	Error Code of the Modbus RTU (Data Address : 400065 - 400068)	70
6.3.1.3.	Bit Address of Status Indicators (Data Address : 400009 - 400010)	70
6.3.1.4.	Internal Write Cycle/Write Result (Data Address : 400099 - 400100)	70
6.3.1.5.	Access Interval Timer (Data Address : 400097 - 400098)	70
6.3.2.	Control I/O	71
6.3.3.	Standard Serial Output (Current Loop)	72
6.3.3.1.	Data Format of Serial Output	72
6.3.3.2.	Transfer Mode of Serial Output	73
6.3.4.	USB	74
6.3.4.1.	Format	74
6.3.4.2.	Monitoring the Function Setting	74
6.3.4.3.	Storing the Function Setting	75
6.3.4.4.	Reading the Whole Function Settings	75
6.3.4.5.	Reading Data	75
6.3.5.	Modbus RTU Data Address	76
6.4.	Maintenance	86
6.4.1.	Parameter	86
6.4.1.1.	Calibration Functions ($[F_{nc}]$)	86
6.4.1.2.	Linearization Functions ($L-F_{nc}$)	87
6.4.1.3.	Basics Functions ($F_{nc} F$)	88
6.4.1.4.	Hold Functions ($HLd F$)	90
6.4.1.5.	Weighing Sequence Programs ($S^q F$)	90
6.4.1.6.	Flow Rate Functions ($F_r F$)	92
6.4.1.7.	Control I/O Functions ($io F$)	92
6.4.1.8.	Standard Serial Output Functions ($[L F]$)	94
6.4.1.9.	RS-485 Functions ($r5 F$)	94
7.	Specifications	95

Illustrations

Illustration 1	Weighing unit	6
Illustration 2	Display unit	7
Illustration 3	Adjusting the leveling foot	8
Illustration 4	Mounting the module	8
Illustration 5	Wiring the connector	9
Illustration 6	When using branch connector (alone use of the AD4212L)	10
Illustration 7	When using branch connector (multiple use of the AD4212L)	11
Illustration 8	Weighing unit wire names	29
Illustration 9	Weighing unit connection check	31
Illustration 10	External dimensions (display unit)	35
Illustration 11	External dimensions (weighing unit)	36
Illustration 12	State diagram	54
Illustration 13	Gravity acceleration graph	57
Illustration 14	Digital linearization	58

1. Introduction

This manual describes how the AD-4212L series Weigh Module works and how to get the most out of it in terms of performance.

Read this manual thoroughly before using the balance and keep it at hand for future reference.

1.1. Features

A Weighing Unit, suitable for building into a production line system. The weighing unit is compact, with a width of 30 mm.

Model	AD4212L-R50	AD4212L-R100
Maximum capacity	51 g	110 g
Minimum division	1 mg	1 mg
Stabilization time	0 g to 5 g Approx. 0.3 s	0 g to 5 g Approx. 0.3 s
(With optimal filter set, under good ambient conditions)	5 g to 51 g Approx. 1.0 s	5 g to 110 g Approx. 1.3 s
Weighing pan diameter	20.5 mm	
Weighing unit size/mass	30 × 165 × 56 mm (W×D×H)/Approx. 400 g	
Display unit size/mass	35.3 × 101.3 × 110 mm (W×D×H)/Approx. 200 g	
Cable dia./length/mass	4.5 mm/10 m/Approx. 350 g	
Power source	24 VDC +10%, -15%	
Operating conditions	-10 °C to +40 °C, 85%RH or less (no condensation)	

- Optimal digital filter setting example (Filter setting)

AD4212L-R50		AD4212L-R100	
Weighing range	Example (setting value)	Weighing range	Example (setting value)
0 g to 20 g	4.0 Hz (11)	0 g to 50 g	4.0 Hz (11)
20 g to 51 g	1.0 Hz (15)	50 g to 110 g	1.0 Hz (15)

The AD4212L series are a weigh module that amplifies signals from a load cell, converts them to digital data and outputs after converting them to a weighing values.

The AD4212L series have the following functions.

- RS-485

There are two kinds of communication modes (RS-485).

- Modbus RTU (RS-485 : 5)
- Interval output (RS-485 : 6, 7, 8)

This weigh module is used as a slave device of the Modbus RTU.

The output data format is the weighing display value with a sign.

- Remote I/O

The remote I/O is an I/O device with communication functions.

The control input status can be read from Modbus RTU coils.

Control output can be toggled on or off with Modbus RTU coils.

□ Digital filter

The digital filter is used to prevent electrical signal movement from the weighing unit. This module has two channels so that each cutoff frequency can be set separately.

Digital filter 1 (F_{nc05})

Digital filter 2 (F_{nc06})

□ Calibration using gravity acceleration correction

This function compensates for weighing error due to the difference of gravity acceleration between the location of calibration and the location of measurement.

□ Digital linearization

The digital linearization function can rectify and reduce deviation using weighing points at zero and maximum capacity. Up to four weighing points excluding the zero point can be specified. A high-order correction curve is used between each point.

□ Flow rate calculation function

Digital filter 2 is a low cutoff frequency filter that can calculate stable flow rates when an extreme change in mass has occurred. You can set the damping time, which moderates flow rate changes, and average the moving time of the flow rate.

Flow rate is calculated a thousand times per second at the same speed as A/D conversion. A hold function to hold flow rate values and the flow rate values with a slight error (unstable flow rate) can be monitored and controlled from the control I/O.

□ Batch weighing

Batch weighing is a procedure to automatically weigh up to the final value.

The weighing sequence which controls the valves (gates) and determines the weight is executed when the weighing start signal is sent to the input terminal.

2. Product Structure, Installation and Precautions

The weigh module is a precision instrument. Unpack the weigh module carefully. Keep the packing material to be used for transporting the weigh module in the future.




Illustration 1 Weighing unit

- #1 Use the three $\phi 4.4$ holes to attach the weighing unit with a tightening torque of approx. 1 Nm.
- #2 Use the two M2 holes to attach a jig to the pan with a depth of 5 mm and a tightening torque of 0.4 Nm or less.
- #3 When using the leveling foot, insert the three leveling feet into the three M4xP0.5 holes (narrow pitch).
- #4 Remove the two M2.6 screws when removing the pan. The tightening torque for installing is 0.4 Nm or less.
- #5 When dirt and dust accumulate in the gap between the pan and the wind shield, remove the pan and then remove dirt and dust.




Illustration 2 Display unit

Accessories	RS-485 connector (2 pieces) 35505-6200-A00 GF manufactured by 3M Branch connector (1 piece) 35715-L010-A00 AK manufactured by 3M Leveling foot (3 pieces)
-------------	---

2.1. Assembling and Adjusting

Refer to the precautions described in “2.2”, “2.3”, “2.4” and “2.5” for installing the weigh module.

□ Adjusting the leveling feet

When using the leveling feet, level the weighing unit by rotating the three leveling feet on the bottom of it as shown in the figure.




Illustration 3 Adjusting the leveling feet

□ Connection

Display unit




Illustration 4 Mounting the module

When connecting or removing the cable, push the connector button with a screwdriver, etc.




Illustration 5 Wiring the connector

Power Supply Connector

+24 V +24 VDC terminal

0 V 0 VDC terminal

FG (SHLD/SLD) Ground terminal

(All connector shields are connected internally with FG.)

POWER

	3	+24V
	2	0V
	1	FG

Sensor Terminals of Weighing Unit

	7	SIG-
	6	SIG+
	5	EXC-
	4	SEN-
	3	SEN+
	2	EXC+
	1	SHLD

SIG-	SIG+	EXC-	SEN-	SEN+	EXC+	SHLD
Blue	Green	White	Purple	Orange	Red	Yellow

Conductor Specifications


Clamp range (typ.)	0.13 mm ² to 1.5 mm ²
AWG	AWG24 — AWG16
Solder plated wire	0.2 mm ² to 1.5 mm ²
Twisted wire	0.2 mm ² to 1.5 mm ²
Rod crimp terminal	DIN 46228 Part1 0.25 mm ² to 1.5 mm ²
Rod crimp terminal with color	DIN 46228 Part4 0.25 mm ² to 0.75 mm ²
Lead length	8 mm

Specifications of conforming cable


Wire outside diameter	φ1.6 ~ 2.0 mm
Wire size	AWG#20 (0.5 mm ²)

Procedure for connecting the cable.


- Step 1** Do not strip the cable jacket.
Insert the cable all the way into the yellow cover.



- Step 2** Crimp the cover on the body using pliers from the side of the connector as shown in the illustration to the right.




- Step 3** Be sure the cover and the body are parallel to each other and there is no space between the body and the cover.



After crimping

Body (black part)
Cover (yellow part)



Before crimping

Using the branch connector

- When connecting a master device such as a PC or PLC to the RS-485 connector with the AD4212L (using a single AD4212L)




Illustration 6 When using a branch connector (using a single AD4212L)

- When connecting a master device such as a PC or PLC to the RS-485 connector with the multiple AD4212L units




Illustration 7 When using branch connectors (using multiple AD4212L)

Power Supply


⚠CAUTION

Ground the module to prevent electrical shock or display unit malfunction.
If the module is not grounded, it may cause an electrical shock, or malfunction due to static electricity.

- Before connecting the module to the power source, read the instruction manual thoroughly.
- Do not connect the module to the power source before the installation is complete.
- ⚠ □ To avoid electrical shock, do not handle the power cable with wet hands.
- ⚠ □ Ground the module. Do not share the ground line with other electrical power equipment.
- The power requirement is 24 DCV, +10% to -15%.
Use a stable power source free from instantaneous power failure or noise.
- To avoid malfunction, do not share the power line with other devices.
- The output voltage of a load cell is a very sensitive signal. Keep all electrical noise sources away from the weighing unit and weighing unit cable.
- Use shielded cables for input and output. Connect the cable shield to the F.G. terminal or the module housing.
- F.G. (frame ground) is internally connected to all connector shields (SHLD/SLD).

As long as the power cord is connected to the weigh module, the weigh module is always in standby mode. This is a normal state and does not harm the weigh module. For accurate weighing, connect the power cord to the weigh module and warm up the weigh module for the appropriate duration before use.


*** Power connection example**




Power reference specifications
 Output voltage: 24 V
 Output power: Output 6 W or more (per one AD4212L unit)

Weighing unit

The cable connector is detachable.
 Match the guides on the connectors and turn the ring to secure the cable connector.




- **Note**
 When connecting the cable, confirm that the display unit, the weighing unit and the cable have the same serial number. Otherwise, the display unit may not display the correct weighing value.




2.2. Precaution Before Use

- The weight module is a precision instrument. Handle it carefully.
- Install the weighing unit in an environment where the temperature is not excessive.
- Install the weight module where it is not exposed to direct sunlight.
- **Grounding the Module**
Ground the module to the DIN rail. Separate this earth ground line from others, such as ground lines for the motor, inverter or power source. Unless the indicator is grounded, it may result in electric shock, operation error or fire.
- **Proper Power Source and Power Cable**
Confirm the AC voltage, frequency and power tolerance of the power cable. If the voltage range of the cable is lower than the power line voltage, it may cause leakage or catch fire.
- **Fuse**
A fuse is installed to help prevent the module from catching fire. The module is equipped with many safety circuits, so if the internal circuits are functioning properly, the fuse is not damaged. If the fuse is damaged, it may have been caused by strong electric discharge. If the fuse blows out, please contact us or our dealer. The fuse in this unit cannot be replaced.
- **Splashing Water**
The module is not water resistant.
- **Flammable Gas**
Do not install the module where flammable gas is present.
- **Heat Radiation of the Module**
To prevent the module from overheating, leave sufficient space around the vent holes on the upper and bottom side of the display unit. Use a cooling fan to keep the operating temperature of the module within specifications.
Display unit is covered with a protective transparent-resin cover. After the installation is complete, take off the protective cover prior to turning on the display unit. Heat damage may be caused if you do not remove the protective cover.
The protective cover is for preventing wire chips when you will install and wire so please do not take off the cover until complete the installing and wiring.

Display unit with a protective cover



How to remove the protective cover



- Install the weighing unit where it is not affected by air conditioners.
- Connect the power cord to the weigh module before use and warm up the weigh module for at least 30 minutes (while the display unit is connected to the power supply).
- Calibrate the balance before use or after having moved it to another location.
In addition, calibrate it periodically to maintain the accuracy.

2.3. Precaution on Building Into a System

The AD-4212L is a precision device. When it is built into a system, errors such as unstable weight values may occur due to static electricity, vibration, sample temperature and magnetism of the materials weighed or used for the devices near the weigh module.

When using the weigh module as part of a system, take the following precautions:

● Precautions when not performing the weighing at the center of the weighing pan


If not performing the weighing at the center of the weighing pan, design the weighing system so that the total moment of the support device and the object to be weighed will be the value specified in the table below.

Allowable eccentric load for each model

Model	Allowable eccentric load
AD4212L-R50	0.015 Nm or less
AD4212L-R100	0.030 Nm or less


AD4212L-R50

Example of a system where the total moment of the device and the object is 0.015 Nm or less:



AD4212 L- R100

Example of a system where the total moment of the device and the object is 0.030 Nm or less:




Note: The values above are for reference and may be different from actual specifications.

Although the overload protection mechanism is built in, please avoid giving impact shock to the weighing pan while weighing.

Precaution on using the leveling foot


If the center of gravity of the weighing sample is outside the width range of the weighing unit, the weighing unit may tilt to one side even if the load is within the allowable moment, preventing proper weighing. In such a case, secure the base of the weighing unit with screws before use.

Position of the center of gravity of the weighing sample
(when outside the width range of the weighing unit)



● Errors due to airflow and measures to take

- Where the influence of ambient airflow is great such as: close to an air conditioner, door or passage way. Even very subtle airflow that is hard to be detected may influence the weighing operation.
 - Avoid those areas as a weighing site.
 - If weighing is to be performed in such an area, use a breeze break or take other appropriate measures.



● Errors due to vibration and measures to take

- Where the influence of vibration is great, such as:
 - (1) Soft ground
 - (2) Second or higher floor
 - (3) Near center of a floor far from pillars
 - (4) Seismic isolated structures
 - (5) Near tall buildings.In the areas listed above, the weighing unit may yield unstable weight values on windy days or after an earthquake. Especially in case of (4) and (5), weight values may be unstable for a long period of time because of long lasting low-frequency vibration after strong winds or an earthquake. Also, when connection cable between the weighing unit and display unit is subject to vibration, there are cases when the weighing values become unstable. Take action so that the vibration does not cause negative effects to the cable as well as the weighing unit.

● Errors due to other causes and measures to take

- Change in temperature or humidity

A sudden change in temperature or humidity can generate a draft and cause the weighing unit to absorb or exude moisture, which leads to unstable displays.

 - Avoid sudden change in temperature or humidity.
 - Use an air conditioner or humidifier to control the temperature or humidity.

2.4. During Use

- To minimize the affect by electrical noises, earth ground the weighing unit and the display unit.
- Do not drop things upon the weighing pan, or place a sample on the pan that is beyond the weighing capacity for weighing unit. Place a sample in the center of the weighing pan to minimize corner-load errors.
- To prevent possible errors, before each weighing, perform re-zero using the RS-232C command, or calculate the difference between the weight value before and after weighing.
- Even though the weighing unit is dust-protected and protected against splashing water, complying with IP65, be sure to clean the weighing pan and keep the conditions around the pan clean after weighing powdery, fluid samples or metallic strips.

2.5. After Use

- Avoid mechanical shock to the weighing unit. Do not drop the weighing unit.
- Periodically calibrate the weighing unit, using a calibration weight.
- Do not disassemble the weighing unit. Contact the local A&D dealer if the weigh module needs service or repair.
- Do not use organic solvents to clean the weighing unit. Clean the weighing unit with a lint free cloth.
- Avoid dust and water so that the weighing unit weighs correctly. Protect the internal parts from liquid spills and excessive dust.
- Use the original package box to transport the AD4212L.

Error Messages

If an error message is displayed, use the following countermeasures.

Error message	Cause	Countermeasure
$[5] E_r$	Program checksum error	Repair is required.
$A_d E_r$	Data cannot be acquired from the A/D converter.	Repair is required.
$F_r A E_r$	Correct data cannot be read from the nonvolatile memory (FRAM).	Initialize the module. If it cannot be resolved, repair is required.
$[E_r r$	Calibration data is incorrect.	Perform the calibration
$[E_r x$	Calibration error.	Refer to "3.2.2 Error Codes for Calibration ([E_r)". x: error number
$E_r r d t$	The setting value is out of range.	Check the setting value.

3. Basic Operation

This section describes the following operations:

- Changing the weighing speed (response characteristics) and using stability detection
- Calibration
- Changing the baud rate and slave address

3.1. Changing the Weighing Speed and Stability Detection

Changing the weighing speed

The weighing speed can be changed by setting digital filter 1 and 2 of basic function (Fnc F).

The AD4212L has two digital filters. The cutoff frequency setting range is different for each.


- Digital filter 1 ($Fnc\ 05$: None, 100.0Hz (high) to 0.7Hz (low))
- Digital filter 2 ($Fnc\ 06$: None, 100.0Hz (high) to 0.07Hz (low))




Setting cutoff frequency

The cutoff frequency is the frequency where the vibration starts to decline.


- If the weighing value is unstable, lower the cutoff frequency.
(Response rate is slow. Resistant to disturbance.)
- To make the response faster, higher the cutoff frequency.
(Response rate is fast. Susceptible to disturbance.)

It is possible to make adjustments while watching the effects of the digital filter.

Press the  key while setting values as shown in Step 4 in "6.2.7.1 Procedure to Store New Parameters" to check the weight displayed.

- The  key changes the cutoff frequency. You can check the setting value on the LED status indicator (binary number).
- The  key returns to the value setting display. (The setting value changed above using the  key will be displayed)

The digital filter flow chart is shown below.




The mass indicated on the display unit is the mass acquired by digital filter 1.
 The mass acquired by digital filter 2 is not indicated on the display unit.

Stability detection

The stability detection time and stability detection width of calibration function ($\bar{C}-F_{nc}$) can be changed.

Item Name	Function code	Description, Range and Default value
$\bar{C}-F_{08}$ Stability detection time	1008	Stability detection is performed using this setting in combination with the setting of $\bar{C}-F_{09}$. When $\bar{C}-F_{08}$ holds 0.0, stability detection will not be performed. (Stable all the time) Scale: 0.1 seconds. 0.0 to <input type="text" value="1.0"/> to 9.9
$\bar{C}-F_{09}$ Stability detection width	1009	Stability detection is performed using this setting in combination with the setting of $\bar{C}-F_{08}$. When $\bar{C}-F_{09}$ stores 0, stability detection will not be performed. (Stable all the time) Scale: 1 d (minimum div). 0 to <input type="text" value="2"/> to 100



Stability detection is performed using the mass value acquired by digital filter 1.

3.2. Calibrating the Display Unit

The weigh module measures the voltage of the load cell and displays it. Calibration corrects the signal from the load cell to convert it into mass correctly.

- ※Perform stable measurement during calibration to prevent measurement errors.
- ※During stable measurement, the **[S]** LED lights.
- ※The blinking decimal point means that the current value is not the weight value.
- ※When **[E Er]** with a number is displayed, it indicates that an error has occurred.
Refer to "3.2.2 Error Codes for Calibration (**[E Er]**)" for details.
- ※Before the calibration, allow the weigh module at least 30 minutes to warm up to avoid drift caused by changes in temperature.

3.2.1. Calibration Using a Weight (**[E -5Et]**)

Calibration is performed by loading and unloading a calibration weight.

- Step 1 Turn off the display by pressing and holding the **[ENT]** key. Then, while holding the **[F]** key, press the **[ENT]** key. **[E R]** will be displayed indicating calibration mode.
- Step 2 Press the **[ENT]** key to enter calibration mode. **[E -5Et]** is displayed. To return to weighing mode, press the **[ESC]** key.



Zero Calibration


- Step 3 Press the **[ENT]** key to display **[E R 0]**.
To skip zero calibration, press the **[↑]** key and proceed to Step 5.
- Step 4 Confirm that the **[S]** LED is lit, and then press the **[ENT]** key. Then **[.....]** is displayed for 2 seconds. To skip span calibration, press the **[ESC]** key twice to return to weighing mode.

Span Calibration

- Step 5 When **[E -5Pn]** is displayed, press the **[ENT]** key. The current calibration weight value is displayed with the rightmost digit flashing. Specify a new value using the **[→]** and **[↑]** keys. To skip span calibration, press the **[ESC]** key three times to return to weighing mode.
- Step 6 Place the weight on the weighing pan. Confirm that the **[S]** LED is lit and press the **[ENT]** key. Then **[.....]** is displayed for 2 seconds.
It is recommended to use a weight of 50g for AD4212L-R50, and 100g for AD4212L-R100. When using a weight other than the recommended one, use a weight with 1/2 or more of the maximum capacity.
- Step 7 When **[E -5nd]** is displayed, remove the weight from the weighing pan. To calibrate span again, press the **[↑]** key.
- Step 8 Press the **[ESC]** key. Then **[E -5Et]** is displayed and calibration data is stored in nonvolatile memory (FRAM) of the weigh module.
- Step 9 Press the **[ESC]** key to return to weighing mode.

Note

When the span calibration value is set to 100 g in Step 5, select the highest-order digit using the  key, and then make the status indicator LEDs light as shown below using the  key.



※The  LED lights when the display is stable.

3.2.2. Error Codes for Calibration ([Er])

When an error occurs during calibration, the error number is displayed. If calibration is finished without removing the error, the setting values will be restored to the state before calibration.

Calibration errors and remedies

Error No.	Description of cause	Treatment
[Er 1]	The display resolution (maximum capacity / minimum division) exceeds the specified value.	Make the minimum division greater or make the maximum capacity smaller. The specified value depends on specifications of the weighing system.
[Er 2]	The voltage at zero calibration is excessive in the positive direction.	It seems that the display unit is damaged. Contact us or your local A&D dealer.
[Er 3]	The voltage at zero calibration is excessive in the negative direction.	
[Er 4]	The value of the calibration weight exceeds the maximum capacity.	Use an appropriate calibration weight and calibrate again.
[Er 5]	The value of the calibration weight is less than the minimum division.	
[Er 6]	The weighing unit sensitivity is not sufficient.	Confirm the weight value.
[Er 7]	The voltage at span calibration is less than the voltage at the zero point.	Check the weighing unit connection.
[Er 8]	The weighing unit output voltage is too high when the mass of maximum capacity is weighed.	Confirm the weight value.

3.3. Changing the Baud Rate and Slave Address

Changing the baud rate

The baud rate can be changed by setting the baud rate of the RS-485 Function (r5 F).

Item Name	Function code	Description, Range and Default value	
r5 03 Baud rate	2103	5 : 9600 bps 6 : 19200 bps	7 : 38400 bps 8 : 115200 bps

Refer to “6.2.7.1 Procedure to Store New Parameters” for details.

Changing the slave address

The slave address is set to “1” at shipment. When using multiple AD4212L units, make sure that the same value is not set more than once.

Item Name	Function code	Description, Range and Default value	
r5 08 Slave address	2108	0 : None	1 to 99

Refer to “6.2.7.1 Procedure to Store New Parameters” for details.

3.3.1. Initializing Parameters

The initialization mode restores the parameters to the default values in the FRAM. Three types of initialization mode are available as shown below.

Initialization mode	Display	Description
RAM initialization	<input type="text" value="r 0"/>	RAM memory is initialized. The center of zero and tare value will be restored to 0.
General function initialization	<input type="text" value="r 1 F"/>	Data of the general functions stored in the FRAM and the RAM are reset to factory settings.
All data initialization	<input type="text" value="r 1 A"/>	All data stored in the FRAM, general functions and RAM are initialized. Data related to calibration is also initialized, so calibration must be performed again.

3.3.1.1. Initializing Mode for RAM and Function Parameters

Step 1 Press the key while holding the key (+) to display for general functions mode. To return to weighing mode, press the key.

Step 2 Press the key while holding the key (+) to display for check mode.

Step 3 Select initialization mode using the key. Press the key.

Step 4 Select an item to be initialized using the key. Press the key.

Step 5 Check that all LED status are blinking.
To perform the initialization, hold the key for 3 seconds or more.

After initialization, all segments will illuminate and return to weighing mode.
To cancel the initialization, press the **ESC** key to return to weighing mode.

3.3.1.2. Initializing All Data

Step 1 In OFF mode (Standby: While turning off the module), press **F** + **ENT** keys to display **CAL** for calibration mode.

To return to weighing mode, press the **ESC** key.

Step 2 Press the **ENT** key to enter into calibration mode.

Step 3 Press the **↑** key four times to select initialization all data mode and press the **ENT** key.

Step 4 Check that all LED status lights are blinking.

To initialize, hold the **ENT** key for 3 seconds or more.

After initialization, all segments illuminate and return to weighing mode.

To cancel the initialization, press the **ESC** key to return to weighing mode.

4. Communication Specification


The AD4212L enables bi-directional communication using the RS-485 interface. (If the RS-485 is set to interval output, only data from the AD4212L can be transmitted)

The AD4212L is set to Modbus RTU at shipment.

The RS-485 has two kinds of communication modes (r5 02).

- Modbus RTU (r5 02 = 5)
- Interval output (r5 02 = 6, 7, 8)

RS-485



Pin No.	Symbol	Description
5	SLD	Connected with FG ground terminal on the power supply connector.
4	RTRM	Terminating resistor (100 Ω) is connected to Pin 1. Enable the terminating resistor with short-circuited to Pin 2.
3	SG	Signal ground
2	DATA-	Minus side of the RS-485 communication line.
1	DATA+	Plus side of the RS-485 communication line.

Communication Specifications

Item	Data transfer mode (r5 02)	
	Modbus RTU	Interval output
Baud rate (r5 03)	r5 03 (9600, 19200, 38400, 115200 bps)	
Start bit length	1 bit	
Character bit length	Fixed 8 bits	
Parity (r5 04)	Fixed even number	r5 04
Stop bit length (r5 05)	Fixed 1 bit	r5 05
Terminator (r5 07)	Time	r5 07
Code	Binary	ASCII
Slave address (r5 08)	1 to 99 (0 : No address setting)	Not used

Modbus RTU

AD4212L is a slave device of the Modbus RTU. Refer to "6.3.5 Modbus RTU Data Address".

Interval output

Weighing display value is output periodically.

Communication mode	Interval output	Reference
6	10 millisecond output (100 times/second)	The output data format is common. Output data is weighing display value.
7	5 millisecond output (200 times/second)	
8	2 millisecond output (500 times/second)	

NOTE :100 times/second : Set the baud rate over 19200bps.

200 times/second : Set the baud rate over 38400bps.

500 times/second : Set the baud rate over 115200bps.

Data address

Weighing values

Data Address (Holding Register)	R/W	Item	Remarks
400001 - 400002	R	Displayed value (Digital filter 1)	
400003 - 400004		Gross value (Digital filter 1)	
400005 - 400006		Net value (Digital filter 1)	
400007 - 400008		Tare value	
400009 - 400010		Status indicator (Status LED)	#6
400043 - 400044		Displayed value (Digital filter 2)	
400045 - 400046		Gross value (Digital filter 2)	
400047 - 400048		Net value (Digital filter 2)	

#6 Bit address of status indicators (Data address : 400009 - 400010)

Data Address (Holding Register)	R/W	Item	Remarks
400009. 15-00	R	Reserved internally	0 fixed
400010. 15-07		Reserved internally	0 fixed
400010. 06		Z : Zero	LED to turn on = 1 LED to turn off = 0
400010. 05		S : Stable	
400010. 04		G : Gross	
400010. 03		N : Net	
400010. 02		H : Hold, Hold busy	
400010. 01		X : Basic function <small>기본기능</small>	
400010. 00		Reserved internally	0 fixed

5. Troubleshooting

The weigh module has check mode function for confirming operations.
When making inquiries, please inform us of the user settings.

5.1. Check Mode

The check mode can be used to check the performance of the display, key switches and external I/O.

5.1.1. Entering Check Mode

Step 1 Press the **[F]** key while holding the **[ENT]** key (**[ENT]** + **[F]**) to display **[Fnc]**.
To return to weighing mode, press the **[ESC]** key.


Step 2 Press the **[ENT]** key while holding the **[→]** key (**[→]** + **[ENT]**) to display **[CHc]** in check mode. Press the **[ENT]** key to display the check item.

Step 3 Select the checked item using the **[↑]** key. Press the **[ENT]** key to enter it.
Press the **[ESC]** key to exit.

Display symbol	Item
[HPEY]	Key check
[H io]	Control I/O check
[H CL]	Standard serial output check
[H rS]	RS-485 check
[H Ad]	A/D converter output check (weighing unit check)
[H in]	Internal count check
[HPr9]	Program version
[H Sn]	Serial number
[SPr9]	Program checksum
[SFrA]	Memory checksum
[F dt]	[-Fnc] check ([-F01] to [-F2B])


5.1.2. Verifying the Switch Operation

When pressing the key, the corresponding segment moves. "0" & "8".
To stop the current check mode, press the **ESC** key twice.



5.1.3. Checking the Control I/O

When pressing the **↑** key when the terminal number of the control I/O is displayed, the output turns on sequentially (*out* is all OFF).
When turning on the input of the control I/O, the LED illuminates.



5.1.4. Checking the Standard Serial Output

Test data "ST, GS, +00000.0kg<CR><LF>" is output using a preset baud rate every time the **ENT** key is pressed.


5.1.5. Checking the RS-485 Output

Test data "ST, GS, +00000.0kg<CR><LF>" is output using a preset baud rate, parity and stop bit length every time the **ENT** key is pressed.

When "Figure data with a sign <CR><LF>" is output, the data is displayed.

- For numbers with a decimal point, the figure before the decimal point is output.
For instance of 123.4, only 123 is displayed.

Example 1: "ST, GS, +0001357kg<CR><LF>"



Example 2: "+54321<CR><LF>"




Example 3: There is no figure. "ABC<CR><LF>"



5.1.6. Monitoring the A/D Converter (for Load Cell Output)


The voltage output rate of the weighing unit is displayed in units of mV/V.



Example: When the internal count is 1.2345 mV/V and the output rate is above ± 7 mV/V, a weighing unit damage or connection error may occur. Refer to "5.3 Verifying Weighing Unit Connections Using Multimeter".

5.1.7. Monitoring the Internal Value

The current internal count (10 times of weighing value) is displayed.
When the internal count is 123, the example display is as follows:




5.1.8. Monitoring the Program Version

The program version is displayed.
Example: Version 1.00 is as follows:



5.1.9. Monitoring the Serial Number

The last five digits of the serial number is displayed.




5.1.10. Monitoring the Checksum of the Program

The checksum of the program is displayed.
Example: Checksum is EF.



5.1.11. Monitoring the Checksum of an Internal FRAM

The checksum of FRAM is displayed. Memory of the general function is not checked.
Example: Checksum is EF.



5.1.12. Displaying Function Parameters for the Calibration (C-F01~28)

The calibration function can be displayed.

5.2. Verifying Weighing Unit Connections (DIAGNOS)

5.2.1. Guideline to Verify Weighing Unit Connections

Faulty wiring or disconnection of the weighing unit can be checked using the display unit. This verification is useful for new settings, pre-measurement inspections and periodic inspections.

No.	Diagnostic item	Diagnostic point	Judgment Criteria (General)
1	Weighing unit input voltage	Between SEN+ ↔ SEN-	3 V or more
2	SEN+ voltage	Between SEN+ ↔ AGND	4 V or more
3	SEN- voltage	Between SEN- ↔ AGND	1 V or less
4	Weighing unit output voltage	Between SIG+ ↔ SIG-	Within ±35 mV
5	Weighing unit output rate	Between SIG+ ↔ SIG-	Within ±7 mV/V
6	SIG+ voltage	Between SIG+ ↔ AGND	1 V to 4 V
7	SIG- voltage	Between SIG- ↔ AGND	1 V to 4 V
8	Internal temperature		-20 °C to +60 °C

AGND : Internal analog circuit ground SHLD : Shield. Frame ground.
 EXC- : Weighing unit excitation voltage (-) SEN- : Sensing input (-)
 EXC+ : Weighing unit excitation voltage (+) SEN+ : Sensing input (+)
 SIG- : Weighing unit output (-)
 SIG+ : Weighing unit output (+)




Illustration 8 Weighing unit wire names

5.2.2. Verifying Weighing Unit Connections with Switch Operation

- Step 1** Press the **[F]** key while holding the **[ENT]** key (**[ENT]** + **[F]**) to display **[Fnc]**.
 To return to weighing mode, press the **[ESC]** key.
- Step 2** Press the **[ENT]** key while holding the **[→]** key (**[→]** + **[ENT]**) to display check mode **[Chc]**.
- Step 3** Press the **[↑]** key twice to select weighing unit connections diagnosis **[d,AG]** and then press the **[ENT]** key to enter it. Each item is automatically diagnosed. After approx. 16 seconds, the diagnosis is displayed. Also, each diagnosis is checked by selecting items pressing the **[↑]** key.
 Press the **[ESC]** key to return to the display **[d,AG]**.

5.2.3. Verifying Using the RS-485

Switch to Modbus RTU (5) for the Communication mode (r5 02) and write commands to the coils so that the diagnosis is started.

Step 1 Write "1" to the self-check start (Data Address 000403) coil.
d ,RG is displayed and each item is automatically diagnosed.
During the self-checking, the "During an internal write cycle / Write result" holding register is "15".

Step 2 After approx.16 seconds, the diagnosis is displayed, then the result is output to the "During an internal write cycle / Write result" holding register.
"During an internal write cycle / Write result" holding register = 0 : No error
1 : Error
When an error occurs, the details are output to "error code" and "error sub code" holding registers.
Refer to "6.3.1.2 Error Code of the Modbus RTU (Data Address : 400065 - 400068)" for more details.

Step 3 Write "1" to the "self-check stop" (Data Address 000404) coil and the diagnosis is finished.

- During the diagnosis from Step 1 to Step 3, weighing mode stops. So, the parameters of the holding register about the weighing (mass) and the parameters of the coil about the status display will be unstable.
Reading and writing of the holding register related to functions can be performed normally.

5.2.4. Verifying Using Control I/O

Step 1 When the input terminal of the control I/O is set to "diagnose" and remains "ON" for 1 second or more, the display shows d ,RG and checks each item automatically.
After approx. 16 seconds, the diagnosis is displayed.

□ When the control I/O is set to "OFF", the diagnosis ends. Keep "ON" until the diagnosis is displayed.

Step 2 Turn off the input terminal of the control I/O set to "diagnose" and display unit returns to weighing mode.

5.2.5. Display and Output of Verification

Items that have not been diagnosed are also totaled as errors. Refer to "5.2.1 Guideline to Verify Weighing Unit Connections" concerning the detail of the diagnosis point and judgment criteria.

When scanning and changing items, d ,RG is displayed.

The diagnostic results of the scanning are displayed as follows:

There are no errors: 0000

There is an error: ErXXX (a code XXX in which error codes are accumulated.)

When more than one error occurs, the total value of the error codes is displayed.

Ex. When errors are weighing unit excitation voltage (No.1) and Internal temperature (No.8):

1 + 128 = 129 129 is the error code of XXX

No.	Check item	Status LED G N H S Z X	Display Range	Error Code
1	Weighing unit excitation voltage	● ● ● ● ● ●	0.001 V	1
2	SEN+ voltage	● ● ● ● ● ●	0.001 V	2
3	SEN- voltage	● ● ● ● ● ●	0.001 V	4
4	Weighing unit output voltage	● ● ● ● ● ●	0.001 mV	8
5	Weighing unit output rate	● ● ● ● ● ●	0.0001 mV/V	16
6	SIG+ voltage	● ● ● ● ● ●	0.001 V	32
7	SIG- voltage	● ● ● ● ● ●	0.001 V	64
8	Internal temperature	● ● ● ● ● ●	0.1 °C	128

● : Lit, ○ : Not lit

5.3. Verifying Weighing Unit Connections Using Multimeter

The weighing unit connection can be checked easily using a digital multimeter. The measurement points of the weighing unit connection are shown below:




Illustration 9 Weighing unit connection check

5.3.1. Check List for Weighing Unit Connections

Measurement points	Description	Conditions
EXC+ SEN+	Drop voltage of cable on EXC+ side.	Normally it is 100 mV or less. However, it may exceed 1V when an extremely long weighing unit cable is used.
EXC+ EXC-	Input voltage	Normal range is between 4.75 V to 5.25 V.
SEN- EXC-	Drop voltage of cable on EXC- side.	Normally it is 100 mV or less. However, it may exceed 1V when an extremely long weighing unit cable is used.
SIG- EXC-	Center point voltage	Approximately 2.5 V, about a half of excitation voltage.
SIG+ SIG-	Output voltage	Generally, it is within 0 V to 15 mV. The theoretical value is calculated from the weighing unit rated capacity, actual load and excitation voltage.

When the weigh module cannot be operated properly, write the required items in the table below and contact us or your local A&D dealer.

Model name AD4212L-R50
 AD4212L-R100

Measurement points		Measurement contents	Measurement result
EXC+	SEN+	Drop voltage of cable on EXC+ side.	[mV]
EXC+	EXC-	Input voltage	[V]
SEN-	EXC-	Drop voltage of cable on EXC- side.	[mV]
SIG-	EXC-	Center point voltage	[V]
SIG+	SIG-	Output voltage	[mV]

6. Display Unit Detailed Descriptions

6.1. Specifications

6.1.1. Digital Parts (Display and Keys)

Display element	Measurement display	5-digit 7-segment red LED 5.3 mm Character height, 1-digit red LED for negative polarity
	Status indicators	6 red LEDs
Measurement display	Numerical display	Switches between NET and GROSS
	Decimal point	Selectable decimal places (10 ¹ , 10 ² , 10 ³ , 10 ⁴)
	Overflow display	All the digits turn OFF. (When the polarity is negative, the minus sign LED appears at the highest-order digit.)
Status indicators	G : GROSS, N : NET, H : HOLD / HOLD BUSY, S : STABLE, Z : ZERO, X : Preset function selected at F_{NC04} in the basic function.	
Key switches	F/ESC , → (ZERO), ↑ (TARE), ENT	

6.1.2. General

6.1.2.1. Interface

Interface	Specification	Connector
RS-485	Refer to "6.3.1 RS-485"	Power clamp connector (3M)
Control I/O	Refer to "6.3.2 Control I/O"	MDR connector 20 pins female Connector is not included
Standard serial output	Refer to "6.3.3 Standard Serial Output (Current Loop)"	
USB	USB 2.0 (High-speed)	Micro-B Cable is not included

6.1.2.2. Weighing Functions

Zero operation	<p>Set the gross weight to zero by pressing the →(ZERO) key.</p> <p>Disable or enable operation when unstable.</p> <p>Zero value is stored in nonvolatile memory.</p> <p>Zero adjustable range: Can be set optionally in the range of 1 to 100% of the maximum capacity.</p> <p>The LED on Z will illuminate when the weighing value is within the center-zero range.</p>
Zero tracking	<p>Tracks the weight drift around the zero point to maintain zero.</p> <p>Zero tracking time: 0.0 to 5.0 second Can be set optionally within the range</p> <p>Zero tracking band: 0.0 to 9.9 d Can be set optionally within the range</p>
Tare	<p>Set the net weight to zero by pressing the ↑(TARE) key. The tare function can be toggled on/off when the weighing value is unstable and negative. The tare value is stored in nonvolatile memory (FRAM).</p> <p>Tare range: Gross weight \leq Maximum capacity</p>
Stability detection	<p>Turns ON the stabilization indicator S when the variation amount of the weight value per sampling is within the set band in the set time.</p> <p>Detection time: 0.0 to 9.9 seconds Can be set optionally within the range</p> <p>Detection band: 0 to 9 d Can be set optionally within the range</p>
Digital filter 1	Cutoff frequency (-3 dB) range: 0.7 to 100 Hz
Digital filter 2	Cutoff frequency (-3 dB) range: 0.07 to 100 Hz
Near-zero detection	Detects whether there is a load or not and outputs the result as near zero.
Upper or lower limit detection	Compares the measurement with HI/OK/LO limits and outputs the results.
Hold function	<p>Displays the measurement value held.</p> <p>Select from normal hold, peak hold, and average hold.</p>
Flow rate calculation	Calculate mass change value per unit time.

6.2. Operations

6.2.1. General Functions

6.2.1.1. Zero Operation

- The zero operation sets the gross weight to zero. It is performed by pressing the **→(ZERO)** key.
- The zero range is set in **[-F05]** (Zero range) and is expressed as a percent of the maximum capacity with the calibration zero point as the center.
- When A/D converter overflow occurs, zero operation is disabled, even within the zero range.
- A ZERO error is output if zero operation is not performed because the value is unstable or out of range.
- The zero value is stored in the non-volatile memory and is saved even if the power is disconnected.
- Clear the zero value with the **[F]** key assigned to clear the zero value.
- **Functions Related to Zero Operation**
 - **[-F05]** (Zero range): Values between 0% and 100% can be specified.
 - **[-F10]** (Tare and zero when unstable): Enable or disable tare and zero operation when unstable.
0: Disable both functions 1: Enable both functions
 - **[-F16]** (Zero when power is turned on): Choose whether or not to perform zero when power is turned on.
0: Disable 1: Enable

6.2.1.2. Zero Tracking

- The zero tracking function tracks the gross weight drift around the zero point to maintain zero.
- The zero tracking time is set in **[-F06]** (Zero tracking time) and the zero tracking band is set in **[-F07]** (Zero tracking band). When the gross weight drift is within the specified range, zero tracking is performed automatically.
- A ZERO error is not output even if zero tracking is not performed.
- **Functions Related to Zero Tracking**
 - **[-F06]** (Zero tracking time): Values between 0.0 and 5.0 seconds can be specified.
 - **[-F07]** (Zero tracking band): Values between 0.0 and 9.9 d can be specified.
(d = minimum division)
Zero tracking does not function when either of the settings is 0.0.

6.2.1.3. Tare Function

- The tare function stores the gross weight as a tare value and sets the net weight to zero. It is performed by pressing the **↑(TARE)** key.
- The tare value is stored in the non-volatile memory and is saved even if the power is disconnected.
- Clear the tare value with the **[F]** key assigned to clear the tare value.
- **Functions Related to the Tare Function**
 - **[-F10]** (Tare and zero when unstable): Enable or disable tare and zero operation when unstable.
0: Disable both functions 1: Enable both functions
 - **[-F11]** (Tare when the gross weight is negative): Enable or disable tare when the gross weight is negative.
0: Disable tare 1: Enable tare

6.2.1.4. Clearing the Tare Value and Zero Operation

To clear the tare value and zero operation, hold the \uparrow (TARE) key and turn on the module. Or: In off mode, hold the \uparrow (TARE) key and press the ENT key.

6.2.1.5. Customizing the Functions of the F Key

Assign a function to the F key from the functions of Fnc02 (F key) below:

- 0 : None
 - 1 : Manual print command
 - 2 : Hold
 - 3 : Operation switch 1
 - 4 : Operation switch 2
 - 5 : Display exchange
 - 6 : Tare clear
 - 7 : Zero clear
 - 8 : Weighing start / Pause / Restart
 - 9 : Actual free fall input
 - 10 : One shot, Small flow
 - 11 : Sequence flow rate monitor
 - 12 : mV/V monitor
 - 13 : Digital filter 2
- The factory setting is 5

- [-F 15 (Clear the zero value): Enable or disable clearing of the zero value.
0: Disable 1: Enable

Operation switch 1 and 2

By assigning the F key to the operation switches, manual input is possible. The output is from the control output (34: Output operation switch is on or off). To ensure that the operation switch is ON or OFF, the status indicator X, a red LED, is assigned to the operation switch status.

These switches work as follows:

Operation switch 1:

Press and release the switch once to save to turn ON or OFF.
Press the switch again to turn it OFF or ON.

Operation switch 2:

While the switch is being pressed, the switch is ON. When it is released, it is OFF.

Additional monitor

The decimal point of other data flashes to separate from weighing data, both LEDs of G: gross and N: Net are illuminated. When pressing the F key again, the AD4212L returns to weighing mode.

mV/V : Output voltage of load cell in the unit of mV/V.

Digital filter 2 : Response of weighing data by digital filter 2

6.2.1.6. Customizing the Function of the x Display

Assign a function to the x display (a red LED) from the functions of F_{nc04} (x display) below:

- 0: None
- 1: Zero tracking in progress
- 2: Alarm (Zero range setting error, over, failure tare calculation)
- 3: Display operation switch status as on or off
- 4: Near-zero
- 5: HI output
- 6: OK output
- 7: LO output
- 8: Large flow
- 9: Medium flow
- 10: Small flow
- 11: Over
- 12: OK
- 13: Under
- 14: Full
- 15: Weighing sequence end
- 16: In weighing sequence
- 17: Weighing sequence error
- 18: Normal batch/Loss-in-weight, Identification
- 19to24: State of Coil IN 1 to 6
- 25to32: Setting of Coil OUT 1 to 8

6.2.1.7. Memory Backup

- Zero value, tare value, display status, calibration data and function data are written into non-volatile memory. The data retention period is more than 10 years. This module is not equipped with a battery.

6.2.1.8. Near-Zero Detection

- Near-zero detects whether an object has been placed on the weighing pan. The near-zero state is defined when the weighing value is within the preset value for the near-zero range.
- **Related functions**
 - F_{nc08} (Near-zero): The value of near-zero.
 - F_{nc09} (Near-zero comparison weight): Selection of the gross weight or net weight to compare the value of near-zero.
 - 1: Gross weight 2: Net weight

6.2.1.9. Upper or Lower Limit Detection Function

- This function detects whether the weighed value is above an upper limit value or below a lower limit value.
- **Related Functions**
 - Comparative upper or lower limit values can be set with $F_{nc\ 10}$ (Upper limit value) or $F_{nc\ 11}$ (Lower limit value).

Result of Detection	Required value
HI	Weighing value > Upper limit value
OK	Upper limit value \geq Weighing value \geq Lower limit value
LO	Lower limit value > Weighing value

- $F_{nc\ 12}$ (Comparison mass of upper and lower limit): Select value to be compared with the upper or lower limit from gross weight or net weight.
 1: Gross weight 2: Net weight

6.2.1.10. Full Value Detection Function

The full value detection function detects that a weighing value has reached the maximum value.

- **Functions Related to the Detection Function**
 - $F_{nc\ 13}$ (Full): The comparative value of the full value can be preset.
 For information on detection conditions, refer to "6.2.7.1 Procedure to Store New Parameters".

6.2.1.11. Digital Filter 1 and 2 (F_{nc05} and F_{nc06})

The AD4212L has two digital filters. The cutoff frequency setting range is different for each.


- Digital filter 1 (F_{nc05} : None, 100.0Hz (high) to 0.7Hz (low))
- Digital filter 2 (F_{nc06} : None, 100.0Hz (high) to 0.07Hz (low))




Setting cutoff frequency

The cutoff frequency is the frequency where the vibration starts to decline.


- If the weighing value is unstable, lower the cutoff frequency.
 (Response rate is slow. Resistant to disturbance.)
- To make the response faster, higher the cutoff frequency.
 (Response rate is fast. Susceptible to disturbance.)

It is possible to make adjustments while watching the effects of the digital filter.

Press the  key while setting values as shown in Step 4 in "6.2.7.1 Procedure to Store New Parameters" to check the weight displayed.

- The  key changes the cutoff frequency. You can check the setting value on the LED status indicator (binary number).
- The  key returns to the value setting display. (The setting value changed above using the  key will be displayed)

The digital filter flow chart is shown below.



6.2.1.12. Hold Functions

Hold functions are selected from the hold operations in $Fnc07$.

- **Normal hold**

The normal hold function saves the value displayed at the time the hold command was received.

- **Peak hold**

The peak hold function saves the maximum value reached after the hold command was received.

- **Averaging hold**

The averaging hold function averages weighing data over a certain period of time and then saves the result.

Hold operations are controlled by the following.

- **F** key : $Fnc02$ (**F** key function) 2
- Control input : $in 01 \sim in 06$ (hold) 9
- Modbus RTU : Coil
- Above near-zero and stable : $HLd03$ (Automatic start condition) 1
- Above near-zero : $HLd03$ (Automatic start condition) 2

The hold is released by the following.

- **F** key : $Fnc02$ (**F** key function) 2
- Control input : $in 01 \sim in 06$ (hold) 9
- Modbus RTU : Coil
- $HLd04, HLd05, HLd06, HLd07$: Release the hold by each function required.

Hold functions are shown below.

Operating conditions		Hold operation (Fnc07)		
		Normal hold	Peak hold	Averaging hold
Average time	HL d01	Not available	Not available	Available
Start wait time	HL d02	Not available	Available	Available
Automatic start condition	HL d03	Not available	Available *4	Available *4
Release using control input	HL d04	Not available	Available	Available
Release time	HL d05	Not available	Available	Available
Release using fluctuation range	HL d06	Not available	Available *2	Available *3
Release at near-zero	HL d07	Not available	Available *1	Available


The weighing value held is the weight that is displayed on the main display.

The gross, net, stable/unstable, and upper/lower limit detection result (HI / OK / LO) are also held. Near-zero is not held.

The weighing value held is output from the standard serial output and the RS-485.

- *1 : When the function is set to release at near zero, peak hold does not work at the near zero.
- *2 : In case of a peak hold, only a negative variation can be released.
- *3 : The basic value is the weighing value when the average time is started.
- *4 : When hold is initiated by automatic start, it can be released either when the F key is pressed or hold is input from the control input.

Peak hold




T1 : Time set for the start wait time in *HL d02*. Scale: 0.01 second Range 0.00 to 9.99 seconds

*1 : Each additional hold input resets the start wait time.

*2 : When the hold value is updated, the hold (output) and the hold busy signals turn on and off.

(The hold busy variation depends on the change of the mass value).

Averaging hold



T1 : Time set for the start wait time in *HL d02*. Scale: 0.01 second Range 0.00 to 9.99 seconds

T2 : Time set for the averaging time in *HL d01*. Scale: 0.01 second Range 0.00 to 9.99 seconds

*1 : Each additional hold input resets the start wait time.

Illustration 2 Peak hold / Averaging hold

6.2.2. Flow Rate

Flow rate is the movement of mass over time.

Weighing unit has two digital filters so that two flow rates can be output.

- Functions Related to flow rate
 - $F_r 01$ (Filter of flow rate 1)
 - $F_r 02$ (Filter of flow rate 2)
- 1: Digital filter 1 2: Digital filter 2

In addition to the digital filters, a damping time can be set to suppress unstable flow rates.


This can be set with the damping time setting which is a moving average time of the weighing values.

Ex. Damping time is 5 seconds: moving average is 5 seconds

Damping time settings can be set for flow rate 1 and flow rate 2 individually.

- Functions related to the flow rate
 - $F_r 03$ (Damping time for flow rate 1)
 - $F_r 04$ (Damping time for flow rate 2) Range: 1 to 1000 seconds
- Confirming with control input / output
 - Control input
 - Prohibits update of flow rate : Holds the flow rate value.
 - Initializes flow rate : Deletes the data used for calculating the flow rate value.
 - Control output
 - Approximate flow rate value : Indicates the flow rate value is not calculated correctly.
 - Initialization causes uncertainty for a certain period of time.

The following is a flow-chart of flow rate calculation after digital filtering.



6.2.3. Batch Weighing

Batch weighing is a procedure to automatically weigh up to the final value.

Select a weighing mode (59 07) from the following:

- 0 : Disable
- 1 : Normal batch sequence
- 2 : Loss-in-weight sequence
- 3 : Specifying with control input
- 4 : Specifying with Modbus RTU

■ Feeding process

1. Input the weighing start signal.
 2. When the weighing start input delay time (59 22) has passed, the large flow, medium flow and small flow outputs turn ON.
 3. When the large flow comparison disable time (59 23) has passed, the large flow output turns OFF under the large flow off output conditions.
 4. When the medium flow comparison disable time (59 24) has passed, the medium flow output turns OFF under the medium flow off output conditions.
 5. When the small flow comparison disable time (59 25) has passed, the small flow output turns OFF under the small flow off output conditions.
 6. When the judging delay time (59 26) has passed and the net value is stable (59 12), the net value is judged.
 7. The weighing end output turns ON and the OK / Over / Under output of the judgment result turns ON.
 8. When the weighing end output time (59 27) has passed, the weighing end output turns OFF and the OK / Over / Under output of the judgment result turns OFF.
- The OK / Over / Under output can be always output by setting the OK / Over / Under output timing (59 11).

■ Weighing start / pause / restart / emergency stop.

When restarted from the pause, the weighing starts with one flow below the previous flow.

Relation between inputs and outputs (Example : with the large flow to turn on)


Start and stop command		Large flow	Medium flow	Small flow	Weighing end	Weighing error	Ref.
Weighing start		ON	ON	ON	OFF	OFF	
Pause during flowing		OFF	OFF	OFF	OFF	ON	
Restart from pause	First	OFF	ON	ON	OFF	OFF	
	Second	OFF	OFF	ON	OFF	OFF	
	Third or later	OFF	OFF	ON	OFF	OFF	
Restart from emergency stop	First	OFF	ON	ON	OFF	OFF	
	Second	OFF	OFF	ON	OFF	OFF	
	Third or later	OFF	OFF	ON	OFF	OFF	
Emergency stop during flowing		OFF	OFF	OFF	OFF	ON	
Stop after comparison (Normally finished)		OFF	OFF	OFF	ON	OFF	

- Weighing end means weighing sequence end.
- Weighing error means weighing sequence error.

6.2.3.1. Sequential Weighing


■ Normal batch sequence

Output terminal	Output conditions	Reference
Near-zero	Gross \leq Near-zero	Comparison weight can be changed to net weight with F_{nc09}
Full	Gross \geq Full	
Large flow off	Net \geq Final value - Optional preliminary	
Medium flow off	Net \geq Final value - Preliminary	
Small flow off	Net \geq Final value - Free fall	
Over	Net > Final value + Over	
OK	Final value + Over \geq Net \geq Final value - Under	
Under	Net < Final value - Under	



■ Loss-in-weight sequence

Output terminal	Output conditions	Reference
Near-zero	Gross \leq Near-zero	Comparison weight can be changed to net weight with F_{nc09}
Full	Gross \geq Full	
Large flow off	-Net \geq Final value - Optional preliminary	
Medium flow off	-Net \geq Final value - Preliminary	
Small flow off	-Net \geq Final value - Free fall	
Over	-Net > Final value + Over	
OK	Final value + Over \geq -Net \geq Final value - Under	
Under	-Net < Final value - Under	



6.2.3.2. Weighing Sequence Error (Output)

A weighing sequence error will occur in the following conditions.

- Weighing start has been input when: Gross + Final value \geq Weighing capacity.
- Weighing start has been input when it is over capacity including negative over capacity.
- The tare fails when tare condition (tare when unstable ($\bar{L}-F \ 10$) and tare when the gross weight is negative ($\bar{L}-F \ 11$)) have been selected and automatic tare at weighing start ($59 \ 13$) has been enabled (1).
- When the time in weighing sequence reaches the flow timeout time.
- When pause has been input during the weighing sequence.
- When an emergency stop has been input during the weighing sequence.

6.2.3.3. Error Reset (Input)

- When the error reset is input, the weighing sequence error output turns OFF.
- When the error reset is input during in weighing sequence, the weighing sequence will be initialized.

The initialization of the weighing sequence turns OFF all the outputs that are related to weighing sequence such as follows.

Large, medium and small flow output

OK / over / under output

In weighing sequence output

Weighing end output

Weighing sequence error output

6.2.3.4. One Shot Small Flow (Input)

When the one shot small flow is input, the small flow output turns ON for the duration that is set for the one-shot time for small flow rate ($59 \ 28$).

The small flow output time will be extended if the one shot small flow is input again while the small flow output has been on.

Example: $59 \ 28 = 2.00$ seconds and one-shot small flow is input three times repeatedly.

The small flow is output 2.00 seconds \times 3 times = 6.00 seconds

The one shot small flow is available during "in weighing sequence".

6.2.3.5. Full Open (Output)

When full open is input while weighing sequence is not active, the large, medium and small flow output is on.

By level input, the large, medium and small flow output remains ON while the full open is input.

6.2.3.6. Actual Free Fall Input

It updates the parameters of $59 \ 02$ (Free fall) and $59 \ 10$ (Free fall coefficient) using the latest weighing results. "Active free fall compensation (Updated coefficient)(3)" of $59 \ 08$ (Automatic free fall compensation) is not updated. It is used when adjusting the weigh module and changing weighing materials.

6.2.3.7. Automatic Free Fall Compensation

The automatic free fall compensation function reduces weighing errors during batch weighing. The weighing value may increase between closing the dribble gate and finishing weighing of a hopper scale and etc. This increased value is called "free fall". To minimize weighing errors, a free fall parameter and a real free fall value should be the same. As a way to do so, there is the "moving average of the last four real free fall", with which the next free fall setting is updated automatically.

The formula of batch error and real free fall are as follows:

Batch error = Net value when the batch is finished – Preliminary

Real free fall = Net value when the batch is finished – Net value when the dribble flow gate is OFF

When the weighing value passes Preliminary – Final value, the dribble flow gate is off.

When a batch error exceeds the effective range of the automatic free fall, the batch weighing is regarded as an error and excluded from the "moving average of the last four real free fall".

6.2.3.8. Active Free Fall Compensation

The active free fall compensation function modifies the free fall compensation in relation to the velocity passing through the gate (flow rate).

Example: When discharging a liquid (water, oil) in the hopper, the flow rate decreases as the remaining amount becomes smaller. In this case, the weighing results always become too small with the conventional free fall compensation. The same problem occurs with materials like honey with a viscosity that changes according to temperature.

Free fall coefficient = Actual free fall / Flow rate (when the dribble flow gate is OFF)

Free fall = Free fall coefficient x Flow rate

When "Active free fall compensation (fixed coefficient) (2)" is set to 59 08 (Automatic free fall compensation), the free fall is calculated with the parameter of 59 10 (Active free fall coefficient). When "Active free fall compensation (updated coefficient) (3)" is set to 59 08, the free fall is calculated with the average of the last four weighing values. When a batch error exceeds an effective range of the automatic free fall, the batch weighing is regarded as an error and excluded from the "moving average of the last four real free fall".

6.2.3.9. Sequence Numbers

The status of batch weighing can be checked from the holding register of the Modbus RTU.

Sequence number	Description
0	Waiting for the weighing start input.
1	Automatic tare
2	Confirming the start condition.
3	During the weighing start input delay, the large, medium and small flow turn ON after checking.
4	Waiting for the large flow comparison disable time.
5	During the large flow, turns OFF the large flow under the large flow off output conditions.
6	Waiting for the medium flow comparison disable time.
7	During the medium flow, turns OFF the medium flow under the medium flow off output conditions.
8	Waiting for the small flow comparison disable time.
9	During the small flow, turns OFF the small flow under the small flow off output conditions.
10	Waiting for the judging delay
11	Wait for the stable weighing value.
12	The comparison result is output. Weighing end is output.

6.2.4. Remote I/O


The remote I/O is an I/O device with communication functions and use the RS-485 Modbus RTU interface. The I/O device uses the control input and output terminals.

The remote I/O function uses the Modbus RTU to perform "status monitor" and "setting control output on and off".

□ Diagram

The diagram shows a configuration of one each of input and output terminals.

All the input terminals (IN1 to IN6) and the output terminals (OUT1 to OUT8) have the same structure.



□ Related functions

Function of OUT1 (α 11) to OUT8 (α 18) : Remote I/O	37
Present function X (Fnc 04) :	
State of memory map coil IN1 to IN6	19 to 24
Setting of memory map coil OUT1 to OUT8	25 to 32

6.2.5. State Diagram and Operation Switches

6.2.5.1. State Diagram

The nonvolatile memory always stores either OFF mode or other mode. It starts from the following state depending on the mode that has been kept when the automatic power is on.

- OFF mode (standby) : Starts from OFF mode.
- Other mode : Starts from Weighing mode.

State diagram can be switched as follows.




Illustration 12 State diagram

6.2.6. Calibration

In calibration mode, operations relating the load cell output voltage to the weighing value can be performed as well as operations directly related to weighing.

Calibrating with a weight	<p>Calibration is performed using a calibration weight.</p> <ul style="list-style-type: none"> ■ Zero calibration: Press ENT key when no load is applied. ■ Span calibration: Enter the calibration weight value and load the calibration weight. <p>When the module enters calibration mode using an actual load, the tare value and the zero value will be automatically cleared.</p>
Digital span	<p>Calibration is performed without an actual load by the numerical input of the load cell output voltage (mV/V). Set the values in the calibration function.</p> <ul style="list-style-type: none"> ■ Zero input voltage: The numerical input of the load cell output at zero. [-F 17] ■ Span input voltage: The numerical input of the load cell output at span. [-F 18] (Load cell output at full capacity – load cell output at zero) ■ Calibration weight value at span: The numerical input of the calibration weight value corresponding to the span input voltage. [-F 19] (These values relate the span input voltage and the calibration weight value.)
Gravity acceleration correction	Calculates and corrects the span error when gravity acceleration between the calibration location and usage location is different.
Digital linearization	Nonlinearity correction function for correcting weighing errors that occur halfway between the zero point and maximum capacity. Up to 4 points can be input in addition to the zero point. The intervals between each point will be calculated using curves.
Function related to the calibration	The function stores basic parameters of the module such as the minimum division and maximum capacity and other data directly related to weighing. Digital span calibration and gravity acceleration correction setting are also performed here.
All data initialization	All the data such as zero value, tare value, calibration data and function data are initialized.

- All parameters in calibration mode are stored in the nonvolatile memory (FRAM).
- Actual load calibration and digital span can be performed at the same time.
Example: For the zero calibration, an actual load is used. For the span calibration, the digital span is used.

6.2.6.1. Calibrating with a Weight ([-5Et])

Refer to "3.2 Calibrating the Display Unit".

6.2.6.2. Calibration Using a Weight with the RS-485 Modbus RTU

Calibration using weights with the RS-485 Modbus RTU is performed in weighing mode. This is referred to in "6.2.6.1 Calibrating with a Weight ([-5Et])".

- Step 1** Preset the related functions for the calibration .
The functions required for the calibration are as follows.

Address	Function No.	Description
400101 - 400102	[-F01	Unit
400103 - 400104	[-F02	Decimal point position
400105 - 400106	[-F03	Minimum division
400107 - 400108	[-F04	Weighing capacity
400137 - 400138	[-F19	Span input voltage weight

- Step 2** Input "1" into the "CAL zero" coil.
The zero calibration will be performed.
The result is output into the "During an internal write cycle / write result" in the Holding register.
- When the zero calibration is not performed, skip **Step 2** and go to **Step 3**.

- Step 3** Place the calibration weight as set in [-F19 Span input voltage weight.
Input "1" into the "CAL span" coil.
The span calibration will be performed.
The result is output into the "During an internal write cycle / write result" in the Holding register.
- "During an internal write cycle / write result"
 - 0 : Calibration succeeded
 - 1 to 8 : Calibration error, refer to "3.2.2 Error Codes for Calibration ([Er])" for details.
 - 15 : During calibration

6.2.6.3. Gravity Acceleration Correction

- When the scale (weighing indicator) has been calibrated in the same place as it is being used, gravity acceleration correction is not required.
- A span error will appear if gravity accelerations are different between the location of calibration and the location of use. Gravity acceleration correction calculates and corrects this span error with the gravity acceleration correction value for both points (the location of calibration and the location of use).
- **When the span is calibrated using actual load, the gravity acceleration correction settings are cleared, and the two gravity acceleration settings return to their default values.**
- **Functions Related to the Gravity Acceleration Correction**
 - [-F26 (Gravity acceleration of the location of calibration):
The gravity acceleration where the module has been calibrated.
 - [-F27 (Gravity acceleration of the location of use):
The gravity acceleration where the module is being used.

Gravity Acceleration Table

Amsterdam	9.813 m/s ²	Manila	9.784 m/s ²
Athens	9.800 m/s ²	Melbourne	9.800 m/s ²
Auckland NZ	9.799 m/s ²	Mexico City	9.779 m/s ²
Bangkok	9.783 m/s ²	Milan	9.806 m/s ²
Birmingham	9.813 m/s ²	New York	9.802 m/s ²
Brussels	9.811 m/s ²	Oslo	9.819 m/s ²
Buenos Aires	9.797 m/s ²	Ottawa	9.806 m/s ²
Calcutta	9.788 m/s ²	Paris	9.809 m/s ²
Chicago	9.803 m/s ²	Rio de Janeiro	9.788 m/s ²
Copenhagen	9.815 m/s ²	Rome	9.803 m/s ²
Cyprus	9.797 m/s ²	San Francisco	9.800 m/s ²
Djakarta	9.781 m/s ²	Singapore	9.781 m/s ²
Frankfurt	9.810 m/s ²	Stockholm	9.818 m/s ²
Glasgow	9.816 m/s ²	Sydney	9.797 m/s ²
Havana	9.788 m/s ²	Tainan	9.788 m/s ²
Helsinki	9.819 m/s ²	Taipei	9.790 m/s ²
Kuwait	9.793 m/s ²	Tokyo	9.798 m/s ²
Lisbon	9.801 m/s ²	Vancouver, BC	9.809 m/s ²
London (Greenwich)	9.812 m/s ²	Washington DC	9.801 m/s ²
Los Angeles	9.796 m/s ²	Wellington NZ	9.803 m/s ²
Madrid	9.800 m/s ²	Zurich	9.807 m/s ²




Illustration 13 Gravity acceleration graph

6.2.6.4. Digital Linearization

Even if zero and span calibration have been performed, weighing errors may occur between the zero point and maximum capacity. Digital linearization ($L - SEt$) is a corrective function designed to correct linearity weighing errors.

- It is possible to input up to four points in addition to the zero point.
- The zero point and each input point will be corrected to put them in a straight line.
- When the actual load input for digital linearization is performed, the calibrated data will be refreshed using zero point and final input point data. It is not necessary to calibrate again. If calibration is performed, the linearization data will not be updated.



















Illustration 3 Digital linearization

6.2.6.5. Actual Load Linearization Function (L-SEt)

Set the digital linearization by loading/unloading masses.

- Warm up the module for at least ten minutes to avoid the effects of temperature drift.
- The input order should proceed from the smallest mass to the largest mass.

<p>Step 1 Press the F + ENT keys to enter to calibration mode and display CAL. Press the ENT key to start the calibration and display L-SEt. Select L-SEt pressing the ↑ key two times and press the ENT key.</p>	   
<p>Step 2 Lnr 0 is displayed. If monitoring the current weighing value, press the → key. Press the → key again to display Lnr 0.</p>	 
<p>Step 3 With nothing on the pan wait for the stabilization (S LED). Press the ENT key. ----- is displayed for approximately two seconds.</p>	
<p>Step 4 Lnr 1 is displayed. If you want to check the current weighing value, press the → key. Press the → key again to display Lnr 1. Press the ENT key. The weight value (the current maximum capacity) is displayed and the smallest digit of the value blinks. Correct the value using the → and ↑ keys so as to be the weight value used.</p>	   <p style="text-align: center; margin: 0;">Sample</p>
<p>Step 5 Place the weight on the pan. Wait for the stabilization (S LED). Press the ENT key. ----- is displayed for approximately two seconds.</p>	
<p>Step 6 Lnr 2 is displayed. Repeat step 4 and step 5. The procedure proceeds in order of Lnr 3 → Lnr 4 → L-End.</p>	 
<p>Step 7 Proceed to step 8 to finish the input operation. To re-input the digital linearization, select the input point using the ↑ key. All data following the new input point will be cleared.</p>	
<p>Step 8 Press the ESC key. L-SEt is displayed and the input data will be stored in the FRAM. At the same time, the calibrated data is also refreshed. Press again the ESC key to return to weighing mode.</p>	

- When **L Er X** is displayed, an error occurred where **X** is the error number. Refer to "3.2.2 Error Codes for Calibration (L Er)" for details.
- The blinking decimal point means that the current value is not the weight value.

6.2.6.6. Calibration Function ([FNC])

All the values set in the calibration function are stored in the nonvolatile memory (FRAM).

Step 1 Press the [F] + [ENT] keys to enter to calibration mode and display [CAL].
 Press the [ENT] key to start the calibration and display [C-SET].
 Press the [ESC] key to return to weighing mode.

Step 2 Select [C-FNC] using the [↑] key and press the [ENT] key.

Step 3 Select the desired function item (function group name with function number) using the [↑] key and press the [ENT] key.
 The current data is displayed.

Step 4 When changing data, two methods of parameter selection and digital input are available depending on the function.


Type	Description of method to change data
Parameter selection	Only the available parameter is displayed and blinks. Select a number using the [↑] key.
Digital input	All the digits are displayed. The digit to be changed blinks. Select a digit using the [→] key and change the value using the [↑] key.

After changing data, press the [ENT] key. The next function number is displayed.
 When the value is not to be changed, press the [ESC] key to return to the function number display.


Step 5 Press the [ESC] key to store new data in FRAM and [C-FNC] is displayed.
 Press again the [ESC] key to return to weighing mode.

- **The blinking decimal point means that the current value is not the weight value.**
- **If digital input data is out of range, [Errdt] is displayed, and the data is canceled.**
- **The function code on the next page is used for command of the USB.**

Item Name	Function code	Description, Range and Default value
[F01] Unit	1001	[1]: g
[F02] Decimal point position	1002	Decimal point position of the weighting value [3]: 0.000
[F03] Minimum division	1003	Minimum division (d) of the weighting value [1]: 1 2: 2 3: 5 4: 10 5: 20 6: 50
[F04] Maximum capacity	1004	Maximum capacity of the module. Weighing is possible up to the value of this setting plus 8 digits. If the value exceeds this, overflow will occur and will not be displayed. The decimal point position depends on [F02] (Decimal point position). AD4212L-R50: 50000 AD4212L-R100: 100000
[F05] Zero range	1005	The range to enable zero operation by the [ZERO] key expressed as a percentage of the maximum capacity with the calibration zero point as the center. For example, if 2 is set, the value in the range of $\pm 2\%$ of the maximum capacity with the center at the calibration zero point will be to zero. When a power-on zero is performed, the initial zero point will be the center. 0 to [2] to 100
[F06] Zero tracking time	1006	Zero tracking is performed using this setting in combination with the setting of [F07]. When [F06] holds 0.0, zero tracking will not be performed. Scale: 0.1 seconds. [0.0] to 5.0
[F07] Zero tracking width	1007	Zero tracking is performed using this setting in combination with the setting of [F06]. When [F07] holds 0.0, zero tracking will not be performed. Scale: 0.1 d (minimum division). [0.0] to 9.9



□ The function code is used for the USB command.

Item Name	Function code	Description, Range and <input type="text" value="Default value"/>
[-F08 Stability detection time	1008	Stability detection is performed using this setting in combination with the setting of [-F09. When [-F08 holds 0.0, stability detection will not be performed. (Stable all the time) Scale: 0.1 seconds. 0.0 to <input type="text" value="1.0"/> to 9.9
[-F09 Stability detection width	1009	Stability detection is performed using this setting in combination with the setting of [-F08. When [-F09 stores 0, stability detection will not be performed. (Stable all the time) Scale: 1 d (minimum div). 0 to <input type="text" value="2"/> to 100
		
[-F 10 Tare and zero when unstable	1010	Tare and zero operation when unstable 0: Disable both functions <input type="text" value="1"/> : Enable both functions
[-F 11 Tare when the gross weight is negative	1011	Tare when the gross weight is negative. 0: Disable tare <input type="text" value="1"/> : Enable tare
[-F 12 Output when out of range and unstable	1012	Standard serial output when the weight value overflows or is unstable. 0: Disable output <input type="text" value="1"/> : Enable output
[-F 13 Excessive negative gross weight	1013	To judge when the negative gross weight is exceeded. <input type="text" value="1"/> : Gross weight < -99999 2: Gross weight < Negative maximum capacity 3: Gross weight < -19 d
[-F 14 Excessive negative net weight	1014	To judge when the negative net weight is exceeded. <input type="text" value="1"/> : Net weight < -99999 2: Net weight < Negative maximum capacity
[-F 15 Clear the zero value	1015	Select whether or not to clear the zero value. 0: Disable <input type="text" value="1"/> : Enable
[-F 16 Zero when power is turned on	1016	Choose whether or not to perform zero when power is turned on. The available range of the zero setting is $\pm 10\%$ of the maximum capacity with the calibration zero point as the center. <input type="text" value="0"/> : Disable 1: Enable

Item Name	Function code	Description, Range and <input type="text" value="Default value"/>
[-F 17 Input voltage at zero	1017	Input voltage from a load cell at zero. Scale: mV/V. This value is determined in zero calibration during the calibration with an actual load. Scale: 0.0001 mV/V. -7.0000 to 7.0000
[-F 18 Span input voltage	1018	Input voltage from a load cell at span. This value and the value of [-F 19 are determined in span calibration during the calibration with an actual load. Scale: 0.0001 mV/V. 0.0100 to 9.9999
[-F 19 Span input voltage weight	1019	The calibration weight value corresponding to the input voltage at span of [-F 18. When performing digital span, [-F 17, [-F 18 and [-F 19 are required for the calibration. The decimal point position depends on [-F 02 (Decimal point position). 1 to 100000
<ul style="list-style-type: none"> □ Record the setting values of [-F 17, [-F 18 and [-F 19 in the "Function list" at the end of the manual to prepare for a malfunction. □ By changing the parameters of [-F 17, [-F 18 and [-F 19, "Zero calibration" and "Span calibration" can be adjusted optionally. (Digital span accuracy approximately 1/5000. The accuracy varies depending on the load cell output accuracy and the conditions of the calibration.) 		
[-F 26 Gravity acceleration of the calibration location	1026	Gravity acceleration of the place where the scale is calibrated. Scale: 0.0001 m/s ² . 9.7500 to <input type="text" value="9.7980"/> to 9.8500
[-F 27 Gravity acceleration of usage location	1027	Gravity acceleration of the place where the scale is being used. Scale: 0.0001 m/s ² . 9.7500 to <input type="text" value="9.7980"/> to 9.8500
[-F 28 Disable hold function	1028	<input type="text" value="0"/> : Enable 1: Disable

6.2.6.7. Linearization Functions (L-Fnc)

- Confirm and change linearity settings.

To use this function, select in the same way as the function related to the calibration are selected.

Item Name	Function code	Description, Range and <input type="text" value="Default value"/>
L-F01 Number of input points	1101	The number of points where linear input was done. The linear-zero input is included as one point. Digital linearization is not performed when the set value is between 0 and 2. <input type="text" value="0"/> to 5
L-F02 Linear-zero	1102	Voltage for linear-zero input. Scale: 0.0001 mV/V. -7.0000 to <input type="text" value="0.0000"/> to 7.0000
L-F03 Setting value for linear 1	1103	The setting value of weight for linear 1 input. The decimal point position depends on L-F02 (Decimal point position). <input type="text" value="0"/> to 100000
L-F04 Span at linear 1	1104	The span voltage between linear-zero and linear 1 input. Scale: 0.0001 mV/V. <input type="text" value="0.0000"/> to 9.9999
L-F05 Setting value for linear 2	1105	The setting value of weight for linear 2 input. The decimal point position depends on L-F02 (Decimal point position). <input type="text" value="0"/> to 100000
L-F06 Span at linear 2	1106	The span voltage between linear-zero and linear 2 input. Scale: 0.0001 mV/V. <input type="text" value="0.0000"/> to 9.9999
L-F07 Setting value for linear 3	1107	The setting value of weight for linear 3 input. The decimal point position depends on L-F02 (Decimal point position). <input type="text" value="0"/> to 100000
L-F08 Span at linear 3	1108	The span voltage between linear-zero and linear 3 input. Scale: 0.0001 mV/V. <input type="text" value="0.0000"/> to 9.9999
L-F09 Setting value for linear 4	1109	The setting value of weight for linear 4 input. The decimal point position depends on L-F02 (Decimal point position). <input type="text" value="0"/> to 100000
L-F10 Span at linear 4	1110	The span voltage between linear-zero and linear 4 input. Scale: 0.0001 mV/V. <input type="text" value="0.0000"/> to 9.9999

6.2.7. List of General Functions

General functions are divided into groups according to function and are indicated by function item (function group name with function number).

All the settings selected in general functions are stored in the FRAM.

6.2.7.1. Procedure to Store New Parameters

Step 1 Press the **ENT** + **F** keys to enter to function mode and display **Fnc**.
 Press the **ENT** key to start function mode.
 To return to weighing mode, press the **ESC** key.

Step 2 Press the **↑** key to select the function group to be set.
 Press the **ENT** key. The function group is as follows:

Display	Group name
<i>Fnc F</i>	Basics function
<i>Hld F</i>	Hold function
<i>Sq F</i>	Sequence function
<i>Fr F</i>	Flow rate function
<i>io F</i>	Control I/O function
<i>[L F</i>	Standard serial output function
<i>r5 F</i>	RS-485 function

Step 3 Press the **↑** key to select the function number to be set.
 Press the **ENT** key. The current setting value is displayed.

Step 4 When changing parameter, two methods of parameter selection and digital input are available depending on the function.

Type	Description of method to change data
Parameter selection	Only the available parameter is displayed and blinks. Select a number using the ↑ key.
Digital input	All the digits are displayed. The digit to be changed blinks. Select the digit using the → key. Change the value using the ↑ key.

After changing data, press the **ENT** key. The next function number is displayed.
 When the value is not to be changed, press the **ESC** key to return to the function number display.

Step 5 Press the **ESC** key. The function number disappeared and the new parameters are stored in FRAM to return to Step 2. Press the **ESC** key again to return to weighing mode.

- **The blinking decimal point means that the current value is not the weight value.**
- **If a data exceeding the available range is input, **Errdt** is displayed, and the data is canceled.**
- **The function code on the next page is used for command of the USB.**


6.2.7.2. Basic Functions (Fnc F)

Item Name	Function code	Description, Range and Default value
Fnc01 Key switch disable	1201	Each digit of the setting corresponds to a key switch. Only available in weighing mode. Key assignment to each binary digit. 0: Permission 4th 3rd 2nd 1st 1: Prohibition <input type="button" value="ESC"/> <input type="button" value="→"/> <input type="button" value="↑"/> <input type="button" value="ENT"/> <input type="text" value="0000"/> to 1111
Fnc02 <input type="button" value="F"/> key	1202	0: None 7: Zero clear 1: Manual print command 8: Weighing start / Pause / Restart 2: Hold 9: Actual free fall input 3: Operation switch 1 10: One shot, Small flow 4: Operation switch 2 11: Sequence flow rate monitor <input type="text" value="5"/> : Display exchange 12: mV/V monitor 6: Tare clear 13: Digital filter 2
Fnc03 Display update rate	1203	<input type="text" value="1"/> : 20 times/second 2: 10 times/second 3: 5 times/second
Fnc04 x display	1204	<input type="text" value="0"/> : None 11: Over 1: Zero tracking in progress 12: OK 2: Alarm 13: Under 3: Display operation switch status as on or off 14: Full 4: Near-zero 15: Weighing end 5: HI output 16: In weighing sequence 6: OK output 17: Weighing sequence, error 7: LO output 18: Normal batch/Loss-in-weight, Identification 8: Large flow 19 to 24: State of Coil IN 1 to 6 9: Medium flow 25 to 32: Setting of Coil OUT 1 to 8 10: Small flow
Fnc05 Digital filter 1	1205	Selects a cutoff frequency. 0: None 6: 20.0 Hz 12: 2.8 Hz 1: 100.0 Hz 7: 14.0 Hz 13: 2.0 Hz 2: 70.0 Hz 8: 10.0 Hz 14: 1.4 Hz 3: 56.0 Hz 9: 7.0 Hz <input type="text" value="15"/> : 1.0 Hz 4: 40.0 Hz 10: 5.6 Hz 16: 0.7 Hz 5: 28.0 Hz 11: 4.0 Hz
Fnc06 Digital filter 2	1206	Selects a cutoff frequency. 0: None 6: 20.0 Hz 12: 2.8 Hz 18: 0.40 Hz 1: 100.0 Hz 7: 14.0 Hz 13: 2.0 Hz 19: 0.28 Hz 2: 70.0 Hz 8: 10.0 Hz 14: 1.4 Hz 20: 0.20 Hz 3: 56.0 Hz 9: 7.0 Hz <input type="text" value="15"/> : 1.0 Hz 21: 0.14 Hz 4: 40.0 Hz 10: 5.6 Hz 16: 0.7 Hz 22: 0.10 Hz 5: 28.0 Hz 11: 4.0 Hz 17: 0.56 Hz 23: 0.07 Hz
Fnc07 Hold	1207	<input type="text" value="1"/> : Normal hold 2: Peak hold 3: Averaging hold
Fnc08 Near-zero	1208	Decimal point position depends on $[F02]$ (Decimal point position). -99999 to <input type="text" value="10"/> to 99999

Item Name	Function code	Description, Range and Default value
<i>Fnc 09</i> Near-zero comparison weight	1209	1: Gross weight 2: Net weight
<i>Fnc 10</i> Upper limit value	1210	The decimal point position depends on $[-F02]$ (Decimal point position). -99999 to 10 to 99999
<i>Fnc 11</i> Lower limit value	1211	The decimal point position depends on $[-F02]$ (Decimal point position). -99999 to -10 to 99999
<i>Fnc 12</i> Comparison mass of upper and lower limit	1212	1: Gross weight 2: Net weight
<i>Fnc 13</i> Full	1213	The reference value for the full value of gross weight. The decimal point position depends on $[-F02]$ (Decimal point position). -99999 to 99999

□ The function code is used for the USB command.

6.2.7.3. Hold Functions (*HLd F*)

Item Name	Function code	Description, Range and Default value
<i>HLd 01</i> Averaging time	1301	Time to perform the averaging. 0.00 is not averaged. Scale: 0.01 seconds. 0.00 to 9.99
<i>HLd 02</i> Start wait time	1302	Waiting time to commence a hold or average. Scale: 0.01 seconds. 0.00 to 9.99
<i>HLd 03</i> Automatic start condition	1303	The condition to commence a hold or average. 0: Disable 2: Above the near-zero 1: Above the near-zero and stable
<i>HLd 04</i> Release using control input	1304	Release when control input of the hold terminal is falling. 0: Do not release 1: Release 
<i>HLd 05</i> Release time	1305	Release after a set amount of time has passed. 0.00 is not averaged. Scale: 0.01 seconds. 0.00 to 9.99
<i>HLd 06</i> Release using fluctuation range	1306	Release when fluctuation of the holding value exceeds a set value. The decimal point position depends on $[-F02]$ (Decimal point position). 0 to 99999
<i>HLd 07</i> Release at near-zero	1307	Release when the weighing value is in the near-zero. 0: Do not release 1: Release

6.2.7.4. Weighing Sequence Functions (59 F)

Item Name	Function code	Description, Range and Default value
59 01 Final value	1401	The decimal point position depends on [-F02 (Decimal point position). -99999 to 0 to 99999
59 02 Free fall	1402	The decimal point position depends on [-F02 (Decimal point position). -99999 to 0 to 99999
59 03 Preliminary	1403	The decimal point position depends on [-F02 (Decimal point position). -99999 to 0 to 99999
59 04 Optional preliminary	1404	The decimal point position depends on [-F02 (Decimal point position). -99999 to 0 to 99999
59 05 Over	1405	The decimal point position depends on [-F02 (Decimal point position). -99999 to 0 to 99999
59 06 Under	1406	The decimal point position depends on [-F02 (Decimal point position). -99999 to 0 to 99999
59 07 Weighing mode	1407	0 : Disable 1 : Normal batch sequence 2 : Loss-in-weight sequence 3 : Specifying with control input 4 : Specifying with Modbus RTU
59 08 Automatic free fall correction	1408	0 : Disable 1 : Moving average of last four times 2 : Real-time free fall compensation (fixed coefficient) 3 : Real-time free fall compensation (updated coefficient)
59 09 Automatic free fall band	1409	The decimal point position depends on [-F02 (Decimal point position). Weighing end value is compensated automatically when net weight is within (final value ± this band). 0 to 99999
59 10 Active free fall coefficient	1410	Active free fall coefficient. Scale: 0.001 second -99.999 to 0.000 to 99.999
59 11 OK/Over/Under output timing	1411	1 : Always 2 : In synchronization with weighing end
59 12 Wait for the weight value to be stable before the judgment	1412	0 : Disable 1 : Enable
59 13 Automatic tare at weighing start	1413	0 : Disable 1 : Enable
59 21 Flow timeout time	1421	The period of the weighing sequence. 0 : Disable Scale: 1 second 0 to 600
59 22 Weighing start input delay time	1422	Waiting time from the start of the weighing sequence to the output. Scale: 0.1 second 0.0 to 60.0

Item Name	Function code	Description, Range and Default value
59 23 Large flow comparison disable time	1423	Time for preventing the gate from malfunctioning due to vibration when opening and closing the gate. Scale: 0.1 second <input type="text" value="0.0"/> to 60.0
59 24 Medium flow comparison disable time	1424	
59 25 Small flow comparison disable time	1425	
59 26 Judging delay time	1426	Wait time between closing small flow gate and outputting comparison. Scale: 0.1 second 0.0 to <input type="text" value="0.1"/> to 60.0
59 27 Weighing end output time	1427	0.0 : Until the next weighing start. Scale: 0.1 second <input type="text" value="0.0"/> to 60.0
59 28 One-shot time for small flow rate	1428	Scale: 0.01 second <input type="text" value="0.00"/> to 6.00

6.2.7.5. Flow Rate Functions (F_r F)

Item Name	Function code	Description, Range and Default value
F_r 01 Filter of flow rate 1	1901	1 : Digital filter 1 <input type="text" value="2"/> : Digital filter 2
F_r 02 Filter of flow rate 2	1902	
F_r 03 Damping time for flow rate 1	1903	Suppress changes in flow rates. The higher value setting, the less changes. Scale: 1 second 1 to <input type="text" value="5"/> to 1000
F_r 04 Damping time for flow rate 2	1904	
F_r 05 +/- flow rate 1	1905	<input type="text" value="0"/> : according to calculation 1 : interchange +/- 2 : absolute value
F_r 06 +/- flow rate 2	1906	

6.2.7.6. Control I/O Functions (I/O F)

	Item Name	Function code	Description, Range and Default value
IN	I/O 01	1601	0 : Disable 1 to 6 : Reserved internally 7 : Zero 8 : Tare 9 : Hold 10 : Gross / Net exchange 11 : Diagnose 12 : Print command 13 : Weighing start 14 : Pause 15 : Restart 16 : Emergency stop OFF=Release ON=Stop 17 : Error reset 18 : Normal batch (=OFF)/ Loss-in-weight exchange(=ON) 19 : Actual free fall input 20 : One-shot small flow 21 : Full open OFF=Not open ON=Open 22 : Zero clear 23 : Tare clear 24 : Operation same as a [F] key * * Not functioned for operation switch 2
	I/O 02	1602	25 : Prohibit update of flow rate 1 OFF=Update ON=Not update 26 : Prohibit update of flow rate 2 OFF=Update ON=Not update 27 : Initialize flow rate 1 28 : Initialize flow rate 2
	I/O 03	1603	0 to [7] to 28
	I/O 04	1604	0 to [8] to 28
	I/O 05	1605	[0] to 28
	I/O 06	1606	[0] to 28
OUT	I/O 11	1611	0 : Disable 1 to 8 : Reserved internally 9 : Stability 10 : Over capacity 11 : Net display 12 : During tare 13 : Hold 14 : Hold busy 15 : HI output 16 : OK output 17 : LO output 18 : Near-zero 19 : Full 20 : Over 21 : OK 22 : Under 23 : Large flow 24 : Medium flow 25 : Small flow 26 : Normal batch(=OFF)/Loss-in-weight(=ON), Identification 27 : In weighing sequence 28 : Weighing end 29 : Weighing sequence error
	I/O 12	1612	30 : In weighing (ON) 31 : In weighing (1 Hz) 32 : In weighing (50 Hz) 33 : Alarm 34 : Output operation switch is on or off 35 : Approximate flow rate value of flow rate 1 36 : Approximate flow rate value of flow rate 2 37 : Remote I/O
	I/O 13	1613	0 to [18] to 37
	I/O 14	1614	0 to [9] to 37
	I/O 15	1615	[0] to 37
	I/O 16	1616	[0] to 37
	I/O 17	1617	[0] to 37
	I/O 18	1618	[0] to 37

Item Name	Function code	Description, Range and Default value
OUT	10 21 OUT1 Logic	1621 1 : Inverting output If data is "0" level, the output transistor turns ON.
	10 22 OUT2 Logic	1622 2 : Non-inverting output If data is "1" level, the output transistor turns ON.
	10 23 OUT3 Logic	1623
	10 24 OUT4 Logic	1624
	10 25 OUT5 Logic	1625
	10 26 OUT6 Logic	1626
	10 27 OUT7 Logic	1627
	10 28 OUT8 Logic	1628

6.2.7.7. Standard Serial Output Functions ([L F])

Item Name	Function code	Description, Range and Default value
[L 01 Serial data	1701	1 : Weighing display 3 : Net 5 : Gross / Net / Tare 2 : Gross 4 : Tare
[L 02 Communication mode	1702	1 : Stream 2 : Automatic print 3 : Manual print
[L 03 Baud rate	1703	1 : 600 bps 2 : 2400 bps

6.2.7.8. RS-485 Functions (r5 F)

Item Name	Function code	Description, Range and Default value
r5 02 Communication mode	2102	5 : Modbus RTU 6 : Interval output at 100 times/second 7 : Interval output at 200 times/second 8 : Interval output at 500 times/second
r5 03 Baud rate	2103	5 : 9600 bps 7 : 38400 bps 6 : 19200 bps 8 : 115200 bps
r5 04 Parity	2104	0 : None 1 : Odd 2 : Even
r5 06 Stop bit length	2106	1 : 1 bit 2 : 2 bits
r5 07 Terminator	2107	1 : CR (0Dh) 2 : CR LF (0Dh, 0Ah)
r5 08 Slave address	2108	0 : None 1 to 99


6.3. Interface

6.3.1. RS-485

The RS-485 has two kinds of communication modes (r5 02).

- Modbus RTU (r5 02 = 5)
- Interval output (r5 02 = 6, 7, 8)

RS-485

	5	SLD
	4	RTRM
	3	SG
	2	DATA-
	1	DATA+

Pin No.	Symbol	Description
5	SLD	Connected with FG ground terminal on the power supply connector.
4	RTRM	Terminating resistor (100Ω) is connected to Pin 1. Enable the terminating resistor with short-circuited to Pin 2.
3	SG	Signal ground
2	DATA-	Minus side of the RS-485 communication line.
1	DATA+	Plus side of the RS-485 communication line.

Communication Specifications

Item	Data transfer mode (r5 02)	
	Modbus RTU	Interval output
Baud rate (r5 03)	r5 03 (9600, 19200, 38400, 115200 bps)	
Start bit length	1 bit	
Character bit length	Fixed 8 bits	
Parity (r5 04)	Fixed even number	r5 04
Stop bit length (r5 06)	Fixed 1 bit	r5 06
Terminator (r5 07)	Time	r5 07
Code	Binary	ASCII
Slave address (r5 08)	1 to 99 (0 : No address setting)	Not used

6.3.1.1. Modbus RTU

Display unit is a slave device of the Modbus RTU. Refer to "6.3.5 Modbus RTU Data Address".

Interval output

Weighing display value is output periodically.

Communication mode	Interval output	Reference
6	10 millisecond output (100 times/second)	The output data format is common. Output data is weighing display value.
7	5 millisecond output (200 times/second)	
8	2 millisecond output (500 times/second)	

NOTE :100 times/second : Set the baud rate over 19200bps.
 200 times/second : Set the baud rate over 38400bps.
 500 times/second : Set the baud rate over 115200bps.

Output data format

	Weighing display value		Terminator (r5 07)
Digit	Sign (1 char)	Figure (7 chars)	1 or 2 chars

NOTE: The state of the weighing display value, decimal point, and unit are not added to the weighing display value.

6.3.1.2. Error Code of the Modbus RTU (Data Address : 400065 – 400068)

Error code		Error sub code		Reference
Error item	Code No.	Item	Code No.	
No error	0	N/A	0	
A/D converter error	1	N/A	0	
Nonvolatile memory error	2	N/A	0	
RAM error	3	N/A	0	
Calibration error	4		1 to 8	Refer to "3.2.2 Error Codes for Calibration (E_r)"
Weighing display error	5	N/A	0	
Verification of the load cell connections error	6		1 to 255	Refer to the error code in "5.2.5 Display and Output of Verification".

6.3.1.3. Bit Address of Status Indicators (Data Address : 400009 – 400010)

Data Address (Holding Register)	R/W	Item	Reference
400009. 15-00	R	Reserved internally	0 fixed.
400010. 15-07		Reserved internally	0 fixed.
400010. 06		Z : Zero	LED to turn on = 1 LED to turn off = 0
400010. 05		S : Stable	
400010. 04		G : Gross	
400010. 03		N : Net	
400010. 02		H : Hold, Hold busy	
400010. 01		X : Basic function at $Fnc04$	
400010. 00		Reserved internally	0 fixed.

6.3.1.4. Internal Write Cycle/Write Result (Data Address : 400099 – 400100)

No.	Item	Reference
0	Write success	
1	Write failure	
1 to 8	Calibration error	Refer to "3.2.2 Error Codes for Calibration (E_r)" for details.
15	Internal write cycle	Writing in the nonvolatile memory.
Other	None	Not used.

6.3.1.5. Access Interval Timer (Data Address : 400097 – 400098)

This is an interval timer to count up every 1 ms. When the values are read, the interval timer is initialized to "0". By reading the values periodically, an approximate communication time can be measured.

6.3.2. Control I/O

- Using a control input from peripherals, data can be monitored and be output.
- Using a control output, the weighing status and weighing result can be output.
- The input and output circuit is isolated from the DC power supply terminals and load cell terminals.
- DC +24 V is supplied between the power supply input terminal (I/O PWR +24V) and COM terminal.

Part of input (IN1 ~ IN6)


Input circuit type	No-voltage contact input (Photo coupler)
Input open voltage	According to use
OFF current	0.1 mA max.
ON current	2.7 mA min.
Input threshold voltage	2 V

Part of output (OUT1 ~ OUT8)

Output circuit type	Open collector
Isolation	Photo coupler
Output voltage	DC 35 V max.
Output current	50 mA max.
Output saturation voltage	1.1 V max.

Control I/O

IN 6	20	10	IN 5
IN 4	19	9	IN 3
IN 2	18	8	IN 1
OUT8	17	7	OUT7
OUT6	16	6	OUT5
OUT4	15	5	OUT3
OUT2	14	4	OUT1
I/O PWR +24V	12	2	COM
	11	1	





- **Assigning functions to terminals**
 - Assign functions to these input terminals : $\text{IO } 01$ (IN1 function) to $\text{IO } 06$ (IN6 function)
 - Assign functions to these output terminals : $\text{IO } 11$ (OUT1 function) to $\text{IO } 18$ (OUT8 function)
 - Assign logic to these output terminals : $\text{IO } 21$ (OUT1 logic) to $\text{IO } 28$ (OUT8 logic)

6.3.3. Standard Serial Output (Current Loop)

- The standard serial output (C.L.) circuit is isolated from all terminals.
- The standard serial output can connect to the A&D external display and printer.
- The standard serial output needs DC current supplied from an external DC power source.
- The standard serial output terminals of the display unit have non-polarity.
- The standard serial output terminals are pin 3 and 13 of the control I/O connector.

Transmission	0 – 20mA, Current loop
Data length	7 bits
Start bit	1 bit
Parity bit	Even
Stop bit	1 bit
Baud rate	600 bps, 2400 bps
Code	ASCII



6.3.3.1. Data Format of Serial Output

- The "A&D standard format" is used to the output format for communication with the A&D printer, and external display and consists of dual headers, data, unit and terminator.

A&D standard format

Header 1	Header 2	Data (Polarity, 8 digits including decimal point)	Unit	Terminator
S T ,	G S ,	+ 0 1 2 3 . 4 5	SP g	CR LF

Item	ASCII code	Hexadecimal	Description
Header 1	ST	[53 54]	Stable
	US	[55 53]	Unstable
	OL	[4F 4C]	Overload
Header 2	GS	[47 53]	Gross
	NT	[4E 54]	Net
	TR	[54 52]	Tare
Punctuation	,	[2C]	Comma
Data (ASCII code)	0 to 9	[30 to 39]	Number
	+	[2B]	Positive sign
	-	[2D]	Negative sign
	SP	[20]	Space
	.	[2E]	Dot

Examples of the A&D standard format

	Header 1	Header 2	Data (8 digits including decimal point, polarity)								Unit		Terminator						
Gross	S	T	,	G	S	,	+	0	0	1	2	3	4	5	SP	g	CR	LF	Header 2 [GS]
Net	S	T	,	N	T	,	+	0	0	1	0	0	0	0	SP	g	CR	LF	Header 2 [NT]
Tare	S	T	,	T	R	,	+	0	0	0	2	3	4	5	SP	g	CR	LF	Header 2 [TR]
Including "."	S	T	,	G	S	,	+	0	1	2	3	.	4	5	SP	g	CR	LF	Numerical part [.]
+Over	O	L	,	G	S	,	+	SP	SP	SP	SP	.	SP	SP	SP	g	CR	LF	Header 1 [OL]
-Over	O	L	,	G	S	,	-	SP	SP	SP	SP	.	SP	SP	SP	g	CR	LF	Header 1 [OL], Polarity [-]
Unstable	U	S	,	G	S	,	+	0	1	2	3	.	4	5	SP	g	CR	LF	Header 1 [US]
Output data	O	L	,	G	S	,	+	SP	SP	SP	SP	.	SP	SP	SP	g	CR	LF	Same as +Over

The position of the decimal point is fixed even if data is out of range.

6.3.3.2. Transfer Mode of Serial Output

There are 3 types of current loop output ([L 02]): Stream, automatic print and manual print.


Stream	The data is output at each display update. If the data cannot be output completely due to a slow baud rate, the data is output at the next update. The output data uses displayed data. Therefore, hidden data is not output.
Automatic printing	Automatic printing depends on the weighing mode setting. 1. Weighing mode (59 07) = 0 When a weighing value is 5d or more and is stable, the data is output only once. To output again, data is required to become less than 5d. Select "Normal hold (1)" in Fnc07 Hold function for the setting. Note: When "stability detection time" ([-F08]) and "stability detection width" ([-F09]) are set to "0" (stability detection is not performed), the data is output only once when it becomes 5d or more. 2. Weighing mode (59 07) = 1 or more (When batch weighing is used) Output once when the weighing sequence finished.
Manual printing	When "manual printing" is selected, data is output when receiving a printing command from the control input, pressing the assigned print key, or writing a coil from the Modbus RTU.

6.3.4. USB


- The function settings can be input and output from a device that is connected to the Micro-B USB connector.
- When the USB is connected to a personal computer (PC), the PC recognizes the USB as a virtual COM port. The setting of virtual COM port is shown below.
Baud rate: 9600 bps, Data bits: 7 bits, Parity: even, Stop bit: 1
- The communication tool can be downloaded at A&D website. Communication parameters are fixed.
- While weighing, do not perform cable connections. It may be easily influenced by environmental noise.
- Use the standard Micro-B USB connector.
- Reading is available whenever the power is on.
- Reading and writing of the function from the USB is valid except weighing mode.

6.3.4.1. Format

Monitoring Command




Storing Command and Response



- The response of the monitoring command is the same as the storing command.
- "+999999" means an irregular response. Ex.: In case that the function code is not correct and the command is not performed.

6.3.4.2. Monitoring the Function Setting

This specifies a function code in the command code and monitors the data.



NNNN is code, ±XXXXXX is a number.

6.3.4.3. Storing the Function Setting

This specifies a function code in the command code and stores the data.

Command

N	N	N	N	,	±	X	X	X	X	X	X	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

 Response

N	N	N	N	,	±	X	X	X	X	X	X	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

NNNN is code, ±XXXXXX is a number.

- For the parameter type, the branch number is stored.
- *FncDI* (Key switch disable) is a decimal.

6.3.4.4. Reading the Whole Function Settings

All the functions can be read at once and a list of functions can be made.

Command

N	N	N	N	CR	LF
---	---	---	---	----	----

NNNN is a command.

Command code	Description
0999	All functions
1000	Calibration
1100	Linearity
1200	Basic
1300	Hold
1400	Sequence
1600	Control I/O
1700	Standard serial output
1900	Flow rate
2100	RS-485

6.3.4.5. Reading Data

The functions below can be monitored.

Command

N	N	N	N	CR	LF
---	---	---	---	----	----

NNNN is a command.

Command code	Description
0101	Program version
0102	Serial No. (lower 5 digits)
0103	Program checksum
0104	FRAM checksum
0201	Gross count
0202	Net count
0203	Tare count
0204	Load cell output. Scale: 1 nV/V
0205	Load cell output. Scale: 10 nV/V

6.3.5. Modbus RTU Data Address

Data Address (Coil)	R/W	Item	Description
000001	R	Near-zero	
000002		Under	
000003		Over	
000004		OK	
000005		Large flow	
000006		Medium flow	
000007		Small flow	
000008		Reserved internally	
000009		Weighing end	
000010		Full	
000011		Reserved internally	
000012		HI	
000013		OK	
000014		LO	
000015		Reserved internally	
000016		Stability	
000017		Gross/net (0/1) display	
000018		In weighing sequence	
000019		Weighing sequence error	
000020		Over-capacity	Weighing display
000021		Zero range setting error	
000022		Tare error	
000023		Reserved internally	
000024		Reserved internally	
000025		Reserved internally	
000026		CAL operation error	
000027		Tare status (1: During tare)	
000028		Normal batch/loss in weight (0/1) identification	
000029		Update of flow rate 1 (0 : Enable)	
000030		Update of flow rate 2 (0 : Enable)	
000031		Approximate flow rate value of flow rate 1 (1:Approximate)	
000032		Approximate flow rate value of flow rate 2 (1:Approximate)	
000033		Net center of zero	
000034		Gross center of zero	
000035		Hold in progress (1: Hold)	
000036		Hold busy status (1: Hold busy)	
000037		Self-checking (1: Self-checking)	
000038		Net over	
000039		Net under	
000040		Gross over	
000041		Gross under	
000042		A/D over	
000043		A/D under	
000044 - 000100			Reserved internally

000101	R	IN1 status	
000102		IN2 status	
000103		IN3 status	
000104		IN4 status	
000105		IN5 status	
000106		IN6 status	
000107		OUT1 status	
000108		OUT2 status	
000109		OUT3 status	
000110		OUT4 status	
000111		OUT5 status	
000112		OUT6 status	
000113		OUT7 status	
000114		OUT8 status	
000115 - 000200		Reserved internally	

Data Address (Coil)	R/W	Item	Description	
000201	W *1	Zero adjustment		
000202		Tare		
000203		Weighing start		
000204		Emergency stop		
000205		Reserved internally		
000206		Reserved internally		
000207		Tare clear		
000208		Reserved internally		
000209		Reserved internally		
000210		Reserved internally		
000211		Print command		
000212		Zero clear		
000213		Gross display		
000214		Net display		
000215		Pause		
000216		Restart		
000217		Reserved internally		
000218		Reserved internally		
000219		Error reset		
000220		One-shot small flow		
000221		Exchange normal batch sequence		
000222		Exchange loss-in-weight sequence		
000223		Permit update of flow rate 1		
000224		Prohibit update of flow rate 1		
000225		Initialize flow rate 1		
000226		Permit update of flow rate 2		
000227		Prohibit update of flow rate 2		
000228		Initialize flow rate 2		
000229		Actual free fall input		
000230		Hold		
000231		Hold cancellation		
000232 - 000300			Reserved internally	
000301			Setting of OUT1 to 1	
000302		Setting of OUT1 to 0		
000303		Setting of OUT2 to 1		
000304		Setting of OUT2 to 0		
000305		Setting of OUT3 to 1		
000306		Setting of OUT3 to 0		
000307		Setting of OUT4 to 1		
000308		Setting of OUT4 to 0		
000309		Setting of OUT5 to 1		
000310		Setting of OUT5 to 0		
000311		Setting of OUT6 to 1		
000312		Setting of OUT6 to 0		
000313		Setting of OUT7 to 1		

Data Address (Coil)	R/W	Item	Description
000314	W *1	Setting of OUT7 to 0	
000315		Setting of OUT8 to 1	
000316		Setting of OUT8 to 0	
000317 - 000400		Reserved internally	
000401		CAL zero	
000402		CAL span	
000403		Self-check start	
000404		Self-check stop (Return to weighing mode)	
000405 - 000500		Reserved internally	

*1 : The command is executed when "1" is written.

Data Address (Holding Register) *5	R/W	Item	Description
400001 - 400002	R	Weighing display (Digital filter 1)	
400003 - 400004		Gross (Digital filter 1)	
400005 - 400006		Net (Digital filter 1)	
400007 - 400008		Tare weight	
400009 - 400010		Status indicator (Status LED)	*3
400011 - 400012		Reserved internally	
400013 - 400014		Reserved internally	
400015 - 400016		Reserved internally	
400017 - 400018		Gross value of weighing sequence end	
400019 - 400020		Net value of weighing sequence end	
400021 - 400022		Tare weight value of weighing sequence end	
400023 - 400024		Sequence number	*1
400025 - 400026		Reserved internally	
400027 - 400028		Flow rate 1 (per second)	
400029 - 400030		Flow rate 2 (per second)	
400031 - 400032		Flow rate 1 (per minute)	
400033 - 400034		Flow rate 2 (per minute)	
400035 - 400036		Flow rate 1 (per hour)	
400037 - 400038		Flow rate 2 (per hour)	
400039 - 400040		Flow rate 1	Changes in a time set at F_r 03
400041 - 400042		Flow rate 2	Changes in a time set at F_r 04
400043 - 400044		Weighing display (Digital filter 2)	
400045 - 400046		Gross (Digital filter 2)	
400047 - 400048		Net (Digital filter 2)	
400049 - 400050		Reserved internally	
400051 - 400052		Reserved internally	
400053 - 400054		Batch error	
400055 - 400056		Actual free fall	
400057 - 400058		Free fall (Average)	
400059 - 400060		Active free fall coefficient (average)	
400061 - 400062		Flow rate (In small flow off)	
400063 - 400064		Flow rate (Real time, per second)	
400065 - 400066		Error code	*2
400067 - 400068		Error sub code	*2
400069 - 400070		Program version	
400071 - 400072		Serial number	
400073 - 400074		Program checksum	
400075 - 400076		Memory checksum	
400077 - 400094		Reserved internally	
400095 - 400096		Output voltage of load cell (nV/V)	
400097 - 400098	Access interval timer (ms)		
400099 - 400100	During an internal write cycle / Write result	*4	

*1 : Refer to "6.2.3.9 Sequence Numbers" for details.

*2 : Refer to "6.3.1.2 Error Code of the Modbus RTU (Data Address : 400065 – 400068)" for details.

*3 : Refer to "6.3.1.3 Bit Address of Status Indicators (Data Address : 400009 – 400010)" for details.

*4 : Refer to "6.3.1.4 Internal Write Cycle/Write Result (Data Address : 400099 – 400100)" for details.

*5 : Double Word word order is low word first (L/H). Following data of Holding registers are the same.

Data Address (Holding Register)	R/W	Item	Description
400101 - 400102		[-F01] Unit	
400103 - 400104		[-F02] Decimal point position	
400105 - 400106		[-F03] Minimum division	
400107 - 400108		[-F04] Maximum capacity	
400109 - 400110		[-F05] Zero range	
400111 - 400112		[-F06] Zero tracking time	
400113 - 400114		[-F07] Zero tracking width	
400115 - 400116		[-F08] Stability detection time	
400117 - 400118		[-F09] Stability detection width	
400119 - 400120		[-F10] Tare and zero when unstable	
400121 - 400122		[-F11] Tare when the gross weight is negative	
400123 - 400124		[-F12] Output when out of range and unstable	
400125 - 400126		[-F13] Excessive negative gross weight	
400127 - 400128		[-F14] Excessive negative net weight	
400129 - 400130		[-F15] Clear the zero value	
400131 - 400132		[-F16] Zero when power is turned on	
400133 - 400134		[-F17] Input voltage at zero	
400135 - 400136		[-F18] Span input voltage	
400137 - 400138		[-F19] Span input voltage weight	
400139 - 400150	R/W	Reserved internally	
400151 - 400152		[-F26] Gravity acceleration of the calibration location	
400153 - 400154		[-F27] Gravity acceleration of the usage location	
400155 - 400156		[-F28] Disable hold function	
400157 - 400158		Reserved internally	
400159 - 400160		Reserved internally	
400161 - 400162		Reserved internally	
400163 - 400164		Reserved internally	
400165 - 400170		Reserved internally	
400171 - 400172		Reserved internally	
400173 - 400174		Reserved internally	
400175 - 400176		Reserved internally	
400177 - 400178		Reserved internally	
400179 - 400180		Reserved internally	
400181 - 400182		Reserved internally	
400183 - 400184		Reserved internally	
400185 - 400186		Reserved internally	
400187 - 400188		Reserved internally	
400189 - 400190		Reserved internally	
400191 - 400200		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400201 - 400202	R/W	Final value	The same as 400401 - 400412
400203 - 400204		Free fall	
400205 - 400206		Preliminary	
400207 - 400208		Optional preliminary	
400209 - 400210		Over	
400211 - 400212		Under	
400213 - 400214		Full	
400215 - 400216		Near-zero	The same as 400315 - 400316
400217 - 400218		Reserved internally	
400219 - 400220		Upper limit value	The same as 400321 - 400322
400221 - 400222		Lower limit value	The same as 400323 - 400324
400223 - 400300		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400301 - 400302	R/W	<i>Fnc01</i> Key switch disable	
400303 - 400304		<i>Fnc02</i> <input type="checkbox"/> key	
400305 - 400306		<i>Fnc03</i> Display update rate	
400307 - 400308		<i>Fnc04</i> X display	
400309 - 400310		<i>Fnc05</i> Digital filter 1	
400311 - 400312		<i>Fnc06</i> Digital filter 2	
400313 - 400314		<i>Fnc07</i> Hold	
400315 - 400316		<i>Fnc08</i> Near-zero	The same as 400215 - 400216
400317 - 400318		<i>Fnc09</i> Near-zero comparison weight	
400319 - 400320		<i>Fnc10</i> Upper limit value	The same as 400219 - 400220
400321 - 400322		<i>Fnc11</i> Lower limit value	The same as 400221 - 400222
400323 - 400324		<i>Fnc12</i> Comparison mass of upper and lower limit	
400325 - 400326		<i>Fnc13</i> Full	
400327 - 400400		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400401 - 400402	R/W	<i>59 01</i> Final value	The same as 400201 - 400212
400403 - 400404		<i>59 02</i> Free fall	
400405 - 400406		<i>59 03</i> Preliminary	
400407 - 400408		<i>59 04</i> Optional preliminary	
400409 - 400410		<i>59 05</i> Over	
400411 - 400412		<i>59 06</i> Under	
400413 - 400414		<i>59 07</i> Weighing mode	
400415 - 400416		<i>59 08</i> Automatic free fall correction	
400417 - 400418		<i>59 09</i> Automatic free fall band	
400419 - 400420		<i>59 10</i> Active free fall coefficient	
400421 - 400422		<i>59 11</i> OK/Over/Under output timing	
400423 - 400424		<i>59 12</i> Wait for the weight value to be stable before the judgment	
400425 - 400426		<i>59 13</i> Automatic tare at weighing start	
400427 - 400440		Reserved internally	
400441 - 400442		<i>59 21</i> Flow timeout time	
400443 - 400444		<i>59 22</i> Weighing start input delay time	
400445 - 400446		<i>59 23</i> Large flow comparison disable time	
400447 - 400448		<i>59 24</i> Medium flow comparison disable time	
400449 - 400450		<i>59 25</i> Small flow comparison disable time	
400451 - 400452		<i>59 26</i> Judging delay time	
400453 - 400454		<i>59 27</i> Weighing end output time	
400455 - 400456		<i>59 28</i> One-shot time for small flow rate	
400457 - 400500		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400501 - 400502	R/W	<i>10 01</i> Function of IN1	
400503 - 400504		<i>10 02</i> Function of IN2	
400505 - 400506		<i>10 03</i> Function of IN3	
400507 - 400508		<i>10 04</i> Function of IN4	
400509 - 400510		<i>10 05</i> Function of IN5	
400511 - 400512		<i>10 06</i> Function of IN6	
400513 - 400600		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400601 - 400602	R/W	<i>10 11</i> Function of OUT1	
400603 - 400604		<i>10 12</i> Function of OUT2	
400605 - 400606		<i>10 13</i> Function of OUT3	
400607 - 400608		<i>10 14</i> Function of OUT4	
400609 - 400610		<i>10 15</i> Function of OUT5	
400611 - 400612		<i>10 16</i> Function of OUT6	
400613 - 400614		<i>10 17</i> Function of OUT7	
400615 - 400616		<i>10 18</i> Function of OUT8	
400617 - 400618		<i>10 21</i> OUT1 Logic	
400619 - 400620		<i>10 22</i> OUT2 Logic	
400621 - 400622		<i>10 23</i> OUT3 Logic	
400623 - 400624		<i>10 24</i> OUT4 Logic	
400625 - 400626		<i>10 25</i> OUT5 Logic	
400627 - 400628		<i>10 26</i> OUT6 Logic	
400629 - 400630		<i>10 27</i> OUT7 Logic	
400631 - 400632		<i>10 28</i> OUT8 Logic	
400633 - 400700		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400701 - 400702	R/W	<i>[L 01</i> Serial data	
400703 - 400704		<i>[L 02</i> Communication mode	
400705 - 400706		<i>[L 03</i> Baud rate	
400707 - 400800		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
400901 - 400902	R/W	Reserved internally	
400903 - 400904		<i>r5 02</i> Communication mode	
400905 - 400906		<i>r5 03</i> Baud rate	
400907 - 400908		<i>r5 04</i> Parity	
400909 - 400910		Reserved internally	
400911 - 400912		<i>r5 06</i> Stop bit length	
400913 - 400914		<i>r5 07</i> Terminator	
400915 - 400916		<i>r5 08</i> Slave address	
400917 - 401000		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
401201 - 401202	R/W	<i>HL d01</i> Averaging time	
401203 - 401204		<i>HL d02</i> Start wait time	
401205 - 401206		<i>HL d03</i> Automatic start condition	
401207 - 401208		<i>HL d04</i> Release using control input	
401209 - 401210		<i>HL d05</i> Release time	
401211 - 401212		<i>HL d06</i> Release using fluctuation range	
401213 - 401214		<i>HL d07</i> Release at near-zero	
401215 - 401300		Reserved internally	

Data Address (Holding Register)	R/W	Item	Description
401401 - 401402	R/W	<i>Fr 01</i> Filter of flow rate 1	
401403 - 401404		<i>Fr 02</i> Filter of flow rate 2	
401405 - 401406		<i>Fr 03</i> Damping time for flow rate 1	
401407 - 401408		<i>Fr 04</i> Damping time for flow rate 2	
401409 - 401410		<i>Fr 05</i> +/- flow rate 1	
401411 - 401412		<i>Fr 06</i> +/- flow rate 2	
401413 - 401500		Reserved internally	

6.4. Maintenance

6.4.1. Parameter

When performing maintenance, use the following list as a memorandum.

When making inquiries about the product, inform your local A&D dealer of the user settings.

6.4.1.1. Calibration Functions ([Fnc])

Item Name	Function code	Description, Range and Default value	User setting
[-F01] Unit	1001	[1]: g	
[-F02] Decimal point position	1002	[3]: 0.000	
[-F03] Minimum division	1003	[1]: 1 2: 2 3: 5 4: 10 5: 20 6: 50	
[-F04] Maximum capacity	1004	AD4212L-R50:50000 AD4212L-R100:100000	
[-F05] Zero range	1005	0 to [2] to 100	
[-F06] Zero tracking time	1006	[0.0] to 5.0	
[-F07] Zero tracking width	1007	[0.0] to 9.9	
[-F08] Stability detection time	1008	0.0 to [1.0] to 9.9	
[-F09] Stability detection width	1009	0 to [2] to 100	
[-F10] Tare and zero when unstable	1010	0: Disable both functions [1]: Enable both functions	
[-F11] Tare when the gross weight is negative	1011	0: Disable tare [1]: Enable tare	
[-F12] Output when out of range and unstable	1012	0: Disable output [1]: Enable output	
[-F13] Excessive negative gross weight	1013	[1]: Gross weight < -99999 2: Gross weight < Negative maximum capacity 3: Gross weight < -19d	
[-F14] Excessive negative net weight	1014	[1]: Net weight < -99999 2: Net weight < Negative maximum capacity	
[-F15] Clear the zero value	1015	0: Disable [1]: Enable	
[-F16] Zero when power is turned on	1016	[0]: Disable 1: Enable	
[-F17]	1017	-7.0000 to 7.0000	

Item Name	Function code	Description, Range and Default value	User setting
Input voltage at zero			
[-F 18 Span input voltage	1018	0.0100 to 9.9999	
[-F 19 Span input voltage weight	1019	1 to 100000	
[-F 26 Gravity acceleration of the calibration location	1026	9.7500 to 9.7980 to 9.8500	
[-F 27 Gravity acceleration of the usage location	1027	9.7500 to 9.7980 to 9.8500	
[-F 28 Disable hold function	1028	0: Enable 1: Disable	

6.4.1.2. Linearization Functions (L -F_{nc})

Item Name	Function code	Description, Range and Default value	User setting
L -F 01 Number of input points	1101	0 to 5	
L -F 02 Linear-zero	1102	-7.0000 to 0.0000 to 7.0000	
L -F 03 Setting value for linear 1	1103	0 to 100000	
L -F 04 Span at linear 1	1104	0.0000 to 9.9999	
L -F 05 Setting value for linear 2	1105	0 to 100000	
L -F 06 Span at linear 2	1106	0.0000 to 9.9999	
L -F 07 Setting value for linear 3	1107	0 to 100000	
L -F 08 Span at linear 3	1108	0.0000 to 9.9999	
L -F 09 Setting value for linear 4	1109	0 to 100000	
L -F 10 Span at linear 4	1110	0.0000 to 9.9999	

6.4.1.3. Basics Functions (Fnc F)

Item Name	Function code	Description, Range and Default value	User setting
Fnc01 Key switch disable	1201	0000 to 1111	
Fnc02 [F] key	1202	0: None 1: Manual print command 2: Hold 3: Operation switch 1 4: Operation switch 2 5: Display exchange 6: Tare clear 7: Zero clear 8: Weighing start / Pause / Restart 9: Actual free fall input 10: One shot, Small flow 11: Sequence flow rate monitor 12: mV/V monitor 13: Digital filter 2	
Fnc03 Display update rate	1203	1: 20 times/second 2: 10 times/second 3: 5 times/second	
Fnc04 x display	1204	0: None 1: Zero tracking in progress 2: Alarm 3: Display operation switch status as on or off 4: Near-zero 5: HI output 6: OK output 7: LO output 8: Large flow 9: Medium flow 10: Small flow 11: Over 12: OK 13: Under 14: Full 15: Weighing end 16: In weighing sequence 17: Weighing sequence, error 18: Normal batch/Loss-in-weight, Identification 19 to 24: State of Coil IN 1 to 6 25 to 32: Setting of Coil OUT 1 to 8	

Item Name	Function code	Description, Range and Default value	User setting
<i>Fnc05</i> Digital filter 1	1205	0: None 8:10.0 Hz 16: 0.7 Hz 1: 100.0 Hz 9: 7.0 Hz 2: 70.0 Hz 10: 5.6 Hz 3: 56.0 Hz 11: 4.0 Hz 4: 40.0 Hz 12: 2.8 Hz 5: 28.0 Hz 13: 2.0 Hz 6: 20.0 Hz 14: 1.4 Hz 7: 14.0 Hz 15: 1.0 Hz	
<i>Fnc06</i> Digital Filter 2	1206	0: None 8:10.0 Hz 16: 0.7 Hz 1: 100.0 Hz 9: 7.0 Hz 17: 0.56 Hz 2: 70.0 Hz 10: 5.6 Hz 18: 0.40 Hz 3: 56.0 Hz 11: 4.0 Hz 19: 0.28 Hz 4: 40.0 Hz 12: 2.8 Hz 20: 0.20 Hz 5: 28.0 Hz 13: 2.0 Hz 21: 0.14 Hz 6: 20.0 Hz 14: 1.4 Hz 22: 0.10 Hz 7: 14.0 Hz 15: 1.0 Hz 23: 0.07 Hz	
<i>Fnc07</i> Hold	1207	1: Normal hold 2: Peak hold 3: Averaging hold	
<i>Fnc08</i> Near-zero	1208	-99999 to 10 to 99999	
<i>Fnc09</i> Near-zero comparison weight	1209	1: Gross weight 2: Net weight	
<i>Fnc10</i> Upper limit value	1210	-99999 to 10 to 99999	
<i>Fnc11</i> Lower limit value	1211	-99999 to -10 to 99999	
<i>Fnc12</i> Comparison mass of upper and lower limit	1212	1: Gross weight 2: Net weight	
<i>Fnc13</i> Full	1213	-99999 to 99999	

6.4.1.4. Hold Functions (HLd F)

Item Name	Function code	Description, Range and Default value	User setting
HLd01 Averaging time	1301	0.00 to 9.99	
HLd02 Start wait time	1302	0.00 to 9.99	
HLd03 Automatic start condition	1303	0: Enable 1: Above the near-zero, and stable 2: Above the near-zero	
HLd04 Release using control input	1304	0: Do not release 1: Release	
HLd05 Release time	1305	0.00 to 9.99	
HLd06 Release using fluctuation range	1306	0 to 99999	
HLd07 Release at near-zero	1307	0: Do not release 1: Release	

6.4.1.5. Weighing Sequence Programs (59 F)

Item Name	Function code	Description, Range and Default value	User setting
59 01 Final value	1401	-99999 to 0 to 99999	
59 02 Free fall	1402	-99999 to 0 to 99999	
59 03 Preliminary	1403	-99999 to 0 to 99999	
59 04 Optional preliminary	1404	-99999 to 0 to 99999	
59 05 Over	1405	-99999 to 0 to 99999	
59 06 Under	1406	-99999 to 0 to 99999	
59 07 Weighing mode	1407	0: Disable 1: Normal batch sequence 2: Loss-in-weigh sequence 3: Specifying with control input 4: Specifying with Modbus RTU	
59 08 Automatic free fall correction	1408	0: Disable 1: Moving average of last four times 2: Real-time free fall compensation (fixed coefficient) 3: Real-time free fall compensation (updated coefficient)	

Item Name	Function code	Description, Range and Default value	User setting
59 09 Automatic free fall band	1409	<input type="text" value="0"/> to 99999	
59 10 Active free fall coefficient	1410	Scale: 0.001 second -99.999 to <input type="text" value="0.000"/> to 99.999	
59 11 OK/Over/Under output timing	1411	<input type="text" value="1"/> : Always <input type="text" value="2"/> : In synchronization with weighing end	
59 12 Wait for the weight value to be stable before the judgment	1412	<input type="text" value="0"/> : Disable <input type="text" value="1"/> : Enable	
59 13 Automatic tare at weighing start	1413	<input type="text" value="0"/> : Disable <input type="text" value="1"/> : Enable	
59 21 Flow timeout time	1421	<input type="text" value="0"/> to 600	
59 22 Weighing start input delay time	1422	<input type="text" value="0.0"/> to 60.0	
59 23 Large flow comparison disable time	1423		
59 24 Medium flow comparison disable time	1424	<input type="text" value="0.0"/> to 60.0	
59 25 Small flow comparison disable time	1425		
59 26 Judging delay time	1426	0.0 to <input type="text" value="0.1"/> to 60.0	
59 27 Weighing end output time	1427	<input type="text" value="0.0"/> to 60.0	
59 28 One-shot time for small flow rate	1428	<input type="text" value="0.00"/> to 6.00	

6.4.1.6. Flow Rate Functions (Fr F)

Item Name	Function code	Description, Range and Default value	User setting
Fr 01 Filter of flow rate 1	1901	1 : Digital filter 1	
Fr 02 Filter of flow rate 2	1902	2 : Digital filter 2	
Fr 03 Damping time for flow rate 1	1903	Suppress changes in flow rate. The higher the value setting, the less changes. Scale: 1 second 1 to 5 to 1000	
Fr 04 Damping time for flow rate 2	1904		
Fr 05 +/- flow rate 1	1905	0 : according to calculation 1 : interchange +/- 2 : absolute value	
Fr 06 +/- flow rate 2	1906		

6.4.1.7. Control I/O Functions (Io F)

Item Name	Function code	Description, Range and Default value	User setting	
≡	Io 01 Function of IN1	1601 0 : Disable 1 to 6: Reserved internally 7 : Zero 8 : Tare 9 : Hold	0 to 7 to 28	
	Io 02 Function of IN2	1602 10 : Gross / Net exchange 11 : Diagnose 12 : Print command	0 to 8 to 28	
	Io 03 Function of IN3	1603 13 : Weighing start 14 : Pause 15 : Restart 16 : Emergency stop	0 to 28	
	Io 04 Function of IN4	1604 17 : Error reset 18 : Normal batch/Loss-in-weight exchange 19 : Actual free fall input 20 : One-shot small flow	0 to 28	
	Io 05 Function of IN5	1605 21 : Full open 22 : Zero clear 23 : Tare clear 24 : Operation same as a [F] key	0 to 28	
	Io 06 Function of IN6	1606 25 : Prohibit update of flow rate 1 26 : Prohibit update of flow rate 2 27 : Initialize flow rate 1 28 : Initialize flow rate 2	0 to 28	

Item Name	Function code	Description, Range and Default value	User setting
OUT	10 11 Function of OUT1	1611 0 : Disable 1 to 8 : Reserved internally 9 : Stability 10 : Over capacity	0 to 18 to 37
	10 12 Function of OUT2	1612 11 : Net display 12 : During tare 13 : Hold 14 : Hold busy	0 to 9 to 37
	10 13 Function of OUT3	1613 15 : HI output 16 : OK output 17 : LO output 18 : Near-zero	0 to 37
	10 14 Function of OUT4	1614 19 : Full 20 : Over 21 : OK 22 : Under	0 to 37
	10 15 Function of OUT5	1615 23 : Large flow 24 : Medium flow 25 : Small flow	0 to 37
	10 16 Function of OUT6	1616 26 : Normal batch/Loss-in-weight, Identification 27 : In weighing sequence 28 : Weighing end 29 : Weighing sequence error	0 to 37
	10 17 Function of OUT7	1617 30 : In weighing (ON) 31 : In weighing (1 Hz) 32 : In weighing (50 Hz) 33 : Alarm	0 to 37
	10 18 Function of OUT8	1618 34 : Output operation switch is on or off 35 : Approximate flow rate value of flow rate 1 36 : Approximate flow rate value of flow rate 2 37 : Remote I/O	0 to 37
OUT	10 21 OUT1 Logic	1621 1 : Inverting output If data is "0" level, the output transistor conducts (ON). 2 : Non-inverting output If data is "1" level, the output transistor conducts (ON).	
	10 22 OUT2 Logic		
	10 23 OUT3 Logic		
	10 24 OUT4 Logic		
	10 25 OUT5 Logic		
	10 26 OUT6 Logic		
	10 27 OUT7 Logic		
	10 28 OUT8 Logic		

6.4.1.8. Standard Serial Output Functions ([L F])

Item Name	Function code	Description, Range and Default value	User setting
[L 01 Serial data	1701	1: Weighing display 2: Gross 3: Net 4: Tare 5: Gross / Net / Tare	
[L 02 Communication mode	1702	1: Stream 2: Automatic print 3: Manual print	
[L 03 Baud rate	1703	1: 600 bps 2: 2400 bps	


6.4.1.9. RS-485 Functions (r5 F)

Item Name	Function code	Description, Range and Default value	
r5 02 Communication mode	2102	5: Modbus RTU 6: Interval output at 100 times/second 7: Interval output at 200 times/second 8: Interval output at 500 times/second	
r5 03 Baud rate	2103	5: 9600 bps 7: 38400 bps 6: 19200 bps 8: 115200 bps	
r5 04 Parity	2104	0: None 1: Odd 2: Even	
r5 06 Stop bit length	2106	1: 1 bit 2: 2 bits	
r5 07 Terminator	2107	1: CR (0Dh) 2: CR LF (0Dh, 0Ah)	
r5 08 Slave address	2108	0: None 1 to 99	

7. Specifications


Model	AD4212L-R50	AD4212L-R100
Weighing capacity	51 g	110 g
Maximum display	51.008 g	110.008 g *
Minimum weighing value (1 digit)	0.001 g	0.001 g
Repeatability (Standard deviation)	0.001 g	0.002 g
Linearity	±0.002 g	±0.002 g
Stabilization time in seconds (at an appropriate filter setting in a good environment)	0 to 5 g approx. 0.3 second	0 to 5 g approx. 0.3 second
	5 to 51 g approx. 1.0 second	5 to 110 g approx. 1.3 second
I/O unit	RS-485 (Modbus RTU), conform to USB USB 2.0	
Sampling rate	1000 times / second	
Sensitivity drift	±30 ppm/°C typ	
Zero temperature coefficient	±50 ppm/°C typ	
Operating environment	-10 °C to +40 °C, 85%RH or less (no condensation)	
Weighing pan dimension	φ20.5 mm	
Weighing unit external dimension/mass	30 (W) × 165 (D) × 56 (H) mm/ approx. 400 g	
Display unit external dimension/mass	35.3 (W) × 101.3 (D) × 110 (H) mm/ approx. 200 g	
Cable diameter/length/mass	φ4.5 mm/10 m/ approx. 350 g	
Power voltage	DC24V +10%/-15%	
Power consumption	6W Max	
Memory back up	Nonvolatile memory, data storage duration: 10 years or more	
Ability of the stopper to withstand overload	1 kg	
Allowable moment	0.015 Nm or less	0.03 Nm or less
Specific frequency	65 Hz	95 Hz
Water-proof level (weighing unit)	IP42	
Accessories	RS-485 connector made by 3M: 35505-6200-A00 GF 2 Branch connector made by 3M: 35715-L010-A00 AK 1 Leveling feet 3	

* When exceeding 100 g, all digits blink. The largest digit "1" is not displayed.



Unit: mm

Illustration 10 External dimensions (display unit)



Unit: mm

Illustration 11 External dimensions (weighing unit)



A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013, JAPAN
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-1566

A&D ENGINEERING, INC.

1756 Automation Parkway, San Jose, California 95131, U.S.A.
Telephone: [1] (408) 263-5333 Fax: [1] (408) 263-0119

A&D INSTRUMENTS LIMITED

Unit 24/26 Blacklands Way, Abingdon Business Park, Abingdon, Oxfordshire OX14 1DY United Kingdom
Telephone: [44] (1235) 550420 Fax: [44] (1235) 550485

A&D AUSTRALASIA PTY LTD

32 Dew Street, Thebarton, South Australia 5031, AUSTRALIA
Telephone: [61] (8) 8301-8100 Fax: [61] (8) 8352-7409

A&D KOREA Limited

한국에이.엔.디(주)
서울특별시 영등포구 국제금융로6길33 (여의도동) 맨하탄빌딩 817 우편 번호 07331
(817, Manhattan Bldg., 33. Gukjegeumyung-ro 6-gil, Yeongdeungpo-gu, Seoul, 07331 Korea)
전화: [82] (2) 780-4101 팩스: [82] (2) 782-4264

ООО A&D RUS

ООО "ЭЙ энд ДИ РУС"
121357, Российская Федерация, г.Москва, ул. Верейская, дом 17
(Business-Center "Vereyskaya Plaza-2" 121357, Russian Federation, Moscow, Vereyskaya Street 17)
тел.: [7] (495) 937-33-44 факс: [7] (495) 937-55-66

A&D INSTRUMENTS INDIA PRIVATE LIMITED

509, उद्योग विहार , फेस -5, गुडगांव - 122016, हरियाणा , भारत
(509, Udyog Vihar, Phase-V, Gurgaon - 122 016, Haryana, India)
फोन : 91-124-4715555 फैक्स : 91-124-4715599

ऐ&डी इन्स्ट्रुमेंट्स इण्डिया प्रा० लिमिटेड