

AD-4430C



for CC-Link

DIN Rail Weighing Module

INSTRUCTION MANUAL

The manual and Marks

All safety messages are identified by the following, "WARNING" or "CAUTION", of ANSI Z535.4 (American National Standard Institute: Product Safety Signs and Labels). The meanings are as follows:

 WARNING	A potentially hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	A potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



This is a hazard alert mark.

- This manual is subject to change without notice, at any time, to improve the product.
- The contents of the product specifications and this manual are subject to change without any obligation on the part of the manufacturer.
- Under the copyright laws, the software (program) described in this manual is copyrighted, with all rights reserved.
The software may be installed into one computer and may not be installed into other computers without the prior written consent of A&D Company, Limited. Copying includes translation into another language, reproduction, conversion, photocopying and offer or loan to another person.

Teflon is a registered trademark of DuPont.

© 2019 **A&D Company, Limited** All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, or translated into any language in any form by any means without the written permission of A&D Company, Limited.

Contents

1.	Compliance.....	5
1.1.	Compliance with FCC rules.....	5
1.2.	Compliance with European Directives	5
1.3.	Precautions for Safety Use.....	5
2.	Outline and Features	7
3.	Specifications	8
3.1.	Analog Part (Load cell Input, A/D Converter).....	8
3.2.	Digital Part (Display and Keys).....	8
3.3.	General.....	8
3.3.1.	Interface.....	8
3.3.2.	Weighing Function.....	9
3.3.3.	General.....	9
3.3.4.	Accessories	9
3.3.5.	Dimensions.....	10
3.4.	Names (The Front Panel and Rear Panel)	11
4.	Installing the Module.....	12
4.1.	Conditions to Install the Module	12
4.2.	Power Supply	12
4.3.	Connecting Load Cell Cable.....	13
4.4.	Verifying Load Cell Cable	14
5.	Operations	15
5.1.	General Functions	15
5.1.1.	Zero Operation	15
5.1.2.	Zero Tracking.....	15
5.1.3.	The Tare Function.....	15
5.1.4.	Clearing the Tare Value and Zero Operation.....	16
5.1.5.	Customizing the Function of the F Switch.....	16
5.1.6.	Customizing the Function of the x Display	17
5.1.7.	Memory Backup	17
5.1.8.	The Detection for the Near-Zero	17
5.1.9.	Upper or Lower Limit Detection Function.....	17
5.1.10.	Full Value Detection Function	18
5.1.11.	User I/O (Remote I/O).....	18
5.1.12.	Digital Filter 1 and 2 (F_{nc05} and F_{nc06}).....	19
5.1.13.	The Hold Function.....	20
5.2.	State Diagram And Operation Switches.....	22
5.2.1.	State Diagram.....	22
5.2.2.	Operation Switches	23
5.3.	The Calibration	24
5.3.1.	Outline of the Calibration	24
5.3.2.	The Calibration using Actual Load ($L-5Et$).....	25
5.3.3.	Gravity Acceleration Correction.....	26
5.3.4.	The Linearization Function	27
5.3.5.	The Actual Load Linearization Function ($L-5Et$)	28

5.3.6.	The Calibration Function ($C-Fnc$).....	29
5.3.7.	The Linearization Function ($L-Fnc$)	33
5.3.8.	Error Codes for the Calibration ($C-ErrB$).....	34
5.3.9.	Adjustment of the Load Cell Output	34
5.4.	The List of General Functions	35
5.4.1.	The Procedure to Store New Parameters	35
5.4.2.	The Basics Function ($Fnc-F$).....	36
5.4.3.	The Hold Function ($HLd-F$)	37
5.4.4.	The Weighing Sequence Program Function ($Seq-F$)	38
5.4.5.	The Setpoint Function ($SP-F$).....	39
5.4.6.	The Control I/O Function ($IO-F$)	40
5.4.7.	The Standard Serial Output Function ($CSL-F$).....	41
5.4.8.	The CC-Link Function ($CLL-F$).....	41
5.5.	Batch Weighing	42
5.5.1.	Sequential Weighing.....	43
5.5.2.	Weighing Sequence Error (Output).....	45
5.5.3.	Error Reset (Input).....	45
5.5.4.	One Shot Small Flow (Input)	45
5.5.5.	Full Open (Output).....	45
5.5.6.	Actual Free Fall Input	45
5.5.7.	Automatic Free Fall Compensation.....	46
5.5.8.	Active Free Fall Compensation	46
5.5.9.	Sequence Numbers.....	47
5.6.	Setpoint (Comparator value)	47
6.	Interface	48
6.1.	Control I/O	48
6.2.	Serial Output (Current Loop).....	48
6.2.1.	Data format of Serial Output.....	49
6.2.2.	Transfer Mode of Serial Output.....	50
6.3.	The CC-Link	51
6.3.1.	Address Map	52
6.3.2.	Commands	60
6.3.3.	Timing Chart	61
6.3.4.	The Calibration	63
6.3.5.	Self-Check	64
6.3.6.	Function Settings.....	64
6.4.	USB	65
6.4.1.	Format	65
6.4.2.	Monitoring the Function Setting.....	65
6.4.3.	Storing the Function Setting	66
6.4.4.	Monitoring the Whole Function Settings	66
6.4.5.	Monitoring Each Piece of Data.....	66
7.	Maintenance	67
7.1.	Error Messages	67
7.2.	Check Mode	67
7.2.1.	Entering Check Mode.....	67
7.2.2.	Verifying the Switch Operation	68

7.2.3.	Checking the Control I/O	68
7.2.4.	Checking the Standard Serial Output.....	68
7.2.5.	Checking the CC-Link	68
7.2.6.	Monitoring the A/D Converter (for Load Cell Output)	68
7.2.7.	Monitoring the Internal Value.....	68
7.2.8.	Monitoring the Program Version.....	68
7.2.9.	Monitoring the Serial Number.....	69
7.2.10.	Monitoring the Checksum of the Program	69
7.2.11.	Monitoring the Checksum of an Internal FRAM.....	69
7.2.12.	Displaying Function Parameters for the Calibration	69
7.3.	Initializing Parameters	70
7.3.1.	Initializing Mode for RAM and Function Parameters.....	70
7.3.2.	Initializing All Data.....	70
7.4.	Verifying Load Cell Connections (DIAGNOS)	71
7.4.1.	Guideline to Verify Load Cell Connections.....	71
7.4.2.	Verifying Load Cell Connections with Switch Operation	72
7.4.3.	Verifying Load Cell Connections with the CC-Link.....	72
7.4.4.	Verifying Using Control I/O	72
7.4.5.	Display and Output of Verification	73
7.5.	Verifying Load Cell Connections Using Multimeter	74
7.5.1.	Check List for load cell connections	74
7.6.	The Parameter List For The Function	76
7.6.1.	The Calibration Function (ϵ -Fnc).....	76
7.6.2.	The Linearization Function (L-Fnc)	77
7.6.3.	The Basics Function (Fnc F).....	78
7.6.4.	The Hold Function (Hld F)	80
7.6.5.	The Weighing Sequence Program Function (SQ F).....	81
7.6.6.	The Setpoint Function (SP F).....	82
7.6.7.	The Control I/O Function (IO F).....	83
7.6.8.	The Standard Serial Output Function (ϵ L F).....	84
7.6.9.	The CC-Link Function ($\epsilon\epsilon$ F).....	85

Illustrations

Illustration 1	Dimensions	10
Illustration 2	Front panel & rear panel	11
Illustration 3	Mounting the module.....	11
Illustration 4	Wiring the connectors	12
Illustration 5	Load cell connections (6-wire connection).....	13
Illustration 6	Load cell connections (4-wire connection & direct connection).....	14
Illustration 7	State diagram	22
Illustration 8	Gravity acceleration graph	27
Illustration 9	Digital linearization	27
Illustration 10	Load cell output adjustment	34
Illustration 11	The CC-Link connector	51
Illustration 12	Turning on the display	61
Illustration 13	Requesting initialization from master station	61
Illustration 14	Inputting setpoints (Basic comparator parameters)	62
Illustration 15	Reading command.....	62
Illustration 16	Writing command	62
Illustration 17	Monitoring the CPU signal	63
Illustration 18	Resetting error status flag	63
Illustration 19	Checking the load cell connection	71
Illustration 20	Load cell connection check.....	74

1. Compliance

1.1. Compliance with FCC rules

- Please note that this equipment generates, uses and can radiate radio frequency energy. This equipment has been tested and has been found to comply with the limits of a Class A computing device pursuant to Subpart J of Part 15 of FCC rules. These rules are designed to provide reasonable protection against interference when this equipment is operated in a commercial environment. If this unit is operated in a residential area it may cause some interference and under these circumstances the user would be required to take, at his/her own expense, whatever measures are necessary to eliminate the interference. (FCC = Federal Communications Commission in the U.S.A.)

1.2. Compliance with European Directives

- ☒ This appliance complies with the statutory EMC (Electromagnetic Compatibility) directive 2004/108/EC and the Low Voltage Directive 2006/95/EC for safety of electrical equipment designed for certain voltages.

Note: The displayed value may be adversely affected under extreme electromagnetic influences.

1.3. Precautions for Safety Use


Before use, confirm the following articles for safe operation.

- **Grounding the Module**
Ground the module to the DIN rail certainly. Separate this earth ground line from others, such as ground lines for the motor, inverter or power source. Unless the indicator is grounded, it may result in electric shock, operation error or fire.
- **Proper Power Source and Power Cable**
Confirm the AC voltage, frequency and power tolerance of the power cable. If the voltage range of the cable is lower than the power line voltage, it may cause leakage or catch fire. Use pole compression terminals to connect the power cable to the terminals.
- **Fuse**
The fuse is installed to help prevent the module from catching fire. The module is equipped with many safety circuits, so if the internal circuits are functioning properly, the fuse is not damaged. If the fuse is damaged, do not replace it but contact your local A&D dealer. This may have been caused by strong electric discharge. The fuse must not be relaced by users.
- **Splashing Water**
The module is not water resistant.
- **Flammable Gas**
Do not install the module where flammable gas is present.
- **Heat Radiation of the Module**
Space out instruments to radiate heat sufficiently. Use a cooling fan to keep the operating temperature of the module within specifications.
AD-4430C is covered with a protective transparent-resin cover. After the installation is


complete, take off the protective cover prior to turning on the AD-4430R. Heat damage may be caused if you do not remove the protective cover.

The protective cover is for preventing wire chips when you will install and wire so please do not take off the cover until complete the installing and wiring.

AD-4430C with a protective cover



How to remove the protective cover



2. Outline and Features

The AD-4430C has the following features.

- The AD-4430C is a weighing indicator that amplifies signals from a load cell, converts them to digital data and outputs after converting them to a weighing values.
- This indicator has the following performance:
 - Input sensitivity 0.15 $\mu\text{V}/\text{d}$ (d = minimum division)
 - Display resolution 99,999 d maximum
 - Sampling rate 1000 times/second
 - Input voltage range -35 to +35 mV (-7 to +7 mV/V)
- The CC-Link communication
When connected to the CC-Link (Control & Communication Link) which makes seamless data communication possible, the weighing system can be built on the network, enhancing flexibility and convenience compared to the conventional communication connections.
 - The calibration can be performed using the command of the CC-Link.
 - Monitoring and changing of functions can be performed.
 - Up to 42 indicators can be connected to one master device when multiple AD-4430C are only used.
- Remote I/O function (User I/O)
The remote I/O is a function for the user's arbitrary application to use the control I/O terminals as the remote I/O. External sensors and switches can be monitored and controlled.
- The calibration using gravity acceleration correction
The function compensates for weighing error due to the difference of gravity acceleration between the calibration place and the measurement place.
- The digital linearization function
The digital linearization function can rectify and reduce the deviation using weighing points during the zero and maximum capacity. Up to four weighing points excluding zero point can be specified. The high-order correction curve is used between each point.
- The digital span mode
Simplified calibration is possible using numerical input, even without an actual load.
- Weighing sequence
The AD-4430C can use a normal batch and loss in weight.
- Digital filter
The digital filter is used to prevent electrical signal movement from the load cell. This module has two channels so that each cutoff frequency can be set separately.
 - Digital filter 1 (Fnc05)
 - Digital filter 2 (Fnc06)
- Flow rate (change volume)
The AD4430C can display the current flow rate (change rate) every second.

3. Specifications

3.1. Analog Part (Load cell Input, A/D Converter)

Input sensitivity	0.15 $\mu\text{V}/\text{d}$ or greater (d = minimum division)	
Input voltage range	-35 mV to +35 mV (-7 to +7 mV/V)	
Zero range	-35 mV to +35 mV (-7 to +7 mV/V)	
Load cell excitation voltage	5 VDC $\pm 5\%$, 60 mA with remote sense capability (Maximum 4 x 350 Ω load cells)	
Temperature coefficient	Zero	$\pm 0.02 \mu\text{V}/^\circ\text{C}$ Typ. $\pm 0.1 \mu\text{V}/^\circ\text{C}$ max
	Span	$\pm 3 \text{ ppm}/^\circ\text{C}$ Typ. $\pm 15 \text{ ppm}/^\circ\text{C}$ max
Non-Linearity	0.005% of full scale	
A/D conversion method	Delta-sigma method	
A/D resolution count	Approximately 16,000,000 counts	
Display resolution	99,999 d max. (d = minimum division)	
Sampling rate	1000 times/second	

3.2. Digital Part (Display and Keys)

Display element	Measurement display	5-digit 7-segment red LED
	Status indicators	6 red LEDs
Measurement display	Numerical display	Switches between NET and GROSS
	Decimal point	Selectable decimal places (10 ¹ , 10 ² , 10 ³ , 10 ⁴)
	Overflow display	All the digits turn OFF. (When the polarity is negative, the minus sign appears at the highest-order digit.)
Status indicators	G: GROSS, N: NET, H: HOLD, S: STABLE, Z: ZERO, X: Preset function selected from the function list.	
Key switches	F/ESC, → (ZERO), ↑ (TARE), ENT	

3.3. General

3.3.1. Interface

Interface	Specification	Connector
Control I/O	Refer to "6.1. Control I/O"	MDR connector 20 pins female Connector is not included
Standard serial output	Refer to "6.2. Serial Output (Current Loop)"	
CC-Link	Refer to "6.3. The CC-Link"	Power clamp connector (3M)
USB	USB 2.0 (High-speed)	Micro-B Cable is not included

3.3.2. Weighing Function

Zero operation	Sets the gross weight to zero by pressing the →(ZERO) key. Selection of disable or enable for the operation when unstable. The zero value is stored in the nonvolatile memory (FRAM). Zero adjustable range : Can be set optionally in the range of 1 to 100% of the maximum capacity.
Zero tracking	Tracks the weight drift around the zero point to maintain zero. Zero tracking time : 0.0 to 5.0 sec. Can be set optionally within the range Zero tracking band : 0.0 to 9.9 d Can be set optionally within the range
Tare	Sets the net weight to zero by pressing the ↑(TARE) key. The inhibition / permission switch of the tare function can be used when the weighing value is unstable and negative. The tare value is stored in the nonvolatile memory (FRAM). Tare range : Gross weight ≤ Maximum capacity
Stability detection	Turns ON the stabilization indicator S when the variation amount of the weight values per sampling are within the set band in the set time. Detection time : 0.0 to 9.9 sec. Can be set optionally within the range Detection band : 0 to 9d Can be set optionally within the range
Digital filter 1	Cutoff frequency (-3 dB) range : 0.7 to 100 Hz
Digital filter 2	Cutoff frequency (-3 dB) range : 0.07 to 100 Hz
Zero detection	Non loading can be detected as near-zero and it is output.
HI/LO limit detection	Compares the measurement with HI/OK/LO limits and outputs the results.
Hold function	Displays the measurement value held. Select from sample hold, peak hold, average hold.
Weighing sequence function	Normal batch, Loss in weight.


3.3.3. General

Memory backup method	Nonvolatile memory, data storage duration: 10 years or more
Power source (DC power)	DC 24 V, +10%, -15%
Power consumption	6 W at maximum
Operating temperature Operating humidity	-10 °C to +50 °C, 85 %RH or less (no condensation)
Installation method	DIN rail mount
Mass	Approximately 200 g

3.3.4. Accessories

Item	Quantity	Model name
CC-Link connector	1	Power clamp wire mount socket, 3M, 35505-6000-B0M GF

3.3.5. Dimensions



Unit : mm

Illustration 1 Dimensions

3.4. Names (The Front Panel and Rear Panel)




Illustration 2 Front panel & rear panel




Illustration 3 Mounting the module

4. Installing the Module

In this section, installation environment, power terminal and load cell cable, and how to connect them are explained. Refer to each chapter for other external I/O.

4.1. Conditions to Install the Module

- The module is a precision electronic instrument. Handle it carefully.
- The operating temperature is $-10\text{ }^{\circ}\text{C}$ to $+50\text{ }^{\circ}\text{C}$.
- Do not install the module in direct sunlight.

4.2. Power Supply

⚠CAUTION

- Earth ground the module to prevent electrical shock or indicator malfunction. If the module is not grounded, it may cause of an electric shock, or malfunction due to static electricity.

- Before connecting the module to the power source, read the instruction manual thoroughly.
- Do not turn the power for the module on before the installation is complete.
- ⚠□ To avoid electrical shock, do not handle the power cable with wet hands.
- ⚠□ Earth ground the module. Do not share the ground line with other electrical power equipment.
- The power requirement is 24 DCV, $+10\%$ to -15% .
Use a stable power source free from instantaneous power failure or noise.
- To avoid a malfunction, do not share the power line with other devices.
- The output voltage of a load cell is a very sensitive signal. Keep all electrical noise sources away from the load cell and load cell cable.
- Use cables shielded for input and output. Connect the cable shield to the F.G. terminal or the module housing.
- Ground terminal. (Connector shields of all are connected inside.)




Illustration 4 Wiring the connectors

The Conductor Specifications

Clamp range (typ.)		0.13 mm ² to	1.5 mm ²
AWG		AWG24 —	AWG16
Solder plated wire		0.2 mm ² to	1.5 mm ²
Twisted wire		0.2 mm ² to	1.5 mm ²
Rod crimp terminal	DIN 46228 Part1	0.25 mm ² to	1.5 mm ²
Rod crimp terminal with cover	DIN 46228 Part4	0.25 mm ² to	0.75 mm ²
Lead length		8 mm	

4.3. Connecting Load Cell Cable

Load Cell

- The cable that extends from the load cell is a part of the load cell. Do not cut the load cell cable even if there is the remainder of the cable.
- Bundle the load cell cable if there is the remainder of the cable.
- The load cell is compensated for temperature change including the resistance value of this cable.
- Basically, connect the shield wire to a point of the shield terminal of the AD-4430C and do not ground it. If there are multiple ground points, it may result in noise due to a ground loop.

Remote Sensing (Compensation for length of the extension cable)

- The AD-4430C is equipped with the compensation function that monitors a drop voltage for the excitation voltage and rectifies the A/D conversion value.
- Use the 6-wire extension cable to use the remote sensing function for the load cell.
- Connect terminals of SEN+ and SEN-. If they are not connected, measurements cannot be performed.
- When the 4-wire cable is used, connect terminals of EXC+ and SEN+ and terminals of EXC- and SEN- at the load cell terminal of the AD-4430C.

Load Cell Cable

- Load cell cables should have high electrical insulation and shield performance.
- Use shielded cables with the insulator that is made of materials with high insulation resistance such as Teflon and polyethylene. **NOTE: Teflon is a registered trademark of DuPont.**
- We recommend using the load cell extension cable produced by A&D co., ltd. when using it. AX-KO162-5M to 100M (5m to 100m)

Cable diameter.....φ9 mm

Cross-sectional area of the conducting wire0.5 mm², 6-wire cable equipped

Terminal No.	Terminal name & Function of the AD-4430C	
7	SIG-	Load cell input (-)
6	SIG+	Load cell input (+)
5	EXC-	Load cell excitation voltage (-)
4	SEN-	Sensing input (-)
3	SEN+	Sensing input (+)
2	EXC+	Load cell excitation voltage (+)
1	SHLD	Shield

6-wire connection to load cell (Recommended)





Illustration 5 Load cell connections (6-wire connection)

4-wire connection to load cell



Direct connection to load cell




Illustration 6 Load cell connections (4-wire connection & direct connection)

4.4. Verifying Load Cell Cable

When the load cell connection is complete, perform a connection check using the following procedure.

- Perform a visual check to ensure that the wiring is correct.
- Turn the module on.
When the calibration has not yet been carried out, the indication value may be blank. However, as long as there are no problems with the display, confirmation can still be carried out using the check mode.
- Enter to the check mode and check the load cell output value.
Refer to "7.2.Check Mode" to enter to the A/D check mode.
- Confirm that the displayed load cell output value matches the specified value. Normally the displayed value will be the load cell rated output value or less.
- If an error occurs, refer to "7.4. Verifying The Load Cell Connections (DIAGNOS)" or "7.5. Verifying The Load Cell Connections Using Multimeter".

5. Operations

5.1. General Functions

5.1.1. Zero Operation

- Zero operation is a function to set the gross weight to zero. It is performed by pressing the **→(ZERO)** key.
- The zero range is set in **C-F05** (Zero range) and is expressed in percent of the maximum capacity with the calibration zero point as the center.
- Zero operation is disabled, even within the zero range, when the A/D converter overflow occurs.
- A ZERO error is output if zero operation is not performed when the value is unstable or out of range.
- The zero value is stored in the non-volatile memory and is maintained, even if the power is disconnected.
- Clearing the zero value is performed using the **F** key assigned to clear the zero value.
- **Functions Related to Zero Operation**
 - **C-F05** (Zero range) : A value between 0% and 100% can be specified.
 - **C-F10** (Tare and zero at unstable weight value) : The selection to enable or disable tare and zero operation when unstable.
 - **C-F16** (Zero setting when power is turned on) : The selection whether or not to perform zero setting when power is turned on.

5.1.2. Zero Tracking

- The zero tracking function traces the gross weight drift around the zero point to maintain zero.
- The zero tracking time is set in **C-F06** (Zero tracking time) and the zero tracking band is set in **C-F07** (Zero tracking band). When the gross weight drift is within the specified ranges, zero tracking is performed automatically.
- A ZERO error is not output even if zero tracking is not performed.
- **Functions Related to Zero Tracking**
 - **C-F06** (Zero tracking time) : The value between 0.0 and 5.0 seconds can be specified.
 - **C-F07** (Zero tracking band) : The value between 0.0 and 9.9 d can be specified. (d = minimum division)

5.1.3. The Tare Function

- Tare is a function to store the gross weight as the tare value and set the net weight to zero. It is performed by pressing the **↑(TARE)** key.
- The tare value is stored in the non-volatile memory and is maintained, even if the power is disconnected.
- Clearing the tare value is performed using the **F** key assigned to clear the tare value.
- **Functions Related to the Tare Function**
 - **C-F10** (Tare and zero at unstable weight value) : The selection to enable or disable tare and zero operation when unstable.
 - **C-F11** (Tare when the gross weight is negative) : The selection to enable or disable tare when the gross weight is negative.

5.1.4. Clearing the Tare Value and Zero Operation

To clear the tare value and zero operation, hold the **↑(TARE)** key and turn on the module. Or: In off mode, hold the **↑(TARE)** key and press the **ENT** key.

5.1.5. Customizing the Function of the F Switch

- Assign a function to the **F** key in the general functions.
- **Functions Related to the F Key**
 - Assigns a function to the **F** key from the functions of **Fnc02** (**F** key) below :

0: None	7: Zero clear
1: Manual print command	8: Weighing start / Pause / Re-start
2: Hold	9: Actual free fall input
3: Alternative switch (Active F key)	10: One shot, Small flow
4: Momentary switch (Active F key)	11: Flow rate monitor (Change volume)
5 : Display exchange	12: mV/V monitor
6: Tare clear	13: Digital filter 2

5 means factory settings.
 - **C-F15** (Clear the zero value) : The selection to enable or disable clearing the zero value.

Alternate switch and momentary switch

By assigning these switches to the **F** key, the ON/OFF status of the **F** key can be transmitted to the master station. This is useful when building a network or performing maintenance. When "Active **F** key" is specified to the function of the display x, the operation of the **F** key can be monitored by the display x. These switches work as follows :

Alternate switch

When pressing and releasing the switch once, the state of the switch is maintained. Press the switch again to turn off or on.

Momentary switch

Only while the switch is being pressed, the switch is ON. When it is released, it is OFF.

Additional monitor

For confirmation, the AD-4430C can display weighing data or other data. The decimal point of other data is flashed to separate weighing data, both LEDs of G: gross and N: Net are lit. When pressing the **F** key again, the AD-4430C returns to weighing mode.

Flow rate (Change rate)	Flow rate (Change rate) per second.
mV/V	Output voltage of load cell in the unit of mV/V.
Digital filter 2	Response of weighing data by digital filter 2

5.1.6. Customizing the Function of the x Display

- Assign a function to the x display in the general functions.
- **Functions Related to the Display x**
 - Assigns a function to the x display from the functions of **Fnc04** (x display) below :

0: None	11: Over
1: Zero tracking in progress	12: OK
2: Alarm (Zero range setting error, over)	13: Under
3: Active <input type="checkbox"/> key	14: Full value
4: Near-zero	15: Weighing sequence, finished
<input type="checkbox"/> : HI output (Over the upper limit value)	16: Weighing sequence, in processing
6: OK output (Between upper and lower limit values)	17: Weighing sequence, error
7: LO output (Below the lower limit value)	18: Normal batch / Loss-in weight, Identification
8: Large flow	
9: Medium flow	19 to 24: User input1 to 6
10: Small flow	25 to 32: User output 1 to 8
 - means factory settings.

key status
When alternate switch or momentary switch is selected at **Fnc02**, the works.
The display turns ON when the key is ON and turns OFF when the key is OFF.

5.1.7. Memory Backup

- Zero value, tare value, display status, calibration data and function data are written into non-volatile memory. The data retention period is more than 10 years. This module is not equipped with a battery for memory backup.

5.1.8. The Detection for the Near-Zero

- Near-zero detects whether an object has been placed on the weighing pan.
The near-zero state is defined when the weighing value is within the preset value for the near-zero range.
- **Related functions**
 - **Fnc08** (Near-zero): The value of near-zero.
 - **Fnc09** (Near-zero comparison weight): Selection of the gross weight or net weight to compare the value of near-zero.

1: Gross weight	2: Net weight
-----------------	---------------

5.1.9. Upper or Lower Limit Detection Function

- This function detects whether the weighed value is above an upper limit value or below a lower limit value.
- **Related Functions**
 - Comparative upper or lower limit values can be set with **Fnc10** (Upper limit value) or **Fnc11** (Lower limit value).

Result of Detection	Required value
HI	Weighing value > Upper limit value
OK	Upper limit value \geq Weighing value \geq Lower limit value
LO	Lower limit value > Weighing value

- **Fnc12** (Comparison mass of upper and lower limit): Select value to be compared with the upper or lower limit from gross weight or net weight.
1: Gross weight 2: Net weight

5.1.10. Full Value Detection Function

The full value detection function detects that a weighing value has reached the maximum value.

- **Functions Related to the Detection Function**
 - **Fnc13** (Full): The comparative value of the full value can be preset.
For information on detection conditions, refer to "5.5.1. Sequential Weighing".

5.1.11. User I/O (Remote I/O)

User I/O (user input and user output) can be used for the user's arbitrary application and is not directly related to the weighing system. Therefore it can turn on the control output using a command on the interface and can check the state of the control input terminal.

- **Example 1. of Use**
We want to monitor a photo sensor using the PLC, but, there is not an input port.
 - Assign a control input terminal to user input. Connect a photo sensor to this terminal.
 - Monitor this terminal connected to the photo sensor using user I/O of the CC-Link.
- **Example 2. of Use**
We want to control a relay using remote operation by the PLC, but, there is no output port.
 - Assign a control output terminal to user output. Connect a relay to this terminal.
 - Control this terminal connected to relay using user I/O of the CC-Link.
- **Example 3. of Use**
We want to monitor a controlled relay by the PLC on the front panel of the AD-4430C.
 - Assign a control output terminal to user output. Connect a relay to this terminal.
 - Assign a monitored output terminal to the display x.

5.1.12. Digital Filter 1 and 2 (Fnc05 and Fnc06)

The AD-4430C has two digital filters. The cutoff frequency setting range is different for each.


- Digital filter 1 (Fnc05: None, 100.0Hz (high) to 0.7Hz (low))
- Digital filter 2 (Fnc06: None, 100.0Hz (high) to 0.07Hz (low))




Setting cutoff frequency

The cutoff frequency is the frequency where the vibration starts to decline.


- If the weighing value is unstable, lower the cutoff frequency.
(Response rate is slow. Resistant to disturbance.)
- To make the response faster, higher the cutoff frequency.
(Response rate is fast. Susceptible to disturbance.)

It is possible to make adjustments while watching the effects of the digital filter.

Press the  key while setting values as shown in Step 4 in "5.7.1.Setting" to check the weight displayed.

- The  key changes the cutoff frequency. You can check the setting value on the LED status indicator (binary number).
- The  key returns to the value setting display. (The setting value changed above using the  key will be displayed)


The digital filter flow chart is shown below.



5.1.13. The Hold Function

- There are three types of hold functions which can be used for different purposes.
- **Normal hold**
The normal hold function holds the value displayed at the time the hold command was received.
- **Peak hold**
The Peak hold function holds the maximum value reached after the hold command was received. The value will be refreshed if it increases again.
- **Averaging hold**
The averaging hold function averages weighing data over a certain period of time and then holds the result. It is useful for measuring things that are difficult to weigh such as an animal that won't settle down, or for averaging out the weight of an object in an unstable state. In addition, it can reduce the effects of breezes which the digital filter cannot eliminate.
- **Functions Related to the Hold Function**
 - **Fnc07(Hold)** : The type of hold function can be selected.
 - To set operating conditions for the hold function, set the averaging time length, standby time, or start and stop conditions with **HLd01** to **HLd07**. (Will not affect normal holds)

Peak hold




T_1 : Time set for the start wait time in **HLd02**. Scale: 0.01 sec. Range 0.00 to 9.99 sec.

*1 : Each additional hold input resets the start wait time.

*2 : When the hold value is updated, the hold (output) and the hold busy signals turn on and off.

(The hold busy variation depends on the change of the mass value).

Averaging hold



T1 : Time set for the start wait time in **Hld02**. Scale: 0.01 sec. Range 0.00 to 9.99 sec.

T2 : Time set for the averaging time in **Hld01**. Scale: 0.01 sec. Range 0.00 to 9.99 sec.

*1 : Each additional hold input resets the start wait time.

5.2. State Diagram And Operation Switches

5.2.1. State Diagram

The nonvolatile memory always stores either OFF mode or other mode. It starts from the following state depending on the mode that has been kept when the automatic power is on.

- OFF mode (standby) : Starts from OFF mode.
- Other mode : Starts from Weighing mode.

State diagram can be switched as follows.




Illustration 7 State diagram

5.2.2. Operation Switches

Key	State	Function and Use
F	Weighing mode	The display switch between gross and net in factory setting. The function key to able to select an arbitrary function and use.
	Setting mode	The ESC key.
→	Weighing mode	The zero key to perform the zero operation.
	Setting mode	The key to change a selected item or move a flashed figure.
↑	Weighing mode	The tare key.
	Setting mode	The key to select parameter or increase number.
ENT	Weighing mode	The key to turn the module off when pressing and holding the key.
	OFF state (Standby)	The key to turn the module on.
	Setting mode	The key to store new settings.
ESC	Weighing mode	The function key (F key) to be selected the function and use.
	Setting mode	The return key or escape key.
ENT + F	Weighing mode	The keys to proceed to the function mode from weighing mode.
→ + ENT	Setting mode	The keys to proceed to the check mode from function mode.
F + ENT	OFF state (Standby)	The keys to proceed to the calibration mode from OFF state (Standby).

5.3. The Calibration

5.3.1. Outline of the Calibration

In the calibration mode, operations relating the load cell output voltage to the weighing value can be performed as well as operations directly related to weighing can be performed.

The calibration using actual load	<p>The calibration is performed using a calibration weight.</p> <ul style="list-style-type: none"> ■ Zero calibration : Press ENT key when no load is applied. ■ Span calibration : Enter the calibration weight value and place the calibration weight. <p>When the module enters the calibration mode using an actual load, the tare value and the zero value will be automatically cleared.</p>
Digital span	<p>The calibration is performed without an actual load by numerical input of the load cell output voltage (mV/V). Set these functions related to the calibration.</p> <ul style="list-style-type: none"> ■ Zero input voltage : Numerical input of the load cell output at zero. ■ Span input voltage : Numerical input of the load cell output of span. (Load cell output at full capacity – load cell output at zero) ■ The calibration weight value of span : Numerical input of the calibration weight value corresponding to the span input voltage. (These values relate the span input voltage and the calibration weight value.)
Gravity acceleration correction	<p>The span error is calculated and corrected when gravity acceleration between the calibration location and use location is different.</p>
Digital linearization	<p>The nonlinearity correction function to correct weighing errors that occur halfway between the zero point and maximum capacity. Up to 4 points can be input in addition to the zero point, and the intervals between each point will be calculated using curves.</p>
Function related to the calibration	<p>The function stores basic parameters of the module such as the minimum division and maximum capacity and other data directly related to weighing is performed. Digital span calibration and gravity acceleration correction setting are also performed here.</p>
All data initialization	<p>All the data such as zero value, tare value, calibration data and function data are initialized.</p>

- All the parameters in the calibration mode are stored in the FRAM.
- Actual load calibration and digital span can be mixed.
Example: For the zero calibration, an actual load is used. For the span calibration, the digital span is used.

5.3.2. The Calibration using Actual Load (C - S E t)

The calibration using actual load (C - S E t) is performed using a calibration weight. When performing the calibration for the first time, preset **C-F01** (Unit), **C-F02** (Decimal point position), **C-F03** (Minimum division) and **C-F04** (Maximum capacity) related to the calibration.

Note To avoid drift caused by changes in temperature, warm up the indicator for ten minutes or more before performing the calibration with an actual load.

Step 1 In the OFF mode (Standby), Press the **F** + **ENT** key to enter to the calibration mode and display **CAL**.

CAL

Step 2 Press the **ENT** key to start the calibration and display **C - S E t**. To return to the weighing mode, press the **ESC** key.

C - S E t

Zero Calibration

Step 3 Press the **ENT** key to display **CAL 0**.

CAL 0

If zero calibration is not to be performed, press the **↑** key and proceed to **Step 5**. To check the current weighing value, press the **→** key. When pressing the **↑** key again, **CAL 0** is display.

Step 4 Wait for the stabilization (**S** LED). Press the **ENT** key.

----- is displayed for approximately two seconds. If span calibration is not performed, press the **ESC** key twice to return to the weighing mode.

Span Calibration

Step 5 Press the **ENT** key when **C - S P n** is displayed. The calibration weight value (the current maximum capacity) is displayed and the least digit of the value blinks. Correct the value using the **→** and **↑** key so as to be the value of the calibration weight used. If span calibration is not performed, press the **ESC** key three times to return to the weighing mode.

C - S P n

02000

03000

Example

Step 6 Place the calibration weight on the pan. Wait for the stabilization (**S** LED). Press the **ENT** key. **-----** is displayed for approximately two seconds.

Step 7 **C - E n d** is displayed.

C - E n d

Step 8 Press the **ESC** key. **C - S E t** is displayed and the calibration data is stored in the nonvolatile memory.

C - S E t

Step 9 The current state is the same as that of **Step 2**.

To return to the weighing mode, press the **ESC** key.

- If **C E r X** is displayed, an error has occurred. Refer to “5.3.8. Error Codes for the Calibration” to take corrective action. X : error number.
- The blinking decimal point means that the current value is not the weight value.

5.3.3. Gravity Acceleration Correction

- When the scale (weighing indicator) has been calibrated in the same place as it is being used, gravity acceleration correction is not required.
- A span error will appear if gravity accelerations are different between the calibration place and the use place. The gravity acceleration correction calculates and corrects this span error by these gravity acceleration correction values for both points (the calibration place and use place).

Note When the span is calibrated using actual load, the gravity acceleration correction settings are cleared, and the two gravity acceleration settings return to their default values.

- **Functions Related to the Gravity Acceleration Correction**
 - **C-F26** (Gravity acceleration of the calibration place):

The gravity acceleration where the module has been calibrated.
 - **C-F27** (Gravity acceleration of use place):

The gravity acceleration where the module is being used.

Gravity Acceleration Table

Amsterdam	9.813 m/s ²	Manila	9.784 m/s ²
Athens	9.800 m/s ²	Melbourne	9.800 m/s ²
Auckland NZ	9.799 m/s ²	Mexico City	9.779 m/s ²
Bangkok	9.783 m/s ²	Milan	9.806 m/s ²
Birmingham	9.813 m/s ²	New York	9.802 m/s ²
Brussels	9.811 m/s ²	Oslo	9.819 m/s ²
Buenos Aires	9.797 m/s ²	Ottawa	9.806 m/s ²
Calcutta	9.788 m/s ²	Paris	9.809 m/s ²
Chicago	9.803 m/s ²	Rio de Janeiro	9.788 m/s ²
Copenhagen	9.815 m/s ²	Rome	9.803 m/s ²
Cyprus	9.797 m/s ²	San Francisco	9.800 m/s ²
Djakarta	9.781 m/s ²	Singapore	9.781 m/s ²
Frankfurt	9.810 m/s ²	Stockholm	9.818 m/s ²
Glasgow	9.816 m/s ²	Sydney	9.797 m/s ²
Havana	9.788 m/s ²	Tainan	9.788 m/s ²
Helsinki	9.819 m/s ²	Taipei	9.790 m/s ²
Kuwait	9.793 m/s ²	Tokyo	9.798 m/s ²
Lisbon	9.801 m/s ²	Vancouver, BC	9.809 m/s ²
London (Greenwich)	9.812 m/s ²	Washington DC	9.801 m/s ²
Los Angeles	9.796 m/s ²	Wellington NZ	9.803 m/s ²
Madrid	9.800 m/s ²	Zurich	9.807 m/s ²




Illustration 8 Gravity acceleration graph

5.3.4. The Linearization Function

Outline

Even if zero and span calibration have been performed, weighing errors may occur between the zero point and maximum capacity. The digital linearization ($L - 5ET$) is a corrective function designed to non-linearly correct weighing errors.

- It is possible to input up to four points in addition to the zero point.
- The zero point and each input point will be corrected to put them in a straight line.
- Areas between input points that could not be corrected completely with straight line correction or with secondary correction will be corrected using a curved line derived from high-order equations.
- When the actual load input for digital linearization is performed, the calibrated data will be refreshed using zero point and final input point data. It is not necessary to calibrate again.




Illustration 9 Digital linearization

5.3.5. The Actual Load Linearization Function (L-SEt)

Set the digital linearization by loading/unloading masses.

- Warm up the module for at least ten minutes to avoid the effects of temperature drift.
- The input order should proceed from the smallest mass to the largest mass.

Step 1 Press the **[F]** + **[ENT]** key to enter to the calibration mode and display **[CAL]**. Press the **[ENT]** key to start the calibration and display **[L-SEt]**. Select **[L-SEt]** using the **[↑]** key and press the **[ENT]** key.

CAL

L-SEt

L-SEt

Step 2 **[Lnr 0]** is displayed.

If monitoring the current weighing value, press the **[→]** key. When pressing the **[→]** key again, **[Lnr 0]** is display.

Lnr 0

Step 3 Wait for the stabilization (**S** LED). Press the **[ENT]** key. **[-----]** is displayed for approximately two seconds.

Step 4 **[Lnr 1]** is displayed.

If you want to check the current weighing value, press the **[→]** key. When pressing the **[→]** key again, **[Lnr 1]** is displayed. Press the **[ENT]** key. The weight value (the current maximum capacity) is displayed and the least digit of the value blinks. Correct the value using the **[→]** and **[↑]** key so as to be the weight value used.

Lnr 1

02000

00100

Sample

Step 5 Place the weight on the pan. Wait for the stabilization (**S** LED). Press the **[ENT]** key. **[-----]** is displayed for approximately two seconds.

Step 6 **[Lnr 2]** is displayed. Repeat step 4 and step 5. The procedure proceeds in order of **[Lnr 3]** → **[Lnr 4]** → **[L-End]**.

Lnr 2

L-End

Step 7 Proceed to step 8 to finish the input operation. If you re-input the digital linearization, select the input point using the **[↑]** key. All data following the new input point will be cleared.

Step 8 Press the **[ESC]** key. **[L-SEt]** is displayed and the inputted data will be stored in the nonvolatile memory. At the same time, the calibrated data is also refreshed. Press again the **[ESC]** key to return to weighing mode.

L-SEt

- When **[E Er x]** is displayed, an error will occur. **x** : error number. Refer to "5.3.8. Error Codes for the Calibration" for details.
- The blinking decimal point means that the current value is not the weight value.

5.3.6. The Calibration Function (CAL)

Step 1 Press the **F** + **ENT** key to enter to the calibration mode and display **CAL** .
 Press the **ENT** key to start the calibration and display **C-Set** .
 Press the **ESC** key to return to weighing mode.

Step 2 Select **C-Fnc** using the **↑** key and press the **ENT** key.

Step 3 Select a desired function item (a function group name with function number) using the **↑** key and press the **ENT** key.
 The current data is displayed.

Step 4 When changing data, two methods of parameter selection and digital input depending on the function are available.

Type	Description of method to change data
Parameter selection	Only the available parameter is displayed and blinks. Select a number using the ↑ key.
Digital input	All the digits are displayed. A digit to be changed blinks. Select a digit using the → key and change the value using the ↑ key.

After changing data, press the **ENT** key. The next function number is displayed.
 When the value is not to be changed, press the **ESC** key to return to the function number display.

Step 5 Press the **ESC** key to store new data in FRAM and **C-Fnc** is displayed.
 Press again the **ESC** key to return to the weighing mode.

- The blinking decimal point means that the current value is not the weight value.
- If digital input data is out of range, **Errdt** is displayed, and the data is canceled.
- The function code on the next page is used for commands of the CC-Link and USB.

Item Name	Function code	Description, Range and Default value
C-F01 Unit	1001	0 : Not used 1 : g 2 : kg 3 : t 4 : N 5 : kN
C-F02 Decimal point position	1002	Decimal point position of the weighting value 0 : 0 1 : 0.0 2 : 0.00 3 : 0.000 4 : 0.0000
C-F03 Minimum division	1003	Minimum division (d) of the weighting value 1 : 1 2 : 2 3 : 5 4 : 10 5 : 20 6 : 50
C-F04 Weighing capacity	1004	Maximum capacity of the module. Weighing is possible up to the value of this setting plus 8 digits. If the value exceeds this, overflow will occur and will not be displayed. #1 1 to 70000 to 99999
C-F05 Zero range	1005	The range to enable zero operation by the → (ZERO) key expressed as a percentage of the maximum capacity with the calibration zero point as the center. For example, if 2 is set, the value in the range of ±2% of the maximum capacity with the center at the calibration zero point will be to zero. When a power-ON zero is performed, the initial zero point will be the center. 0 to 2 to 100
C-F06 Zero tracking time	1006	Performs zero tracking using this setting in combination with the setting of C-F07 . When C-F06 stores 0.0, zero tracking will not be performed. Scale : 0.1 seconds. 0.0 to 5.0
C-F07 Zero tracking width	1007	Performs zero tracking using this setting in combination with the setting of C-F06 . When C-F07 stores 0.0, zero tracking will not be performed. Scale : 0.1 d (minimum division). 0.0 to 9.9

When **C-F06 = 1.0**, **C-F07 = 4.5**

Zero tracking follows the weight value drifting around the zero point and adjusts to display as zero.

d = minimum division = 1 digit

When **C-F06 = 2.0**, **C-F07 = 0.5**

Zero tracking functions when the weight value is drifting within the range shown in the graph.

#1: The decimal point position depends on **C-F02** (Decimal point position).

□ The function code on the next page is used for commands of the CC-Link and USB.

Item Name	Function code	Description, Range and <input type="text" value="Default value"/>
C-F08 Stability detection time	1008	Performs stability detection using this setting in combination with the setting of C-F09 . When C-F08 stores 0.0, stability detection will not be performed. (Stable all the time) Scale : 0.1 seconds. 0.0 to <input type="text" value="1.0"/> to 9.9
C-F09 Stability detection width	1009	Performs stability detection using this setting in combination with the setting of C-F08 . When C-F09 stores 0, stability detection will not be performed. (Stable all the time) Scale : 0.1 d (minimum division). 0 to <input type="text" value="2"/> to 9
<p>Stability detection outputs the STABLE signal when changes in the weight value are within a certain range during a certain time.</p>		
C-F10 Tare and zero at unstable weight value	1010	Tare and zero operation when unstable 0 : Disables both functions. <input type="text" value="1"/> : Enables both functions.
C-F11 Tare when the gross weight is negative	1011	Tare when the gross weight is negative. 0 : Disables tare. <input type="text" value="1"/> : Enables tare.
C-F12 Output when out of range and unstable	1012	Standard serial output when the weight value overflows or is unstable. 0 : Disables output. <input type="text" value="1"/> : Enables output.
C-F13 Exceeding negative gross weight	1013	To judge when the negative gross weight is exceeded. <input type="text" value="1"/> : Gross weight < -99999 2 : Gross weight < Negative maximum capacity 3 : Gross weight < -19 d
C-F14 Exceeding negative net weight	1014	To judge when the negative net weight is exceeded. <input type="text" value="1"/> : Net weight < -99999 2 : Net weight < Negative maximum capacity
C-F15 Clear the zero value	1015	Select whether or not to clear the zero value. 0 : Disables. <input type="text" value="1"/> : Enables.
C-F16 Zero setting when power is turned on	1016	Select whether or not to perform zero setting when power is turned on. <input type="text" value="0"/> : Not used. 1 : Use.

Item Name	Function code	Description, Range and <input type="text" value="Default value"/>
C-F17 Input voltage at zero	1017	Input voltage from a load cell at zero. Scale : mV/V. This value is determined in zero calibration during the calibration with an actual load. Scale : 0.0001 mV/V. -7.0000 to <input type="text" value="0.0000"/> to 7.0000
C-F18 Span input voltage	1018	Input voltage from a load cell at span. This value and the value of C-F19 are determined in span calibration during the calibration with an actual load. Scale : 0.0001 mV/V. 0.0100 to <input type="text" value="3.2000"/> to 9.9999
C-F19 Weight against span Input voltage	1019	The calibration weight value corresponding to the input voltage at span of C-F18 . When performing digital span, C-F17 , C-F18 and C-F19 are required for the calibration. #1 1 to <input type="text" value="32000"/> to 99999
<p>NOTE:</p> <p>*1 Record the setting values of C-F17, C-F18 and C-F19 in the "Function list" at the end of the manual to prepare against a malfunction.</p> <p>*2 By changing the parameters of C-F17, C-F18 and C-F19, "Zero calibration" and "Span calibration" can be adjusted optionally. (Digital span accuracy approximately 1/5000. The accuracy varies depending on the load cell output accuracy and the conditions of the calibration.)</p> <p>Caution Excluding emergencies, perform the calibration with an actual load.</p>		
C-F26 Gravity acceleration of the calibration place	1026	Gravity acceleration of the place where the scale is calibrated. Scale : 0.0001 m/s ² . 9.7500 to <input type="text" value="9.8000"/> to 9.8500
C-F27 Gravity acceleration of use place	1027	Gravity acceleration of the place where the scale is being used. Scale : 0.0001 m/s ² . 9.7500 to <input type="text" value="9.8000"/> to 9.8500
C-F28 Suppression of the hold function	1028	<input type="text" value="0"/> : Permission 1: Prohibition

#1 : The decimal point position depends on **C-F02** (Decimal point position).

5.3.7. The Linearization Function (L-Fnc)

- Confirm and change linearity settings.
To use this function, select L-Fnc in the same way as the function related to the calibration are selected.

Item Name	Function code	Description, Range and Default value
L-F01 Number of input points	1101	Number of points where linear input was done. The linear-zero input is included as one point. Digital linearization is not performed when the set value is between 0 and 2. 0 to 5
L-F02 Linear-zero	1102	Voltage for linear-zero input. Scale : 0.0001 mV/V. -7.0000 to 0.0000 to 7.0000
L-F03 Setting value for linear 1	1103	The setting value of weight for linear 1 input. #1 0 to 99999
L-F04 Span at linear 1	1104	The span voltage between linear-zero and linear 1 input. Scale : 0.0001 mV/V. 0.0000 to 9.9999
L-F05 Setting value for linear 2	1105	The setting value of weight for linear 2 input. #1 0 to 99999
L-F06 Span at linear 2	1106	The span voltage between linear-zero and linear 2 input. Scale : 0.0001 mV/V. 0.0000 to 9.9999
L-F07 Setting value for linear 3	1107	The setting value of weight for linear 3 input. #1 0 to 99999
L-F08 Span at linear 3	1108	The span voltage between linear-zero and linear 3 input. Scale : 0.0001 mV/V. 0.0000 to 9.9999
L-F09 Setting value for linear 4	1109	The setting value of weight for linear 4 input. #1 0 to 99999
L-F10 Span at linear 4	1110	The span voltage between linear-zero and linear 4 input. Scale : 0.0001 mV/V. 0.0000 to 9.9999

#1 : The decimal point position depends on **C-F02** (Decimal point position).

5.3.8. Error Codes for the Calibration (C ErB)

When an error occurs during the calibration, the error number is displayed. If calibration is finished without removing the error, the setting values will be restored to the state before calibration.

Calibration errors and remedies

Error No.	Description of cause	Treatment
C Er1	The display resolution (maximum capacity / minimum division) exceeds the specified value.	Make the minimum division greater or make the maximum capacity smaller. The specified value depends on specifications of the weighing system.
C Er2	Voltage at zero calibration exceeds in the positive direction.	Check the load cell rating and connection. When nothing is wrong with the rating and connection, adjust the load cell output as described in the next section. When the load cell or A/D converter may be the cause of error, confirm this by using the check mode.
C Er3	Voltage at zero calibration exceeds in the negative direction.	
C Er4	The value of the calibration weight exceeds the maximum capacity.	Use an appropriate the calibration weight and calibrate again.
C Er5	The value of the calibration weight is less than the minimum division.	
C Er6	The load cell sensitivity is not sufficient.	Use a load cell with higher sensitivity or make the minimum division greater.
C Er7	Voltage at span calibration is less than voltage at the zero point.	Check the load cell connection.
C Er8	The load cell output voltage is too high when the mass of maximum capacity is weighed.	Use a load cell with a greater rating or make the maximum capacity smaller.


5.3.9. Adjustment of the Load Cell Output

Add a resistor as shown below to adjust the load cell output.

Use a resistor with a high resistance value and a low temperature coefficient.

"C Er2"

When exceeding in the positive direction.



"C Er3"

When exceeding in the negative




Illustration 10 Load cell output adjustment

- Because the zero point of the module has a wide adjustable range, correcting the output of a normal load cell is hardly ever required. Before an output correction is carried out, confirm load cells (deformation, wiring mistakes, contact with anything, or model selection etc.) and connections.

5.4. The List of General Functions

General functions are divided into groups according to function and are indicated by function item (function group name with function number).

All the parameters in the general functions are stored in the nonvolatile memory (FRAM).

5.4.1. The Procedure to Store New Parameters

Step 1 Press the **ENT** + **F** key to enter to the function mode and display **Fnc** .
 Press the **ENT** key to start the function mode.
 To return to the weighing mode, press the **ESC** key.

Step 2 Press the **↑** key to select the function group to be set.
 Pre

Display	Group name
<i>Fnc F</i>	Basics function
<i>Hld F</i>	Hold function
<i>Sq F</i>	Sequence function
<i>Sp F</i>	Setpoint function
<i>io F</i>	Control I/O function
<i>[L F</i>	Standard serial output function
<i>[[F</i>	CC-Link function

ss the **ENT** key. The function group is as follows :

Step 3 Press the **↑** key to select the function number to be set.
 Press the **ENT** key. The current setting value is displayed.

Step 4 When changing parameter, two methods of parameter selection and digital input depending on the function are available.

Type	Description of method to change data
Parameter selection	Only the available parameter is displayed and blinks. Select a number using the ↑ key.
Digital input	All the digits are displayed. The digit to be changed blinks. Select the digit using the → key. Change the value using the ↑ key.

After changing data, press the **ENT** key. The next function number is displayed.
 When the value is not to be changed, press the **ESC** key to return to the function number display.

Step 5 Press the **ESC** key to turn off the function number display and return to Step 2.
 Press the **ESC** key once more to store new parameters in the nonvolatile memory (FRAM) and to return to the weighing mode.

- The blinking decimal point means that the current value is not the weight value.
- If a data exceeding the available range is inputted, **Errdt** is displayed, and the data is canceled.
- The function code on the next page is used for commands of the CC-Link and USB.

5.4.2. The Basics Function (Fnc F)

Item Name	Function code	Description, Range and Default value
Fnc01 Key switch disable	1201	Each digit of the setting corresponds to a key switch. Only available in the weighing mode. Key assignment to each binary digit. 0: Permission 1: Prohibition 4th 3rd 2nd 1st digit <input type="checkbox"/> ESC <input type="checkbox"/> → <input type="checkbox"/> ↑ <input type="checkbox"/> ENT <input type="text" value="0000"/> to 1111
Fnc02 <input type="checkbox"/> F key	1202	0: None 1: Manual print command 2: Hold 3: Alternative switch (Active <input type="checkbox"/> F key) 4: Momentary switch (Active <input type="checkbox"/> F key) <input type="checkbox"/> 5: Display exchange 6: Tare clear 7: Zero clear 8: Weighing start / Pause / Re-start 9: Actual free fall input 10: One shot, Small flow 11: Sequence flow rate monitor 12: mV/V monitor 13: Digital filter 2
Fnc03 Display update rate	1203	<input type="checkbox"/> 1: 20 times/sec. 2: 10 times/sec. 3: 5 times/sec.
Fnc04 x display	1204	<input type="checkbox"/> 0 : None 1: Zero tracking in progress 2: Alarm (Zero range setting error, over) 3: Active <input type="checkbox"/> F key 4: Near-zero 5: HI output (Over the upper limit value) 6: OK output (Between upper and lower limit values) 7: LO output (Below the lower limit value) 8: Large flow 9: Medium flow 10: Small flow 11: Over 12: OK 13: Under 14: Full value 15: Weighing sequence, finished 16: Weighing sequence, in processing 17: Weighing sequence, error 18: Normal batch / Discharge, Identification (ON = Loss in weight) 19 to 24 : User input1 to 6 25 to 32 : User output 1 to 8
Fnc05 Digital filter 1	1205	Selects a cutoff frequency. 0 : None 6 : 20.0 Hz 12 : 2.8 Hz 1 : 100.0 Hz 7 : 14.0 Hz 13 : 2.0 Hz 2 : 70.0 Hz 8 : 10.0 Hz 14 : 1.4 Hz 3 : 56.0 Hz 9 : 7.0 Hz <input type="checkbox"/> 15 : 1.0 Hz 4 : 40.0 Hz 10 : 5.6 Hz 16 : 0.7 Hz 5 : 28.0 Hz 11 : 4.0 Hz
Fnc06 Digital Filter 2	1206	Selects a cutoff frequency. 0 : None 6 : 20.0 Hz 12 : 2.8 Hz 18 : 0.40 Hz 1 : 100.0 Hz 7 : 14.0 Hz 13 : 2.0 Hz 19 : 0.28 Hz 2 : 70.0 Hz 8 : 10.0 Hz 14 : 1.4 Hz 20 : 0.20 Hz 3 : 56.0 Hz 9 : 7.0 Hz <input type="checkbox"/> 15 : 1.0 Hz 21 : 0.14 Hz 4 : 40.0 Hz 10 : 5.6 Hz 16 : 0.7 Hz 22 : 0.10 Hz 5 : 28.0 Hz 11 : 4.0 Hz 17 : 0.56 Hz 23 : 0.07 Hz
Fnc07 Hold	1207	<input type="checkbox"/> 1: Normal hold 2 : Peak hold 3 : Averaging hold
Fnc08 Set near-zero	1208	The reference value for near-zero. Decimal point position depends on C-F02 (Decimal point position). -99999 to <input type="text" value="10"/> to 99999

5.4.5. The Setpoint Function (SP F)


Item Name	Function code	Description, Range and Default value	
SP01 Object of SP1	1501	Setting values concerning setpoints (SP) Caution : Do not select the same item to plural setpoints. 0 : Not used 1 : Final value 2 : Optional preliminary 3 : Preliminary 4 : Free fall 5 : Over 6 : Under 7 : Full 8 : Near-zero 9 : Free fall coefficient 10 : Upper limit 11 : Under limit	
SP02 Object of SP2	1502		0 to <input type="text" value="1"/> to 11
SP03 Object of SP3	1503		0 to <input type="text" value="2"/> to 11
SP04 Object of SP4	1504		0 to <input type="text" value="3"/> to 11
SP05 Object of SP5	1505		0 to <input type="text" value="4"/> to 11
SP06 Object of SP6	1506		0 to <input type="text" value="5"/> to 11
SP07 Object of SP7	1507		0 to <input type="text" value="6"/> to 11
SP08 Object of SP8	1508		0 to <input type="text" value="7"/> to 11
SP11 Parameter of SP1	1511	Setting parameters of setpoints (SP). The decimal point position depends on C-F02 (Decimal point position).	
SP12 Parameter of SP2	1512		-99999 to <input type="text" value="0"/> to 99999
SP13 Parameter of SP3	1513		-99999 to <input type="text" value="0"/> to 99999
SP14 Parameter of SP4	1514		-99999 to <input type="text" value="0"/> to 99999
SP15 Parameter of SP5	1515		-99999 to <input type="text" value="0"/> to 99999
SP16 Parameter of SP6	1516		-99999 to <input type="text" value="0"/> to 99999
SP17 Parameter of SP7	1517		-99999 to <input type="text" value="99999"/>
SP18 Parameter of SP8	1518		-99999 to <input type="text" value="10"/> to 99999

The setpoint (comparator data) is the function to compare data.

5.4.6. The Control I/O Function (\square F)

Item Name	Function code	Description, Range and Default value
io 01 Function of IN1	1601	0 : Not used 16 : Emergency stop (Level input) 1 to 6 : User input 1 to 6 17 : Error reset
io 02 Function of IN2	1602	7 : Zero 18 : Normal batch/ 8 : Tare Loss-in-weight exchange
io 03 Function of IN3	1603	9 : Hold 19 : Actual free fall input
io 04 Function of IN4	1604	10 : Gross / Net exchange
io 05 Function of IN5	1605	11 : Diagnose 20 : One shot, Small flow
io 06 Function of IN6	1606	12 : Print command 21 : Full open (Level input) 13 : Weighing start 22 : Zero clear 14 : Pause 23 : Tare clear 15 : Restart 24 : Operation same as a \square F key
io 11 Function of OUT1	1611	0 : Not used 23 : Large flow 1 to 8 : User output 1 to 8 24 : Medium flow
io 12 Function of OUT2	1612	9 : Stability 25 : Small flow
io 13 Function of OUT3	1613	10 : Over capacity 26 : Normal batch/ 11 : Net display Loss-in-weight exchange
io 14 Function of OUT4	1614	12 : During tare 27 : In weighing sequence
io 15 Function of OUT5	1615	13 : Hold 28 : End of weighing sequence
io 16 Function of OUT6	1616	14 : Hold busy 29 : Error of weighing sequence
io 17 Function of OUT7	1617	15 : HI output (Over the upper limit value)
io 18 Function of OUT8	1618	16 : OK output (Between upper and lower limit values)
io 21 OUT1 Logic	1621	17 : LO output (Below the lower limit value)
io 22 OUT2 Logic	1622	18 : Near-zero 30 : In weighing (ON)
io 23 OUT3 Logic	1623	19 : Full 31 : In weighing (1 Hz)
io 24 OUT4 Logic	1624	20 : Over 32 : In weighing (50 Hz)
io 25 OUT5 Logic	1625	21 : OK 33 : Alarm
io 26 OUT6 Logic	1626	22 : Under 34 : Active \square F key #2
io 27 OUT7 Logic	1627	
io 28 OUT8 Logic	1628	

- 1 : Inverting output
If data is "0" level, the output transistor conducts (ON).
- 2 : Non inverting output
If data is "1" level, the output transistor conducts (ON).



- #1** When **Fnc02** (**F** key) stores 3 (Alternative switch), the function is effective.
 When **Fnc02** (**F** key) stores 4 (Momentary switch), the function is ineffective.
- #2** When **Fnc04** (x display) stores 3 (Active **F** key), the function becomes the same as the display x.

5.4.7. The Standard Serial Output Function (*EL F*)

Item Name	Function code	Description, Range and Default value
CL 01 Serial data	1701	<input type="checkbox"/> 1 : Weighing display 3 : Net 5 : Gross / Net / Tare 2 : Gross 4 : Tare
CL 02 Communication mode	1702	<input type="checkbox"/> 1 : Stream 2 : Automatic print 3 : Manual print
CL 03 Baud rate	1703	1 : 600 bps <input type="checkbox"/> 2 : 2400 bps

5.4.8. The CC-Link Function (*EE F*)

Item Name	Function code	Description, Range and Default value
CC 01 Station number	1801	Station number for this module <input type="checkbox"/> 1 to 64
CC 02 Number of the remote register occupied	1802	0 : 1 station 1 : 2 stations <input type="checkbox"/> 2 : 4 stations
CC 03 Baud rate	1803	0 : 156 kbps 2 : 2.5 Mbps <input type="checkbox"/> 4 : 10 Mbps 1 : 625 kbps 3 : 5 Mbps
CC 04 Initial process	1804	0 : Not needed <input type="checkbox"/> 1 : Necessary
CC 05 Output data	1805	<input type="checkbox"/> 0 : Weighing display 1 : Net 2 : Gross
CC 06 Weighing information 1	1806	<input type="checkbox"/> 0 : Not used 6 : Sequence flow rate (In small flow OFF) 1 : Sequence number 7 : Sequence flow rate (Real time) 2 : Batch weighing error 8 : Load cell output. Scale : 1 nV/V 3 : Actual free fall 9 : Net (Digital filter 2)
CC 07 Weighing information 2	1807	4 : Free fall (Averaging) #1 10 : Gross (Digital filter 2) 5 : Free fall coefficient (Averaging) #1

#1 : Free fall and free fall coefficient are recalculated at the end of the weighing even if **Sq 08** (Automatic free fall correction) is set either parameter.

If **Sq 08** (Automatic free fall correction) is set to 2 (Real time free fall compensation(fixed coefficient)), **Sq 10** (Active free fall coefficient) is always used.

If **Sq 08** (Automatic free fall correction) is set to 3 (Real time free fall compensation (updated coefficient)), **Sq 10** (Active free fall coefficient) is always recalculated.

5.5. Batch Weighing

Batch weighing is a procedure to automatically weigh up to the final value.

Select a weighing mode (**Sq 07**) from the following:

- 0 : Disable
- 1 : Normal batch sequence
- 2 : Loss-in-weight sequence
- 3 : Specifying with control input
- 4 : Specifying with CC-Link

■ Feeding process

1. Input the weighing start signal.
 2. When the weighing start input delay time (**Sq 22**) has passed, the large flow, medium flow and small flow outputs turn ON.
 3. When the large flow comparison disable time (**Sq 23**) has passed, the large flow output turns OFF under the large flow off output conditions.
 4. When the medium flow comparison disable time (**Sq 24**) has passed, the medium flow output turns OFF under the medium flow off output conditions.
 5. When the small flow comparison disable time (**Sq 25**) has passed, the small flow output turns OFF under the small flow off output conditions.
 6. When the judging delay time (**Sq 26**) has passed and the net value is stable (**Sq 12**), the net value is judged.
 7. The weighing end output turns ON and the OK / Over / Under output of the judgment result turns ON.
 8. When the weighing end output time (**Sq 27**) has passed, the weighing end output turns OFF and the OK / Over / Under output of the judgment result turns OFF.
- The OK / Over / Under output can be always output by setting the OK / Over / Under output timing (**Sq 11**).

■ Weighing start / pause / restart / emergency stop.

When restarted from the pause, the weighing starts with one flow below the previous flow.

Relation between inputs and outputs (Example : with the large flow to turn on)


Start and stop command		Large flow	Medium flow	Small flow	Weighing end	Weighing error	Ref.
Weighing start		ON	ON	ON	OFF	OFF	
Pause during flowing		OFF	OFF	OFF	OFF	ON	
Restart from pause	First	OFF	ON	ON	OFF	OFF	
	Second	OFF	OFF	ON	OFF	OFF	
	Third or later	OFF	OFF	ON	OFF	OFF	
Restart from emergency stop	First	OFF	ON	ON	OFF	OFF	
	Second	OFF	OFF	ON	OFF	OFF	
	Third or later	OFF	OFF	ON	OFF	OFF	
Emergency stop during flowing		OFF	OFF	OFF	OFF	ON	
Stop after comparison (Normally finished)		OFF	OFF	OFF	ON	OFF	

- Weighing end means weighing sequence end.
- Weighing error means weighing sequence error.

5.5.1. Sequential Weighing


■ Normal batch sequence

Output terminal	Output conditions	Reference
Near-zero	Gross \leq Near-zero	Comparison weight can be changed to net weight with F_{nc09}
Full	Gross \geq Full	
Large flow off	Net \geq Final value - Optional preliminary	
Medium flow off	Net \geq Final value - Preliminary	
Small flow off	Net \geq Final value - Free fall	
Over	Net > Final value + Over	
OK	Final value + Over \geq Net \geq Final value - Under	
Under	Net < Final value - Under	



■ Loss-in-weight sequence

Output terminal	Output conditions	Reference
Near-zero	Gross \leq Near-zero	Comparison weight can be changed to net weight with Fnc09
Full	Gross \geq Full	
Large flow off	-Net \geq Final value - Optional preliminary	
Medium flow off	-Net \geq Final value - Preliminary	
Small flow off	-Net \geq Final value - Free fall	
Over	-Net > Final value + Over	
OK	-Final value + Over \geq Net \geq Final value - Under	
Under	-Net < Final value - Under	



5.5.2. Weighing Sequence Error (Output)

A weighing sequence error will occur in the following conditions.

- Weighing start has been input when: Gross + Final value \geq Weighing capacity.
- Weighing start has been input when it is over capacity including negative over capacity.
- The tare fails when tare condition (tare when unstable (**C-F10**) and tare when the gross weight is negative (**C-F11**)) have been selected and automatic tare at weighing start (**Sq 13**) has been enabled (1).
- When the time in weighing sequence reaches the flow timeout time.
- When pause has been input during the weighing sequence.
- When an emergency stop has been input during the weighing sequence.

5.5.3. Error Reset (Input)

- When the error reset is input, the weighing sequence error output turns OFF.
- When the error reset is input during in weighing sequence, the weighing sequence will be initialized.

The initialization of the weighing sequence turns OFF all the outputs that are related to weighing sequence such as follows.

Large, medium and small flow output
OK / over / under output
In weighing sequence output
Weighing end output
Weighing sequence error output

5.5.4. One Shot Small Flow (Input)

When the one shot small flow is input, the small flow output turns ON for the duration that is set for the one-shot time for small flow rate (**Sq 28**).

The small flow output time will be extended if the one shot small flow is input again while the small flow output has been on.

Example: **Sq 28** = 2.00 seconds and one-shot small flow is input three times repeatedly.

The small flow is output 2.00 seconds \times 3 times = 6.00 seconds

The one shot small flow is available during "in weighing sequence".

5.5.5. Full Open (Output)

When full open is input while weighing sequence is not active, the large, medium and small flow output is on.

By level input, the large, medium and small flow output remains ON while the full open is input.

5.5.6. Actual Free Fall Input

It updates the parameters of **Sq 02** (Free fall) and **Sq 10** (Free fall coefficient) using the latest weighing results. "Active free fall compensation (Updated coefficient)(3)" of **Sq 08** (Automatic free fall compensation) is not updated. It is used when adjusting the weighing module and changing weighing materials.

5.5.7. Automatic Free Fall Compensation

The automatic free fall compensation function reduces weighing errors during batch weighing. The weighing value may increase between closing the dribble gate and finishing weighing of a hopper scale and etc. This increased value is called "free fall". To minimize weighing errors, a free fall parameter and a real free fall value should be the same. As a way to do so, there is the "moving average of the last four real free fall", with which the next free fall setting is updated automatically.

The formula of batch error and real free fall are as follows:

Batch error = Net value when the batch is finished – Preliminary

Real free fall = Net value when the batch is finished – Net value when the dribble flow gate is OFF

When the weighing value passes Preliminary – Final value, the dribble flow gate is off.

When a batch error exceeds the effective range of the automatic free fall, the batch weighing is regarded as an error and excluded from the "moving average of the last four real free fall".

5.5.8. Active Free Fall Compensation

The active free fall compensation function modifies the free fall compensation in relation to the velocity passing through the gate (flow rate).

Example: When discharging a liquid (water, cement, tar) in the hopper, the flow rate decreases as the remaining amount becomes smaller. In this case, the weighing results always become too small with the conventional free fall compensation. The same problem occurs with materials like honey with a viscosity that changes according to temperature.

Free fall coefficient = Actual free fall / Flow rate (when the dribble flow gate is OFF)

Free fall = Free fall coefficient x Flow rate

When "Active free fall compensation (fixed coefficient) (2)" is set to **Sq 08** (Automatic free fall compensation), the free fall is calculated with the parameter of **Sq 10** (Active free fall coefficient). When "Active free fall compensation (updated coefficient) (3)" is set to **Sq 08**, the free fall is calculated with the average of the last four weighing values. When a batch error exceeds an effective range of the automatic free fall, the batch weighing is regarded as an error and excluded from the "moving average of the last four real free fall".

5.5.9. Sequence Numbers

The status of batch weighing can be checked from the holding register of the CC-Link

Sequence number	Description
0	Waiting for the weighing start input.
1	Automatic tare
2	Confirming the start condition.
3	During the weighing start input delay, the large, medium and small flow turn ON after checking.
4	Waiting for the large flow comparison disable time.
5	During the large flow, turns OFF the large flow under the large flow off output conditions.
6	Waiting for the medium flow comparison disable time.
7	During the medium flow, turns OFF the medium flow under the medium flow off output conditions.
8	Waiting for the small flow comparison disable time.
9	During the small flow, turns OFF the small flow under the small flow off output conditions.
10	Waiting for the judging delay
11	Wait for the stable weighing value.
12	The comparison result is output. Weighing end is output.

5.6. Setpoint (Comparator value)

These parameters of the **SP1** to **SP8** (setpoint) store items of fundamental setpoint for the weighing sequence. The **SP11** to **SP18** (parameter of the setpoint) store setpoint values of the **SP1** to **SP8** (setpoint). These function can be selected with **SP1** to **SP8** (setpoint). The remote registers of 4 stations are occupied in the initial settings for the CC-Link. Change it if needed. To keep the original settings, set "not used (0)".

Parameter & Item	Relation item
0: Not used	Not related
1: Final value	Sq 01
2: Optional preliminary	Sq 04
3: Preliminary	Sq 03
4: Free fall	Sq 02
5: Over	Sq 05

Parameter & Item	Relation item
6: Under	Sq 06
7: Full	Fnc13
8: Near-zero	Fnc08
9: Free fall coefficient	Sq 10
10: Upper limit	Fnc10
11: Under limit	Fnc11

6. Interface

6.1. Control I/O

- Using a control input from peripherals, data can be monitored and be output.
- Using a control output, the weighing status and weighing result can be output.
- The input and output circuit is isolated from the DC power supply terminals and load cell terminals.
- DC +24 V is supplied between the power supply input terminal (I/O PWR +24V) and COM terminal.

Part of input (IN1 ~ IN6)


Input circuit type	No-voltage contact input (Photo coupler)
Input open voltage	According to use
OFF current	0.1 mA max.
ON current	2.7 mA min.
Input threshold voltage	2 V

Part of output (OUT1 ~ OUT8)

Output circuit type	Open collector
Isolation	Photo coupler
Output voltage	DC 35 V max.
Output current	50 mA max.
Output saturation voltage	1.1 V max.

Control I/O

IN 6	20	10	IN 5
IN 4	19	9	IN 3
IN 2	18	8	IN 1
OUT8	17	7	OUT7
OUT6	16	6	OUT5
OUT4	15	5	OUT3
OUT2	14	4	OUT1
C.L.	13	3	C.L.
I/O PWR +24V	12	2	COM
	11	1	COM




□ Assigning functions to terminals

- Assign functions to these input terminals : **io 01** (IN1 function) to **io 06** (IN6 function)
- Assign functions to these output terminals : **io 11** (OUT1 function) to **io 18** (OUT8 function)
- Assign logic to these output terminals : **io 21** (OUT1 logic) to **io 28** (OUT8 logic)

6.2. Serial Output (Current Loop)

- The current loop (C.L.) circuit is isolated from all terminals.
- The standard serial output can connect to the A&D external display and printer.
- The current loop output needs to supply DC current from an external DC power source.
- The current loop terminals of the AD-4430C have non-polarity.
- The current loop terminals are pin 3 and 13 of the control I/O connector.

Transmission	0 – 20 mA, Current loop
Data length	7 bits
Start bit	1 bit
Parity bit	Even
Stop bit	1 bit
Baud rate	600 bps, 2400 bps
Code	ASCII



6.2.1. Data format of Serial Output

- The "A&D standard format" is used to the output format for communication with the A&D printer, and external display and consists of dual headers, data, unit and terminator.

A&D standard format

Header 1		Header 2		Data (Polarity, 8 digits including decimal point)								Unit		Terminator			
S	T	,	G	S	,	+	0	1	2	3	.	4	5	k	g	CR	LF

Item	ASCII code	Hexadecimal	Description
Header 1	ST	[53 54]	Stable
	US	[55 53]	Unstable
	OL	[4F 4C]	Overload
Header 2	GS	[47 53]	Gross
	NT	[4E 54]	Net
	TR	[54 52]	Tare
Punctuation	,	[2C]	Comma
Data (ASCII code)	0 to 9	[30 to 39]	Numerical number
	+	[2B]	Positive sign
	-	[2D]	Negative sign
	SP	[20]	Space
	.	[2E]	Dot
Unit (4 types)	SP SP	[20 20]	Not used
	SP g	[20 67]	g (gram)
	kg	[6B 67]	kg (kilogram)
	SP t	[20 74]	t (ton)

Examples of the A&D standard format

	Header 1		Header 2		Data (Polarity, 8 digits including decimal point)								Unit		Terminator				
Gross	S	T	,	G	S	,	+	0	0	1	2	3	4	5	k	g	CR	LF	Header 2 [GS]
Net	S	T	,	N	T	,	+	0	0	1	0	0	0	0	k	g	CR	LF	Header 2 [NT]
Tare	S	T	,	T	R	,	+	0	0	0	2	3	4	5	k	g	CR	LF	Header 2 [TR]
Including "."	S	T	,	G	S	,	+	0	1	2	3	.	4	5	k	g	CR	LF	Numerical part [.]
+Over	O	L	,	G	S	,	+	SP	SP	SP	SP	.	SP	SP	k	g	CR	LF	Header 1 [OL]
-Over	O	L	,	G	S	,	-	SP	SP	SP	SP	.	SP	SP	k	g	CR	LF	Header 1 [OL], Polarity [-]
Unstable	U	S	,	G	S	,	+	0	1	2	3	.	4	5	k	g	CR	LF	Header 1 [US]
Output data	O	L	,	G	S	,	+	SP	SP	SP	SP	.	SP	SP	k	g	CR	LF	Same as +Over

The position of decimal point is fixed even if data is out of range.

6.2.2. Transfer Mode of Serial Output

The type of the standard serial output is 3 types of "stream", "automatic print" and "manual print".

Stream	The data is output at each display rewrite. If the data cannot be output completely due to a slow baud rate, the data is output at the next rewrite. The output data uses a displayed data. Therefore, hidden data is not output.
Automatic printing	<p>□ Automatic printing depends on the weighing mode setting.</p> <p>1. Weighing mode (Sq 07) = 0 When a weighing value is 5d or more and is stable, the data is output only once. To output again, data is required to become less than 5d. Select "Normal hold (1)" in Fnc07 Hold function for the setting. Note: When "stability detection time" (C-F08) and "stability detection width"(C-F09) are set to "0" (stability detection is not performed), the data is output only once when it becomes 5d or more.</p> <p>2. Weighing mode (Sq 07) = 1 or more (When batch weighing is used) Output once when the weighing sequence finished.</p>
Manual printing	When "manual printing" is selected, receiving a printing command from the CC-Link or pressing the assigned print key, data is output.

6.3. The CC-Link


The AD-4430C is the remote device station of the CC-Link interface version 1.10. When using the CC-Link, the AD4430C can be controlled on remote I/O and remote register, so the program may be simplified.

- Use the connector authorized by the CC-Link.

Station number	1 to 64
Number of the remote register occupied	1 station, 2 stations, 4 stations
Baud rate	156 kbps, 625 kbps, 2.5 Mbps, 5 Mbps, 10 Mbps


Status LED of the CC-Link

LED	Indication	Turning off	Blinking
RUN	Normal	Resetting, No signal	-
SD	Sending	-	-
RD	Receiving	-	-
ERR	Parameter error CRC error Station trouble	Normal	Changing parameters




The CC-Link connector

DA	Signal line DA
DB	Signal line DB
DG	Signal ground
NC	Open terminal
SLD	Shield terminal



Accessory

3M 35505-6000-B0M GF



Spring type

3M 35A05-60S0-B0M GF

Illustration 11 The CC-Link connector

6.3.1. Address Map

Remote register (4 stations occupied)

In case of setting address to 1.

AD-4430C ⇒ Master				Master ⇒ AD-4430C		
Station No.	Remote register	Buffer	Description	Remote register	Buffer	Description
1	RWr0000	2E0	Net	RWw0000	1E0	SP1: Final
	RWr0001	2E1		RWw0001	1E1	
	RWr0002	2E2	Gross	RWw0002	1E2	SP2: Optional preliminary
	RWr0003	2E3		RWw0003	1E3	
2	RWr0004	2E4	Total weight (Net when finishing)	RWw0004	1E4	SP3: Preliminary
	RWr0005	2E5		RWw0005	1E5	SP4: Free fall
	RWr0006	2E6	Error code	RWw0006	1E6	SP5: Over
	RWr0007	2E7	Error sub code	RWw0007	1E7	SP6: Under
3	RWr0008	2E8	Weighing information 1	RWw0008	1E8	SP7: Full
	RWr0009	2E9		RWw0009	1E9	
	RWr000A	2EA	Weighing information 2	RWw000A	1EA	SP8: Near-zero
	RWr000B	2EB		RWw000B	1EB	
4	RWr000C	2EC	Command data reply	RWw000C	1EC	Command data
	RWr000D	2ED		RWw000D	1ED	
	RWr000E	2EE	Command No. reply	RWw000E	1EE	Command No.
	RWr000F	2EF	Not used (Reserved by inside)	RWw000F	1EF	Not used (Reserved by inside)

Remote register (2 stations occupied)

In case of setting address to 1.

AD-4430C ⇒ Master				Master ⇒ AD-4430C		
Station No.	Remote register	Buffer	Description	Remote register	Buffer	Description
1	RWr0000	2E0	Value (Net / Gross)	RWw0000	1E0	SP1: Final
	RWr0001	2E1		RWw0001	1E1	
	RWr0002	2E2	Error code	RWw0002	1E2	SP2: Optional preliminary
	RWr0003	2E3	Error sub code	RWw0003	1E3	
2	RWr0004	2E4	Command data response	RWw0004	1E4	Command data
	RWr0005	2E5		RWw0005	1E5	
	RWr0006	2E6	Command No. response	RWw0006	1E6	Command No.
	RWr0007	2E7	Not used (Reserved by inside)	RWw0007	1E7	Not used (Reserved by inside)

Remote register (1 station occupied)

In case of setting address to 1.

AD-4430C ⇒ Master				Master ⇒ AD-4430C		
Station No.	Remote register	Buffer	Description	Remote register	Buffer	Description
1	RWr0000	2E0	Value (Net / Gross)	RWw0000	1E0	Not used (Reserved by inside)
	RWr0001	2E1		RWw0001	1E1	
	RWr0002	2E2	Error code	RWw0002	1E2	
	RWr0003	2E3	Error sub code	RWw0003	1E3	

Station No.	AD-4430C ⇒ Master			Master ⇒ AD-4430C				
	Remote input	Buffer	Description	Remote output	Buffer	Description		
1	RX0000	0E0	Setpoints writing response flag	RY0000	160	Setpoints, request flag		
	RX0001		Not used (Reserved by inside)	RY0001		Not used (Reserved by inside)		
	RX0002		Command response flag	RY0002		Command request flag		
	RX0003		Write / Read response flag	RY0003		Write / Read selection flag		
	RX0004		Not used (Reserved by inside)			RY0004	Not used (Reserved by inside)	
	RX0005					RY0005		
	RX0006		CPU normal operation			RY0006		
	RX0007		Not used (Reserved by inside)			RY0007		
	RX0008		Decimal point 2 ⁰	3 bits Binary		RY0008		
	RX0009					RY0009		
	RX000A					RY000A		
	RX000B		Not used (Reserved by inside)			RY000B		
	RX000C					RY000C		
	RX000D					RY000D		
	RX000E					RY000E		
	RX000F					RY000F		
	RX0010	0E1			Near-zero	RY0010		Zero
	RX0011				Large flow	RY0011		Zero clear
	RX0012				Medium flow	RY0012		Tare
	RX0013		Small flow	RY0013	Tare clear			
	RX0014		Over	RY0014	Hold			
	RX0015		Final	RY0015	Net display			
	RX0016		Under	RY0016	Gross display			
	RX0017		Stable	RY0017	Printing command			
	RX0018		Weighing end	RY0018	Actual free fall input			
	RX0019		Capacity over	RY0019	One shot, Small flow			
	RX001A		Holding	RY001A	Error rest			
	RX001B		Full	RY001B	Restart			
	RX001C		In weighing sequence	RY001C	Weighing start			
	RX001D		Normal batch / Discharge	RY001D	Normal batch / Discharge			
	RX001E		weighing sequence error	RY001E	Pause			
	RX001F		Weighing failure	RY001F	Emergency stop			

Station No.	AD-4430C ⇒ Master			Master ⇒ AD-4430C		
	Remote input	Buffer	Description	Remote output	Buffer	Description
2	RX0020 to RX003F	0E2 to 0E3	Not used (Reserved by inside)	RY0020 to RY003F	162 to 163	Not used (Reserved by inside)
3	RX0040	0E4	Not used (Reserved by inside)	RY0040	164	Not used (Reserved by inside)
	RX0041			RY0041		
	RX0042			RY0042		
	RX0043			RY0043		
	RX0044			RY0044		
	RX0045			RY0045		
	RX0046			RY0046		
	RX0047			RY0047		
	RX0048			RY0048		
	RX0049			RY0049		
	RX004A			RY004A		
	RX004B			RY004B		
	RX004C			RY004C		
	RX004D			RY004D		
	RX004E			RY004E		
	RX004F			RY004F		
	RX0050	0E5	User output 1	RY0050	165	User output 1
	RX0051		User output 2	RY0051		User output 2
	RX0052		User output 3	RY0052		User output 3
	RX0053		User output 4	RY0053		User output 4
	RX0054		User output 5	RY0054		User output 5
	RX0055		User output 6	RY0055		User output 6
	RX0056		User output 7	RY0056		User output 7
	RX0057		User output 8	RY0057		User output 8
	RX0058		User input 1	RY0058		Not used (Reserved by inside)
	RX0059		User input 2	RY0059		
	RX005A		User input 3	RY005A		
RX005B	User input 4		RY005B			
RX005C	User input 5		RY005C			
RX005D	User input 6		RY005D			
RX005E	Not used (Reserved by inside)		RY005E			
RX005F			RY005F			

Station No.	AD-4430C ⇒ Master			Master ⇒ AD-4430C					
	Remote input	Buffer	Description	Remote output	Buffer	Description			
4	RX0060	0E6	Net over	RY0060	166	Not used (Reserved by inside)			
	RX0061		Net under	RY0061					
	RX0062		Gross over	RY0062					
	RX0063		Gross under	RY0063					
	RX0064		A/D over	RY0064					
	RX0065		A/D under	RY0065					
	RX0066		Center zero of net	RY0066					
	RX0067		Center zero of gross	RY0067					
	RX0068		In displaying net	RY0068					
	RX0069		In displaying gross	RY0069					
	RX006A		During tare	RY006A					
	RX006B		CAL operation error	RY006B					
	RX006C		Zero compensation error	RY006C					
	RX006D		Tare error	RY006D					
	RX006E		Error of displaying net	RY006E					
	RX006F		Linkage of display x	RY006F					
	RX0070		0E7	Not used (Reserved by inside)			RY0070	167	Not used (Reserved by inside)
	RX0071						RY0071		
	RX0072	RY0072							
	RX0073	RY0073							
	RX0074	RY0074							
	RX0075	RY0075							
	RX0076	RY0076							
	RX0077	RY0077							
	RX0078	Initial process request flag		RY0078	Initial process finish flag				
	RX0079	Initial data processing completion flag		RY0079	Initial data setting request flag				
	RX007A	Error status flag		RY007A	Error reset request flag				
	RX007B	Remote station READY flag		RY007B	Not used (Reserved by inside)				
	RX007C	Not used (Reserved by inside)		RY007C					
	RX007D			RY007D					
	RX007E			RY007E					
	RX007F			RY007F					

Station No.	AD-4430C ⇒ Master			Master ⇒ AD-4430C				
	Remote input	Buffer	Description	Remote output	Buffer	Description		
1	RX0000	0E0	Setpoints writing response flag	RY0000	160	Setpoints request flag		
	RX0001		Not used (Reserved by inside)	RY0001		Not used (Reserved by inside)		
	RX0002		Command response flag	RY0002		Command request flag		
	RX0003		<u>Write</u> / Read response flag	RY0003		<u>Write</u> / Read selection flag		
	RX0004		Not used (Reserved by inside)			RY0004	Not used (Reserved by inside)	
	RX0005					RY0005		
	RX0006		CPU normal operation			RY0006		
	RX0007		Not used (Reserved by inside)			RY0007		
	RX0008		Decimal point 2 ⁰	3bits Binary		RY0008		
	RX0009					RY0009		
	RX000A					RY000A		
	RX000B		Not used (Reserved by inside)			RY000B		
	RX000C					RY000C		
	RX000D					RY000D		
	RX000E					RY000E		
	RX000F					RY000F		
	RX0010	0E1			Near-zero	RY0010		Zero
	RX0011				Large flow	RY0011		Zero clear
	RX0012				Medium flow	RY0012		Tare
	RX0013		Small flow	RY0013	Tare clear			
	RX0014		Over	RY0014	Hold			
	RX0015		Final	RY0015	Net display			
	RX0016		Under	RY0016	Gross display			
	RX0017		Stable	RY0017	Printing command			
	RX0018		Weighing end	RY0018	Actual free fall input			
	RX0019		Capacity over	RY0019	One shot, Small flow			
	RX001A		Holding	RY001A	Error rest			
	RX001B		Full	RY001B	Restart			
	RX001C		In weighing sequence	RY001C	Weighing start			
	RX001D		<u>Normal batch</u> / Discharge	RY001D	<u>Normal batch</u> / Discharge			
	RX001E		weighing sequence error	RY001E	Pause			
	RX001F		Weighing failure	RY001F	Emergency stop			

Station No.	AD-4430C ⇒ Master			Master ⇒ AD-4430C					
	Remote input	Buffer	Description	Remote output	Buffer	Description			
2	RX0020	0E2	Net over	RY0020	162	Not used (Reserved by inside)			
	RX0021		Net under	RY0021					
	RX0022		Gross over	RY0022					
	RX0023		Gross under	RY0023					
	RX0024		A/D over	RY0024					
	RX0025		A/D under	RY0025					
	RX0026		Center zero of net	RY0026					
	RX0027		Center zero of gross	RY0027					
	RX0028		In displaying net	RY0028					
	RX0029		In displaying gross	RY0029					
	RX002A		During tare	RY002A					
	RX002B		CAL operation error	RY002B					
	RX002C		Zero compensation error	RY002C					
	RX002D		Tare error	RY002D					
	RX002E		Error of displaying net	RY002E					
	RX002F		Linkage of display x	RY002F					
	RX0030		0E2	Not used (Reserved by inside)			RY0030	163	Not used (Reserved by inside)
	RX0031						RY0031		
	RX0032	RY0032							
	RX0033	RY0033							
	RX0034	RY0034							
	RX0035	RY0035							
	RX0036	RY0036							
	RX0037	RY0037							
	RX0038	Initial process request flag			RY0038	Initial process finish flag			
	RX0039	Initial process finish flag			RY0039	Initial process request flag			
	RX003A	Error status flag		RY003A	Error reset request flag				
	RX003B	Remote station READY		RY003B	Not used (Reserved by inside)				
	RX003C	Not used (Reserved by inside)		RY003C					
	RX003D			RY003D					
	RX003E			RY003E					
	RX003F			RY003F					

Station No.	AD-4430C ⇒ Master			Master ⇒ AD-4430C		
	Remote input	Buffer	Description	Remote output	Buffer	Description
1	RX0000	0E0	Near-zero	RY0000	160	Zero
	RX0001		Large flow	RY0001		Zero clear
	RX0002		Medium flow	RY0002		Tare
	RX0003		Small flow	RY0003		Tare clear
	RX0004		Over	RY0004		Hold
	RX0005		Final	RY0005		Net display
	RX0006		Under	RY0006		Gross display
	RX0007		Stable	RY0007		Printing command
	RX0008		Weighing end	RY0008		Actual free fall input
	RX0009		Capacity over	RY0009		One shot, Small flow
	RX000A		Holding	RY000A		Error rest
	RX000B		Full	RY000B		Restart
	RX000C		In weighing sequence	RY000C		Weighing start
	RX000D		Normal batch / Discharge	RY000D		Normal batch / Discharge
	RX000E		weighing sequence error	RY000E		Pause
	RX000F		Weighing failure	RY000F		Emergency stop
	RX0010		0E1	Not used (Reserved by inside)		RY0010
	RX0011	RY0011				
	RX0012	RY0012				
	RX0013	RY0013				
	RX0014	RY0014				
	RX0015	RY0015				
	RX0016	RY0016				
	RX0017	RY0017				
	RX0018	Initial process request flag		RY0018	Initial process finish flag	
	RX0019	Initial process finish flag		RY0019	Initial process request flag	
	RX001A	Error status flag		RY001A	Error reset request flag	
	RX001B	Remote station READY		RY001B		
	RX001C	Not used (Reserved by inside)		RY001C	Not used (Reserved by inside)	
	RX001D			RY001D		
	RX001E			RY001E		
	RX001F		RY001F			

Numerical Form of Remote Register

Numerical number is hexadecimal. Negative numbers are indicated with 2's complement numbers.

Decimal	Hexadecimal (16 bits)	Hexadecimal (24 bits)	Hexadecimal (32 bits)
-10	FFF6	FFFFFF6	FFFFFFFF6
-1	FFFF	FFFFFFF	FFFFFFFFF
0	0000	000000	00000000
1	0001	000001	00000001
10	000A	00000A	0000000A

Writing Prohibition of Internal Reservation Area

The item "Not used (Reserved by inside)" on tables of the remote register and remote I/O is internal reservation. Writing this item is inhibited. When inputting anything into the remote output (R_Y) and remote register (R_{Ww}), a malfunction may occur. Values of the internal reservation remote input (R_Y) and remote register (R_{Ww}) are indefinite.

Error Codes

Error Code	Error flag	(Instrument error)
0	no error	
1	A/D error	(Module error)
2	EEPROM error	(Writing error)
3	RAM error	(Reading & Writing error)
4	Calibration error	(Calibration data error)
5	Weighing error	(Mode error)
6	Self-check error	(Performing self-check)

- Error code and Error status flag (R_{X007A}) are not reset automatically. Reset the "Error flag (R_{X007A})" of "6.3.3. Timing Chart".

Weighing Errors

Net over
Net under
Gross over
Gross under
A/D over
A/D under
Zero compensation error
Tare error
Net display error
CAL operation error

- Weighing failure will turn ON when either over, under or operation error occur.
- Operation error is cleared when operation is performed normally.

6.3.2. Commands

Command No.	Command data	Description	Writing	Reading
0	1	Zero	○	×
	2	Zero clear	○	×
	3	Tare	○	×
	4	Tare clear	○	×
	5	Hold	○	×
	6	Net display	○	×
	7	Gross display	○	×
	8	Printing command	○	×
	9	F key	○	×
	21	Normal batch weighing	○	×
	22	Loss in weight	○	×
	23	Weighing start	○	×
	24	Pause	○	×
	25	Restart	○	×
	26	Error reset	○	×
	27	Actual free fall input	○	×
	28	One shot, Small flow	○	×
	81	Self check, start	○	×
	82	Self check, stop	○	×
	91	CAL zero mode	○	×
92	CAL span mode	○	×	
93	CAL end	○	×	
94	CAL zero setting	○	×	
95	CAL span setting	○	×	
101	-	Program version	×	○
102	-	Serial No.(lower 5 digits)	×	○
103	-	Program checksum	×	○
104	-	FRAM checksum	×	○
201	-	Gross count	×	○
202	-	Net count	×	○
203	-	Tare count	×	○
204	-	Load cell output. Scale : 1 nV/V	×	○
205	-	Load cell output. Scale : 10 nV/V	×	○
206	-	Flow rate (per second)	×	○
301	-	Sequence No.	×	○
302	-	Batch weighing error	×	○
303	-	Actual free fall	×	○
304	-	Free fall (average)	×	○
305	-	Free fall coefficient (average)	×	○
306	-	Flow rate (when small flow is OFF)	×	○
307	-	Result of batch weighing	×	○
Function code	parameter	Function	○	○

6.3.3. Timing Chart

Example assumes that station No. is 1 and remote registers are occupied 4 stations.

1. Turning on the Display

1. Turn on the AD-4430C. When the CC-Link can communicate, the "Initial process request flag (RX0078)" is turned on.
 2. At the master station, checks, initialize and turn on the "Initial process finish flag (RY0078)".
 3. The AD-4430C turns off the "Initial process request flag (RX0078)" and turns on the "Remote station READY flag (RX007B)".
 4. Turn off the "Initial process finish flag (RY0078)" at the master station.
- When "0 : not needed" is set to **CC 04 initial process** of "5.4.8. The CC-Link Function ", the initial process is skipped and "Remote station READY (RX007B)" turns on.




Illustration 12 Turning on the display

2. Resuming Weighing Mode from Suspended Modes

Because the weighing stops and a correct weighing value is not gotten, the remote station READY flag (RX007B) is turned off in the calibration mode and in off mode (OFF state, standby). The way to resume weighing mode is the same as the process to turn on the AD-4430C.

Example 3. Requesting Initialization from Master Station

1. In case of requesting the "Initial setting request of the AD-4430C from the master station, while turning on the "Remote station READY flag (RX007B)", turn on the "Initial process request flag (RY0079)".
2. The AD-4430C turns off the "Remote station READY flag (RX007B)" and performs initial settings.
3. When finishing the initial setting, the AD-4430C turns on the "Initial data processing completion flag (RX0079)".
4. Turn off the "Initial data setting request flag (RY0079)" by the master station.




Illustration 13 Requesting initialization from master station

4. Inputting Setpoints (Basic Comparator Parameter)

- Setpoints (Basic comparator parameters) can be input into the AD-4430C using the remote register (RWw0000 to RWw000B) collectively.
- 1. Store setpoints to the remote register (RWw0000 to RWw000B).
Turn on the "Setpoint request flag (RY0000)".
- 2. Turn off the "Setpoint request flag (RY0000)" after turning on the "Setpoint writing flag (RX0000)".




Illustration 14 Inputting setpoints (Basic comparator parameters)

5. Reading Command

1. Select the type of data at the command No. (RWw000E) of remote register.
2. The output data is stored at the command data (RWw000C to RWw000D) of remote register.




Illustration 15 Reading command

6. Writing Command

1. Select the type of data at the command No. (RWw000E) of remote register.
2. Place the writing data at the command data (RWw000C to RWw000D) of remote register.




Illustration 16 Writing command

7. Monitoring the CPU Signal at Normal Operation

When the AD-4430C indicator status is normal, the following CPU normal operation flag (RX0006) is output. It alternates in a period between 0.5 second and 1 second.




Illustration 17 Monitoring the CPU signal

8. Resetting Error Status Flag

1. When an error is detected, the remote station READY flag (RX007B) is turned off, the error status (RX007A) turns on, and the error status is informed to the master station.
2. The master station requests to reset the error status flag (RX007A) using the error reset request flag (RY007A).




Illustration 18 Resetting error status flag

6.3.4. The Calibration

The AD-4430C can perform the calibration using the CC-Link commands (that consists of command data (RWw000C to RWw000D) and command No.(RWw000E) of the remote register). Refer to section "6.3.2. Commands" for the detail of these commands of the CC-Link. In the following steps, all command No. (RWw000E) of the remote register is 0.

- | | | |
|---------------|---|---------------------------------------|
| Step 1 | CAL zero mode
The AD-4430C displays [CAL 0] and enters the CAL zero input mode. | Command data (RWw000C to RWw000D): 91 |
| Step 2 | CAL zero setting
The input voltage at zero point (C-F17) is updated when a command is received.
The AD-4430C proceeds to CAL span input mode. | Command data (RWw000C to RWw000D): 94 |
| Step 3 | CAL span mode
The AD-4430C displays [CAL SPN] and enters the CAL span input mode. | Command data (RWw000C to RWw000D): 92 |
| Step 4 | CAL span setting
The span input voltage (C-F18) is updated when a command is received.
The AD-4430C returns to weighing mode. | Command data (RWw000C to RWw000D): 95 |
| Step 5 | CAL end
The AD-4430C displays [CAL End] and returns to weighing mode. | Command data (RWw000C to RWw000D): 93 |
- Specify the weight against span Input voltage (C-F19) on the function related to the calibration ([CAL]).

6.3.5. Self-Check

The connections of the load cell can be verified using the CC-Link command.

Refer to section "6.3.2. Commands" for the detail of these commands of the CC-Link. In the following steps, all command No. (RWw000E) of the remote register is 0.

- Step 1** Input the command to start self check. Command data (RWw000C to RWw000D): 81
The AD-4430C enters the self check mode and start the scan. (self check error)
- Step 2** Input the command to stop self check Command data (RWw000C to RWw000D): 82
The AD-4430C stops the self check mode and returns to weighing mode.
- Step 3** Input error reset request flag. Error reset request flag
The AD-4430C resets self check error flag.

The AD-4430C sums up the result of the self check and outputs it to error sub code (RWr0007). There is no error, the error sub code is 0. (The undiagnosed item is regarded as error.) Refer to "7.4.1. Guideline to Verify the Load Cell Connections" for the details of diagnostic point and check criteria. Refer to "7.4.5. Display and Output of Verification" for display and output of self check.

Self Check Item	Error code
Power supply voltage for load cell	1
SEN+ voltage	2
SEN- voltage	4
Output voltage of load cell	8
Output value of load cell	16
SIG+ voltage	32
SIG- voltage	64
Internal temperature	128

6.3.6. Function Settings

- The monitoring and changing of the function settings uses the "5. Reading Command" and "6. Writing Command" in the "6.3.3. Timing Chart".

Monitoring the Function Settings

Set the function code to command No. (RWw000E) using the "5. Reading Command".

Read data of the command data response (RWr000C to RWr000D)

Changing the Function Settings

Set the function code to command No. (RWw000E) using the "6. Writing Command".

Write data into the command data (RWw000C to RWw000D)

- Refer to the following sections for the function code.
 "5.3.6. The Calibration Function ($L-F_{nc}$)",
 "5.3.7. The Linearization Function ($L-F_{nc}$)",
 "5.4.2. The Basics Function ($F_{nc} F$)" to
 "5.4.8. The CC-Link Function ($CC F$)"

6.4. USB

- The function settings can be input and output from a device that is connected to the Micro-B USB connector.
- When the USB is connected to a personal computer (PC), the PC recognizes the USB as a virtual COM port. The setting of virtual COM port is shown below.
Baud rate: 9600 bps, Data bits: 7 bits, Parity: even, Stop bit: 1
- The communication tool can be downloaded at A&D website. Communication parameters are fixed.
- While weighing, do not perform cable connections. It may be easily influenced by environmental noise.
- Use the standard Micro-B USB connector.
- Reading is available whenever the power is on.
- Writing of the function from the USB is valid except weighing mode.

6.4.1. Format

Monitoring Command

Function code (4 figures) Terminator

Example of the near-zero

Command

1	2	0	8	CR	LF
---	---	---	---	----	----

Function code (4 figures) Data (7 figures) Terminator

Response

1	2	0	8	,	+	0	0	0	0	1	0	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

Storing Command and Response

Function code (4 figures) Data (7 figures) Terminator

Example of the near-zero

Command

1	2	0	8	,	+	0	0	0	0	1	0	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

Function code (4 figures) Data (7 figures) Terminator

Response

1	2	0	8	,	+	0	0	0	0	1	0	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

- The response of the monitoring command is the same as the storing command.
- "+999999" means an irregular response. Ex.: In case that the function code is not correct and the command is not perform.

6.4.2. Monitoring the Function Setting

It specifies a function code in the command code and monitors the data.

Command

N	N	N	N	CR	LF
---	---	---	---	----	----

Response

N	N	N	N	,	±	X	X	X	X	X	X	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

NNNN is code, ±XXXXXX is numerical number.

6.4.3. Storing the Function Setting

It specifies a function code in the command code and stores the data.

Command

N	N	N	N	,	±	X	X	X	X	X	X	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

Response

N	N	N	N	,	±	X	X	X	X	X	X	CR	LF
---	---	---	---	---	---	---	---	---	---	---	---	----	----

NNNN is code, ±XXXXXX is numerical number.

- In case of parameter type, store branch number.
- **Fnc01** (Key switch disable) is a decimal.

6.4.4. Monitoring the Whole Function Settings

Functions of all can be monitored at once. It can make a list of functions.

Command

N	N	N	N	CR	LF
---	---	---	---	----	----

NNNN is command.

Command code	Description
0999	All functions
1000	Calibration
1100	Linearity
1200	Basic
1300	Hold
1400	Weighing sequence
1500	Setpoint
1600	Control I/O
1700	Standard serial output
1800	CC-Link

6.4.5. Monitoring Each Piece of Data

Each function can be monitored.

Command

N	N	N	N	CR	LF
---	---	---	---	----	----

NNNN is command.

Command code	Description
0101	Program version
0102	Serial No.(lower 5 digits)
0103	Program checksum
0104	FRAM checksum
0201	Gross count
0202	Net count
0203	Tare count
0204	Load cell output. Scale : 1 nV/V
0205	Load cell output. Scale : 10 nV/V
0206	Flow rate (per second)

7. Maintenance

7.1. Error Messages

If an error message is displayed, use the following countermeasure.

Error message	Cause	Countermeasure
$[E5 Er]$	Program checksum error	Repairer is required.
$[Ad Er]$	Data can not be acquired from the A/D converter.	Repairer is required.
$[FrREr]$	Correct data can not be read from the nonvolatile memory (FRAM).	Initialize the module. If not be resolved, repairer is required.
$[E Err]$	Calibration data is incorrect.	Perform the calibration
$[E Er X]$	Calibration error.	Refer to "5.3.8. Error Codes for the Calibration". X: numerical.
$[Err dt]$	The setting value is out of range.	Check the setting value.

7.2. Check Mode

The check mode can be used to check the performance of the display, key switches and external I/O.


7.2.1. Entering Check Mode

- Step 1** Press the $[F]$ key while holding the $[ENT]$ key ($[ENT] + [F]$) to display $[Fnc]$. To return to weighing mode, press the $[ESC]$ key.
- Step 2** Press the $[ENT]$ key while holding the $[→]$ key ($[→] + [ENT]$) to display $[Hc]$ in check mode. Press the $[ENT]$ key to display the check item.
- Step 3** Select the checked item using the $[↑]$ key. Press the $[ENT]$ key to enter it. Press the $[ESC]$ key to exit.

Display symbol	Item
$[HKEY]$	Key check
$[H io]$	Control I/O check
$[H [L]$	Standard serial output check
$[H [C]$	CC-Link check
$[H Ad]$	A/D converter output check (Load cell check)
$[H in]$	Internal count check
$[HPrg]$	Program version
$[H Sn]$	Serial number
$[SPrg]$	Program checksum
$[SFrA]$	Memory checksum
$[F dt]$	C-Fnc check (C-F01 to C-F28)


7.2.2. Verifying the Switch Operation

When pressing the key, the corresponding segment moves. "8" & "8".
 To stop the current check mode, press the **ESC** key twice.



7.2.3. Checking the Control I/O

When pressing the **↑** key when the terminal number of the control I/O is displayed, the output turns on sequentially (out 0 is all OFF). When turning on the input of the control I/O, the LED illuminates.




7.2.4. Checking the Standard Serial Output

Test data "ST, GS, +00000.0kg<CR><LF>" is output using a preset baud rate every time the **ENT** key is pressed.


7.2.5. Checking the CC-Link

The status of the CC-Link communication can be monitored.
 The remote register (RWw0000 to RWw0001) can be monitored.
 When 4 stations are used, net value is displayed.
 When 2 stations or 1 station are used, the display accords with data output (**CC 05**).
 The initialization request can be sent to the master station with the **ENT** key.




7.2.6. Monitoring the A/D Converter (for Load Cell Output)

The voltage output rate of the load cell is displayed in units of mV/V.
 Example: When the internal count is 1.2345 mV/V and the output rate is above ± 7 mV/V, a load cell damage or connection error may occur. Refer to "7.5. Verifying Load Cell Connections Using Multimeter".




7.2.7. Monitoring the Internal Value

The current internal count (10 times of weighing value) is displayed.
 When the internal count is 123, the example display is as follows:




7.2.8. Monitoring the Program Version

The program version is displayed.
 Example: Version 1.00 is as follows:



7.2.9. Monitoring the Serial Number


The last five digits of the serial number is displayed.



7.2.10. Monitoring the Checksum of the Program

The checksum of the program is displayed.


Example: Checksum is EF.



7.2.11. Monitoring the Checksum of an Internal FRAM

The checksum of FRAM is displayed. Memory of the general function is not checked.

Example: Checksum is EF.






7.2.12. Displaying Function Parameters for the Calibration

The function related to the calibration can be displayed.




- Refer to "**5.3.6. The Calibration Function**" for operation and details.
- Parameters can not be changed here.

7.3. Initializing Parameters


The initialization mode restores the parameters to the default values in the FRAM. Three types of initialization mode are available as shown below.

Initialization mode	Display	Description
RAM initialization		RAM memory is initialized. The center of zero and tare value will be restored to 0.
General function initialization		Data of the general functions stored in the FRAM and the RAM are reset to factory settings.
All data initialization		All data stored in the FRAM, general functions and RAM are initialized. Data related to calibration is also initialized, so calibration must be performed again.

7.3.1. Initializing Mode for RAM and Function Parameters

- Step 1** Press the **F** key while holding the **ENT** key (**ENT** + **F**) to display  for general functions mode. To return to weighing mode, press the **ESC** key.
- Step 2** Press the **ENT** key while holding the **→** key (**→** + **ENT**) to display  for check mode.
- Step 3** Select initialization mode  using the **↑** key. Press the **ENT** key.
- Step 4** Select an item to be initialized using the **↑** key. Press the **ENT** key.
- Step 5** Check that all LED status are blinking.
To perform the initialization, hold the **ENT** key for 3 seconds or more.
After initialization, all segments will illuminate and return to weighing mode.
To cancel the initialization, press the **ESC** key to return to weighing mode.

7.3.2. Initializing All Data

- Step 1** In OFF mode (Standby: While turning off the module), press **F** + **ENT** keys to display  for calibration mode.
To return to weighing mode, press the **ESC** key.
- Step 2** Press the **ENT** key to enter into calibration mode.
- Step 3** Press the **↑** key four times to select initialization all data mode and press the **ENT** key.
- Step 4** Check that all LED status lights are blinking.
To initialize, hold the **ENT** key for 3 seconds or more.
After initialization, all segments illuminate and return to weighing mode.
To cancel the initialization, press the **ESC** key to return to weighing mode.

7.4. Verifying Load Cell Connections (DIAGNOS)

7.4.1. Guideline to Verify Load Cell Connections

Faulty wiring or disconnection of the load cell can be checked using the AD-4430C. This verification is useful for new settings, pre-measurement inspections and periodic inspections.

No.	Diagnostic item	Diagnostic point	Judgment Criteria (General)	Error code
1	Load cell input voltage	Between SEN+ ↔ SEN-	3 V or more	1
2	SEN+ voltage	Between SEN+ ↔ AGND	4 V or more	2
3	SEN- voltage	Between SEN- ↔ AGND	1 V or less	4
4	Load cell output voltage	Between SIG+ ↔ SIG-	Within ±35 mV	8
5	Load cell output rate	Between SIG+ ↔ SIG-	Within ±7 mV/V	16
6	SIG+ voltage	Between SIG+ ↔ AGND	1 V to 4 V	32
7	SIG- voltage	Between SIG- ↔ AGND	1 V to 4 V	64
8	Internal temperature		-20 °C to +60 °C	128

AGND : Internal analog circuit ground
 EXC- : Load cell excitation voltage (-)
 EXC+ : Load cell excitation voltage (+)
 SIG- : Load cell output (-)
 SIG+ : Load cell output (+)

SHLD : Shield. Frame ground.
 SEN- : Sensing input (-)
 SEN+ : Sensing input (+)




Illustration 19 Checking the load cell connection

7.4.2. Verifying Load Cell Connections with Switch Operation

- Step 1** Press the **F** key while holding the **ENT** key (**ENT** + **F**) to display **Fnc** for general functions mode. Press the **ENT** key to enter general functions mode.
To return to weighing mode, press the **ESC** key.
- Step 2** Press the **ENT** key while holding the **→** key (**→** + **ENT**) to display check mode **LHc**. To display the check item, press the **ENT** key.
- Step 3** Press the **↑** key twice to select load cell connections diagnosis **d,RL** and then press the **ENT** key to enter it. Each item is automatically diagnosed. After approx. 16 seconds, the diagnosis is displayed. Also, each diagnosis is checked by selecting items pressing the **↑** key.
Press the **ESC** key to return to the display **d,RL**.

7.4.3. Verifying Load Cell Connections with the CC-Link

The connections of the load cell can be verified using the CC-Link command.

Refer to section "6.3.2. Commands" for the detail of these commands of the CC-Link. In the following steps, all command No. (RWw000E) of the remote register is 0.

- Step 1** Input the command to start the self check. Command data (RWw000C to RWw000D): 81
The AD-4430C enters to the self check mode and start the scan. (self check error)
The result is stored in the error sub code (RWr0007).
- Step 2** Input the command to stop the self check Command data (RWw000C to RWw000D): 82
The AD-4430C stops the self check mode and returns to weighing mode.
The CC-Link outputs the diagnose result of self check error directly.
- Step 3** Input error reset request flag. Error reset request flag
The AD-4430C resets self check error flag.
- The status of the CC-link is the same as the status of "Verifying Load Cell Connections with the CC-Link". Request an error reset and reset error.

7.4.4. Verifying Using Control I/O

- Step 1** When the input terminal of the control I/O is set to "diagnose" and remains "ON" for 1 second or more, the display shows **d,RL** and checks each item automatically.
After approx. 16 seconds, the diagnosis is displayed.
- When the control I/O is set to "OFF", the diagnosis ends. Keep "ON" until the diagnosis is displayed.
- Step 2** Turn off the input terminal of the control I/O set to "diagnose" and AD-4430C returns to weighing mode.

7.4.5. Display and Output of Verification

Total value of error codes is output to the error sub code (RWr0003) in the CC-Link. Items that have not been diagnosed are also totaled as errors. Refer to "7.4.1. Guideline to Verify the Load Cell Connections" concerning the detail of the diagnose point and judgment criteria.

When scanning and changing items, d,RC is displayed and 99999 is output. The diagnostic result of the scanning are displayed and output as a code *XXX* in which error codes are accumulated.

If there are no errors, Good is displayed and 00000 is output.

If there is an error, ErXXX is displayed and 00XXX is output.

The resistance of the load cell cable is calculated with the following formula :
 (Resistance of Load cell) x (SEN- voltage) / (Load cell input voltage)

No.	Check item	Status LED	Display Range	Error Code
		G N H S Z X		
1	Load cell excitation voltage	● ● ● ● ● ●	0.001 V	1
2	SEN+ voltage	● ● ● ● ● ●	0.001 V	2
3	SEN- voltage	● ● ● ● ● ●	0.001 V	4
4	Load cell output voltage	● ● ● ● ● ●	0.001 mV	8
5	Load cell output rate	● ● ● ● ● ●	0.0001 mV/V	16
6	SIG+ voltage	● ● ● ● ● ●	0.001 V	32
7	SIG- voltage	● ● ● ● ● ●	0.001 V	64
8	Internal temperature	● ● ● ● ● ●	0.1 °C	128

● : Lit, ○ : Not lit

7.5. Verifying Load Cell Connections Using Multimeter

The load cell connection can be checked easily using a digital multimeter.

The measurement points of the load cell connection are shown below:

When a summing box is used, the same measurement points inside the summing box must be measured.




Illustration 20 Load cell connection check

7.5.1. Check List for load cell connections

Measurement points	Description	Conditions
EXC+ SEN+	Drop voltage of cable on EXC+ side.	Normally it is 100 mV or less. However, it may exceed 1V when an extremely long load cell cable is used. For the 4-wire connection, it must be 0 V.
EXC+ EXC-	Input voltage	Normal range is between 4.75 V to 5.25 V.
SIG- EXC-	Center point voltage	Approximately 2.5 V, about a half of excitation voltage.
SIG+ SIG-	Output voltage	Generally, it is within 0 V to 15 mV. The theoretical value is calculated from the load cell rated capacity, actual load and excitation voltage.

When the module does not operate properly, write the required items in the table below and contact your local A&D dealer.

Item	Usage circumstances, model number, rated, measurement value etc.	Note
Connection method	<input type="checkbox"/> 4-wire connection <input type="checkbox"/> 6-wire connection	When using the 4-wire connection, connect between EXC+ and SEN+ and between EXC- and SIG-.
Model name & number		
Rated capacity	[Unit]	
Rated output	[mV/V]	
Allowable overload	[%]	
The number of load cells used	[pieces]	
Use of summing box		
Length of the extension cable	[m]	Length between the module and the summing box.
Initial load of weighing module	[Unit]	
Minimum division of weighing module	[Unit]	All digits including decimal figures. Ex: 0.002kg
Capacity of weighing module	[Unit]	All digits including decimal figures. Ex: 10.000kg
Output of load cell using initial load	[mV/V]	Between -0.1mV/V and rated sensitivity of load cell (using initial load)
Output of load cell using capacity or arbitrary load.	Load cell output at Load [Unit] [mV/V]	When loaded to capacity, the output value of the initial load + the rated output value of the load cell. (It must be within allowable overload.)

Measurement points		Measurement contents	Measurement result
EXC+	SEN+	A drop voltage of cable on EXC+ side.	[mV]
EXC+	EXC-	Input voltage	[V]
SEN-	EXC-	A drop voltage of cable on EXC- side.	[mV]
SIG-	EXC-	Center point voltage	[V]
SIG+	SIG-	Output voltage	[mV]

7.6. The Parameter List For The Function

When performing maintenance, use the following list as a memorandum.

When making inquiries about the product, inform your local A&D dealer of the user settings.

7.6.1. The Calibration Function (\bar{C} -Func)

Item Name	Function code	Description, Range and Default value	User setting
C-F01 Unit	1001	0: Not used 1: g 2: kg 3: t 4: N 5: kN	
C-F02 Decimal point position	1002	0: 0 1: 0.0 2: 0.00 3: 0.000 4: 0.0000	
C-F03 Minimum division	1003	1: 1 2: 2 3: 5 4: 10 5: 20 6: 50	
C-F04 Maximum capacity	1004	1 to 70000 to 99999	
C-F05 Zero range	1005	0 to 2 to 100	
C-F06 Zero tracking time	1006	0.0 to 5.0	
C-F07 Zero tracking width	1007	0.0 to 9.9	
C-F08 Stability detection time	1008	0.0 to 1.0 to 9.9	
C-F09 Stability detection width	1009	0 to 2 to 9	
C-F10 Tare and zero at unstable weight value	1010	0: Disables both functions. 1: Enables both functions.	
C-F11 Tare when the gross weight is negative	1011	0: Disables tare. 1: Enables tare.	
C-F12 Output when out of range and unstable	1012	0: Disables output. 1: Enables output.	
C-F13 Exceeding negative gross weight	1013	1: Gross weight < -99999 2: Gross weight < Negative maximum capacity 3: Gross weight < -19d	
C-F14 Exceeding negative net weight	1014	1: Net weight < -99999 2: Net weight < Negative maximum capacity	
C-F15 Clear the zero value	1015	0: Disables. 1: Enables.	
C-F16 Zero setting when power is turned on	1016	0: Not used. 1: Use.	

Item Name	Function code	Description, Range and Default value	User setting
C-F17 Input voltage at zero	1017	-7.0000 to <input type="text" value="0.0000"/> to 7.0000	
C-F18 Span input voltage	1018	0.0100 to <input type="text" value="3.2000"/> to 9.9999	
C-F19 Weight against span input voltage	1019	1 to <input type="text" value="32000"/> to 99999	
C-F26 Gravity acceleration of the calibration place	1026	9.7500 to <input type="text" value="9.8000"/> to 9.8500	
C-F27 Gravity acceleration of use place	1027	9.7500 to <input type="text" value="9.8000"/> to 9.8500	
C-F28 Suppression of the hold function	1028	<input type="text" value="0"/> : Permission. 1: Prohibition.	

7.6.2. The Linearization Function (L - F n c)

Item Name	Function code	Description, Range and Default value	User setting
L-F01 Number of input points	1101	<input type="text" value="0"/> to 5	
L-F02 Linear-zero	1102	-7.0000 to <input type="text" value="0.0000"/> to 7.0000	
L-F03 Setting value for linear 1	1103	<input type="text" value="0"/> to 99999	
L-F04 Span at linear 1	1104	<input type="text" value="0.0000"/> to 9.9999	
L-F05 Setting value for linear 2	1105	<input type="text" value="0"/> to 99999	
L-F06 Span at linear 2	1106	<input type="text" value="0.0000"/> to 9.9999	
L-F07 Setting value for linear 3	1107	<input type="text" value="0"/> to 99999	
L-F08 Span at linear 3	1108	<input type="text" value="0.0000"/> to 9.9999	
L-F09 Setting value for linear 4	1109	<input type="text" value="0"/> to 99999	
L-F10 Span at linear 4	1110	<input type="text" value="0.0000"/> to 9.9999	

7.6.3. The Basics Function (Fnc F)

Item Name	Function code	Description, Range and Default value	User setting
Fnc01 Key switch disable	1201	0: Permission, 1: Prohibition 0000 to 1111	
Fnc02 [F] key function	1202	0: None 1: Manual print command 2: Hold 3: Alternative switch (Active [F] key) 4: Momentary switch (Active [F] key) 5: Display exchange 6: Tare clear 7: Zero clear 8: Weighing start / Pause / Re-start 9: Actual free fall input 10: One shot, Small flow 11: Sequence flow rate monitor 12: mV/V monitor 13: Digital filter 2	
Fnc03 Display refresh rate	1203	1: 20 times/sec. 2: 10 times/sec. 3: 5 times/sec.	
Fnc04 x display	1204	0: None 1: Zero tracking in progress 2: Alarm (Zero range setting error, over) 3: Active [F] key 4: Near-zero 5: HI output (Over the upper limit value) 6: OK output (Between upper and lower limit values) 7: LO output (Below the lower limit value) 8: Large flow 9: Medium flow 10: Small flow 11: Over 12: OK 13: Under 14: Full value 15: Weighing end 16: Weighing sequence, in processing 17: Weighing sequence, error 18: Normal batch/Loss-in-weight, Identification 19 to 24: User input1 to 6 25 to 32: User output 1 to 8	

Item Name	Function code	Description, Range and Default value	User setting
Fnc05 Digital filter 1	1205	0: None 1: 100.0 Hz 2: 70.0 Hz 3: 56.0 Hz 4: 40.0 Hz 5: 28.0 Hz 6: 20.0 Hz 7: 14.0 Hz 8: 10.0 Hz 9: 7.0 Hz 10: 5.6 Hz 11: 4.0 Hz 12: 2.8 Hz 13: 2.0 Hz 14: 1.4 Hz 15: 1.0 Hz	
Fnc06 Digital filter 2	1206	0: None 1: 100.0 Hz 2: 70.0 Hz 3: 56.0 Hz 4: 40.0 Hz 5: 28.0 Hz 6: 20.0 Hz 7: 14.0 Hz 8: 10.0 Hz 9: 7.0 Hz 10: 5.6 Hz 11: 4.0 Hz 12: 2.8 Hz 13: 2.0 Hz 14: 1.4 Hz 15: 1.0 Hz 16: 0.70 Hz 17: 0.56 Hz 18: 0.40 Hz 19: 0.28 Hz 20: 0.20 Hz 21: 0.14 Hz 22: 0.10 Hz 23: 0.07 Hz	
Fnc07 Hold function	1207	1: Normal hold 2: Peak hold 3: Averaging hold	
Fnc08 Near-zero	1208	-99999 to 10 to 99999	
Fnc09 Comparison target at near-zero	1209	1: Gross weight 2: Net weight	
Fnc10 Upper limit value	1210	-99999 to 10 to 99999	
Fnc11 Lower limit value	1211	-99999 to -10 to 99999	
Fnc12 Comparison target of upper and lower limit	1212	1: Gross weight 2: Net weight	
Fnc13 Full value	1213	-99999 to 99999	

7.6.4. The Hold Function (H L d F)

Item Name	Function code	Description, Range and Default value	User setting
HLd01 Averaging time	1301	<input type="text" value="0.00"/> to 9.99	
HLd02 Start wait time	1302	<input type="text" value="0.00"/> to 9.99	
HLd03 Condition of automatic start	1303	<input type="text" value="0"/> : Not used 2: Above the near-zero 1: Above the near-zero, and stable	
HLd04 Release using control input	1304	0: Do not release <input type="text" value="1"/> : Release	
HLd05 Release time	1305	<input type="text" value="0.00"/> to 9.99	
HLd06 Release using fluctuation range	1306	<input type="text" value="0"/> to 99999	
HLd07 Release at the near-zero	1307	<input type="text" value="0"/> : Do not release 1: Release	

7.6.5. The Weighing Sequence Program Function (S_q F)

Item Name	Function code	Description, Range and Default value	User setting
Sq 01 Final value	1401	-99999 to 0 to 99999	
Sq 02 Free fall	1402	-99999 to 0 to 99999	
Sq 03 Preliminary	1403	-99999 to 0 to 99999	
Sq 04 Optional preliminary	1404	-99999 to 0 to 99999	
Sq 05 Over	1405	-99999 to 0 to 99999	
Sq 06 Under	1406	-99999 to 0 to 99999	
Sq 07 Weighing mode	1407	0: Not used 1: Normal batch sequence 2: Discharge sequence 3: Specifying with control input 4: Specifying with CC-Link	
Sq 08 Automatic free fall correction	1408	0: Not used 1: Moving average of last four times 2: Real time free fall compensation (fixed coefficient) 3: Real time free fall compensation (updated coefficient)	
Sq 09 Automatic free fall band	1409	0 to 99999	
Sq 10 Active free fall coefficient	1410	-99.999 to 0.000 to 99.999	
Sq 11 OK/Over/Under output timing	1411	1: Always 2: In synchronization with weighing end	
Sq 12 Stability at judgment	1412	0: Disable 1: Enable	
Sq 13 Automatic tare at weighing start	1413	0: Disable 1: Enable	
Sq 21 Flow timeout time	1421	0 to 600	
Sq 22 Weighing start input delay time	1422	0.0 to 60.0	
Sq 23 Large flow comparison disable time	1423	0.0 to 60.0	
Sq 24 Medium flow comparison disable time	1424	0.0 to 60.0	
Sq 25 Small flow comparison disable time	1425	0.0 to 60.0	
Sq 26 Judging delay time	1426	0.0 to 0.1 to 60.0	
Sq 27 Weighing end output time	1427	0.0 to 60.0	
Sq 28 One-shot time for small flow rate	1428	0.00 to 6.00	

7.6.6. The Setpoint Function (SP F)

Item Name	Function code	Description, Range and Default value	User setting
SP01 Object of SP1	1501	0 to <input type="text" value="1"/> to 11	
SP02 Object of SP2	1502	0: Not used 1: Final value 0 to <input type="text" value="2"/> to 11	
SP03 Object of SP3	1503	2: Optional preliminary 3: Preliminary 0 to <input type="text" value="3"/> to 11	
SP04 Object of SP4	1504	4: Free fall 5: Over 0 to <input type="text" value="4"/> to 11	
SP05 Object of SP5	1505	6: Under 7: Full 0 to <input type="text" value="5"/> to 11	
SP06 Object of SP6	1506	8: Near-zero 9: Free fall coefficient 0 to <input type="text" value="6"/> to 11	
SP07 Object of SP7	1507	10: Upper limit 11: Under limit 0 to <input type="text" value="7"/> to 11	
SP08 Object of SP8	1508	0 to <input type="text" value="8"/> to 11	
SP11 Parameter of SP1	1511	-99999 to <input type="text" value="0"/> to 99999	
SP12 Parameter of SP2	1512	-99999 to <input type="text" value="0"/> to 99999	
SP13 Parameter of SP3	1513	-99999 to <input type="text" value="0"/> to 99999	
SP14 Parameter of SP4	1514	-99999 to <input type="text" value="0"/> to 99999	
SP15 Parameter of SP5	1515	-99999 to <input type="text" value="0"/> to 99999	
SP16 Parameter of SP6	1516	-99999 to <input type="text" value="0"/> to 99999	
SP17 Parameter of SP7	1517	-99999 to <input type="text" value="99999"/>	
SP18 Parameter of SP8	1518	-99999 to <input type="text" value="10"/> to 99999	

7.6.7. The Control I/O Function (\square F)

Item Name	Function code	Description, Range and Default value	User setting
io 01 Function of IN1	1601	0 : Not used 1 to 6 : User input 1 to 6 7 : Zero	0 to 1 to 24
io 02 Function of IN2	1602	8 : Tare 9 : Hold 10 : Gross / Net exchange	0 to 2 to 24
io 03 Function of IN3	1603	11 : Diagnose 12 : Print command 13 : Weighing start	0 to 3 to 24
io 04 Function of IN4	1604	14 : Pause 15 : Restart 16 : Emergency stop (Level input)	0 to 4 to 24
io 05 Function of IN5	1605	17 : Error reset 18 : Normal batch/Loss-in-weight exchange 19 : Actual free fall input	0 to 5 to 24
io 06 Function of IN6	1606	20 : One shot, Small flow 21 : Full open (Level input) 22 : Zero clear 23 : Tare clear 24 : Operation same as a F key	0 to 6 to 24
io 11 Function of OUT1	1611	0 : Not used 1 to 8 : User output 1 to 8 9 : Stability	0 to 1 to 34
io 12 Function of OUT2	1612	10 : Over capacity 11 : Net display 12 : During tare 13 : Hold	0 to 2 to 34
io 13 Function of OUT3	1613	14 : Hold busy 15 : HI output (Over the upper limit value) 16 : OK output (Between upper and lower limit values) 17 : LO output (Below the lower limit value)	0 to 3 to 34
io 14 Function of OUT4	1614	18 : Near-zero 19 : Full 20 : Over 21 : OK	0 to 4 to 34
io 15 Function of OUT5	1615	22 : Under 23 : Large flow 24 : Medium flow	0 to 5 to 34
io 16 Function of OUT6	1616	25 : Small flow 26 : Normal batch/Loss-in-weight, Identification 27 : In weighing sequence 28 : Weighing end	0 to 6 to 34
io 17 Function of OUT7	1617	29 : Weighing sequence error 30 : In weighing (ON) 31 : In weighing (1 Hz) 32 : In weighing (50 Hz)	0 to 7 to 34
io 18 Function of OUT8	1618	33 : Alarm 34 : Active F key	0 to 8 to 34

Item Name	Function code	Description, Range and Default value	User setting
io 21 OUT1 Logic	1621	<p>1: Inverting output If data is "0" level, the output transistor conducts (ON).</p> <p>2: Non inverting output If data is "1" level, the output transistor conducts (ON).</p>	
io 22 OUT2 Logic	1622		
io 23 OUT3 Logic	1623		
io 24 OUT4 Logic	1624		
io 25 OUT5 Logic	1625		
io 26 OUT6 Logic	1626		
io 27 OUT7 Logic	1627		
io 28 OUT8 Logic	1628		

7.6.8. The Standard Serial Output Function (*EL F*)

Item Name	Function code	Description, Range and Default value	User setting
CL 01 Serial data	1701	<p>1: Weighing display</p> <p>2: Gross</p> <p>3: Net</p> <p>4: Tare</p> <p>5: Gross / Net / Tare</p>	
CL 02 Communication mode	1702	<p>1: Stream</p> <p>2: Automatic print</p> <p>3: Manual print</p>	
CL 03 Baud rate	1703	<p>1: 600 bps</p> <p>2: 2400 bps</p>	

7.6.9. The CC-Link Function (CC F)

Item Name	Function code	Description, Range and Default value	User setting
CC 01 Station number	1801	<input type="text" value="1"/> to 64	
CC 02 Number of remote register occupied	1802	0: 1 stations 1: 2 stations <input type="text" value="2"/> : 4 stations	
CC 03 Baud rate	1803	0: 156 kbps 1: 625 kbps 2: 2.5 Mbps 3: 5 Mbps <input type="text" value="4"/> : 10 Mbps	
CC 04 Initial process	1804	0: Not needed <input type="text" value="1"/> : Necessary	
CC 05 Output data	1805	<input type="text" value="0"/> : Weighing display 1: Net 2: Gross	
CC 06 Weighing information 1	1806	<input type="text" value="0"/> : Not used 1 : Sequence number 2 : Batch weighing error 3 : Actual free fall 4 : Free fall (Averaging) 5 : Free fall coefficient (Averaging) 6 : Sequence flow rate (In small flow OFF) 7 : Sequence flow rate (Real time)	
CC 07 Weighing information 2	1807	8 : Load cell output. Scale : 1 nV/V 9 : Net (Digital filter 2) 10 : Gross (Digital filter 2)	



A&D Company, Limited

3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013, JAPAN
Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-1566

A&D ENGINEERING, INC.

1756 Automation Parkway, San Jose, California 95131, U.S.A.
Telephone: [1] (408) 263-5333 Fax: [1] (408) 263-0119

A&D INSTRUMENTS LIMITED

Unit 24/26 Blacklands Way, Abingdon Business Park, Abingdon, Oxfordshire OX14 1DY United Kingdom
Telephone: [44] (1235) 550420 Fax: [44] (1235) 550485

A&D AUSTRALASIA PTY LTD

32 Dew Street, Thebarton, South Australia 5031, AUSTRALIA
Telephone: [61] (8) 8301-8100 Fax: [61] (8) 8352-7409

A&D KOREA Limited

한국에이.엔.디(주)
서울특별시 영등포구 국제금융로6길33 (여의도동) 맨하탄빌딩 817 우편 번호 07331
(817, Manhattan Bldg., 33. Gukjegeumyung-ro 6-gil, Yeongdeungpo-gu, Seoul, 07331 Korea)
전화: [82] (2) 780-4101 팩스: [82] (2) 782-4264

ООО A&D RUS

ООО "ЭЙ энд ДИ РУС"
121357, Российская Федерация, г.Москва, ул. Верейская, дом 17
(Business-Center "Vereyskaya Plaza-2" 121357, Russian Federation, Moscow, Vereyskaya Street 17)
тел.: [7] (495) 937-33-44 факс: [7] (495) 937-55-66

A&D INSTRUMENTS INDIA PRIVATE LIMITED

ऐ&डी इन्स्ट्रूमेन्ट्स इण्डिया प्रा० लिमिटेड
509, उद्योग विहार, फेस -5, गुडगांव - 122016, हरियाणा, भारत
(509, Udyog Vihar, Phase-V, Gurgaon - 122 016, Haryana, India)
फोन : 91-124-4715555 फैक्स : 91-124-4715599